TUYU KS-2615P

TUYU Electric Spin Scrubber User Manual - Model KS-2615P

Efficient Cleaning for Your Home

1. Introduction

Thank you for choosing the TUYU Electric Spin Scrubber. This cordless, full-body IPX7 waterproof cleaning brush is designed to simplify your cleaning tasks, offering powerful rotation and versatile attachments for various surfaces. Please read this manual carefully before use to ensure proper operation and maintenance.

2. Product Overview & Included Components

The TUYU Electric Spin Scrubber comes with a comprehensive set of components to address diverse cleaning needs. Familiarize yourself with each part before assembly and use.

- Electric Spin Scrubber Main Unit
- Adjustable Extension Rod (2 sections)
- USB Charging Cable (Type C)
- 7 Replaceable Brush Heads:
  - Hard Flat Brush (Large)
  - Hard Flat Brush (Small)
  - Corner Brush
  - Dome Brush
  - Sponge Brush
  - Scouring Pad
  - Copy Wool Brush (Microfiber)
- 1 Hook for storage
- User Manual



Figure 1: All components of the TUYU Electric Spin Scrubber package.

3. Setup

3.1 Assembling the Scrubber

1. **Attach Extension Rod (Optional):** If extended reach is desired, connect the two sections of the stainless-steel extension rod by screwing them together. Then, align the extension rod with the main unit's handle and push until it clicks securely into place. To remove, press the release button on the handle and pull apart.
2. **Attaching Brush Heads:** Select the appropriate brush head for your cleaning task. Align the grooves on the back of the brush head with the corresponding slots on the main unit's rotating head. Push the brush head firmly onto the unit until it clicks into place.
3. **Removing Brush Heads:** To change a brush head, simply pull it firmly away from the main unit. No buttons or twisting are required for removal.



Figure 2: The adjustable extension rod allows for comfortable cleaning of hard-to-reach areas.

4. Charging

The TUYU Electric Spin Scrubber features fast charging via a Type-C USB port. Ensure the unit is fully charged before its first use for optimal performance.

1. Locate the Type-C charging port on the main unit, typically covered by a rubber seal for waterproofing.
2. Open the rubber seal and insert the provided USB charging cable. Connect the other end to a compatible USB power adapter (not included).
3. The LED digital display on the unit will show the battery usage percentage. The indicator light will be red during charging and turn green when fully charged.
4. A full charge typically takes 2-3 hours and provides up to 90 minutes of working time.
5. After charging, ensure the rubber seal is completely closed to maintain IPX7 waterproofing.



Figure 3: The LED display shows real-time battery level, and the unit charges via Type-C USB.

5. Operating Instructions

The scrubber offers two adjustable speeds for different cleaning intensities.

1. **Power On/Off:** Press and hold the power button on the main unit to turn the scrubber on or off.
2. **Adjust Speed:** Once powered on, press the power button once to switch between the two speed modes:
    - **Low Speed (350 RPM/Min):** Ideal for normal cleaning and reducing splashing.
    - **High Speed (450 RPM/Min):** Suitable for heavy-duty cleaning and stubborn stains.
3. **Cleaning:** Apply appropriate cleaning solution to the surface or brush head. Guide the rotating brush over the area to be cleaned. The powerful motor and various brush heads make cleaning efficient.



Figure 4: Choose between High Speed for heavy-duty cleaning and Low Speed to reduce splashing.

6. Cleaning Applications

The TUYU Electric Spin Scrubber includes 8 versatile cleaning heads, each designed for specific tasks and surfaces:

- **Hard Flat Brush (Large):** Ideal for large flat surfaces like floors, tiles, walls, and glass.
- **Hard Flat Brush (Small):** Perfect for detailed work on cooktops, cabinets, and countertops.
- **Corner Brush:** Designed to clean corners, crevices, and curved areas such as bathtubs and sinks.
- **Dome Brush:** Excellent for cleaning curved and recessed objects, including bathtubs and sinks.
- **Sponge Brush:** Suitable for gentle cleaning and polishing of delicate surfaces.
- **Scouring Pad:** For tougher stains on durable surfaces.
- **Copy Wool Brush (Microfiber):** Great for polishing and waxing surfaces like cars or furniture.



Figure 5: Various brush heads for different cleaning needs, including flat, corner, and dome shapes.



Figure 6: The wide flat brush is effective for large flat surfaces.



Figure 7: The corner brush is designed for hard-to-reach areas and crevices.



Figure 8: Use the small flat brush for detailed cleaning of compact areas.



Figure 9: The dome brush is effective for curved and recessed surfaces like bathtubs.



Figure 10: The sponge brush and scouring pad are suitable for various cleaning tasks, including car tires.

7. Maintenance

1. **Cleaning Brush Heads:** After each use, remove the brush head and rinse it thoroughly with water to remove any cleaning solution or debris. Allow to air dry completely before storing.
2. **Cleaning the Main Unit:** Wipe the main unit with a damp cloth. Do not use abrasive cleaners, steel wool, or harsh chemicals. Ensure the charging port's rubber seal is closed before cleaning to prevent water ingress.
3. **Storage:** Store the scrubber and its attachments in a dry, cool place, away from direct sunlight. Use the provided hook to hang the unit for convenient storage.

8. Safety Information

- The entire machine is IPX7 waterproof, allowing it to be used in wet environments. However, ensure the charging port's rubber seal is completely closed before exposing the unit to water to prevent damage.
- Do not submerge the main unit in water for extended periods, especially if the charging port seal is compromised.
- Keep the device out of reach of children.
- Use only the provided charging cable.
- Do not use the scrubber on delicate surfaces that may be scratched by the brush heads. Test on an inconspicuous area first.



Figure 11: The IPX7 waterproof rating allows for use in wet conditions, but ensure the charging port is sealed.

9. Troubleshooting

If the scrubber does not turn on or operate correctly:

- Check the battery level on the LED display. If low, recharge the unit fully.
- Ensure the brush head is correctly attached and securely clicked into place.
- If the unit still malfunctions, contact customer support for assistance.

10. Specifications

- **Brand:** TUYU
- **Model Number:** KS-2615P
- **Color:** Grey White
- **Handle Material:** Plastic, Stainless Steel

- **Product Dimensions:** 17.52"L x 5.91"W x 5.5"H
- **Special Feature:** Adjustable, Cordless, Lightweight, Waterproof (IPX7), Reusable, Hanging Loop
- **Battery:** 1 Lithium Ion battery (included)
- **Charging Port:** Type C USB
- **Working Time:** Up to 90 minutes (on a full charge)
- **Speed Settings:** Low (350 RPM/Min), High (450 RPM/Min)
- **Item Weight:** 2 Pounds
- **Manufacturer:** Shenzhenshi Shiheng Technology CO., Ltd.

11. Warranty and Support

For any warranty claims, technical support, or inquiries regarding your TUYU Electric Spin Scrubber, please contact the manufacturer or the seller directly through your purchase platform. Refer to your purchase documentation for specific contact details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question