Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Dyson 419639-01

Dyson V11 Extra Cordless Vacuum Cleaner User Manual

Model: 419639-01

Introduction

The Dyson V11 Extra cordless vacuum cleaner is engineered with the power, versatility, and run time to deep clean homes with pets. This manual provides essential information for the setup, operation, and maintenance of your new Dyson V11 Extra.

What's in the Box

Your Dyson V11 Extra package includes the following components:

- Dyson V11 Extra Main Body (Motor, Bin, Battery)
- Wand (Long extension pipe)
- High Torque cleaner head with Dynamic Load Sensor (Main floor head)
- Mini-motorized tool (Anti-tangle brush bar)
- Combination tool (Wide nozzle and brush in one)
- Crevice tool
- Extension hose
- Up-top adapter (Adjustable angle tool)
- Docking station (Wall-mountable charging dock)
- Charger
- User Manual and Warranty Information





Image: All components of the Dyson V11 Extra Cordless Vacuum Cleaner.

Setup

1. **Initial Charge:** Fully charge the vacuum before first use. Connect the charger to the battery port or the docking station. The LCD screen will display charging progress.
2. **Assemble the Wand:** Click the wand (long pipe) into the main body until it securely latches.
3. **Attach a Cleaner Head:** Select your desired cleaner head (e.g., High Torque cleaner head) and click it onto the end of the wand. For handheld use, attach tools directly to the main body.
4. **Docking Station Installation (Optional):** Choose a suitable location near a power outlet. Secure the docking station to the wall using the provided screws and wall plugs. Ensure it is mounted at a height that allows the vacuum to hang freely.

Operating Modes

The Dyson V11 Extra features three power modes, selectable via the button on the LCD screen:

- **Eco Mode:** Provides the longest run time for lighter cleaning tasks on all floor types.
- **Med Mode (Auto Mode):** Offers an optimal balance of power and run time. When the High Torque cleaner head is attached, Auto mode intelligently adapts suction power between carpets and hard floors.
- **Boost Mode:** Delivers maximum suction power for intensive spot cleaning or heavily soiled areas. This mode will reduce run time significantly.

Features

- **Cordless Versatility:** Designed for whole-home deep cleaning without the restriction of a cord.
- **Digital Motor V11:** Powerful suction for effective cleaning on various surfaces.
- **LCD Screen:** Displays current performance, including selected power mode, remaining run time, and maintenance alerts (e.g., filter cleaning, blockage).
- **Whole-machine Filtration:** Captures 99.97% of microscopic dust particles, expelling cleaner air.
- **'Point and Shoot' Bin Emptying:** Hygienically ejects dust and debris deep into your bin in one action.

Attachments and Usage

The Dyson V11 Extra comes with several attachments for specialized cleaning tasks:

- **High Torque cleaner head:** Ideal for carpets and hard floors. Its Dynamic Load Sensor automatically adjusts suction power across different floor types.
- **Mini-motorized tool:** Designed for smaller spaces and pet hair on upholstery and stairs. Its anti-tangle brush bar prevents hair from wrapping around.
- **Combination tool:** A versatile tool with a wide nozzle and brush, suitable for quick switching between cleaning and dusting tasks on various surfaces.
- **Crevice tool:** For precise cleaning around edges and narrow gaps.
- **Extension hose:** Provides extra reach for cleaning high or low areas, or inside cars.
- **Up-top adapter:** Allows you to angle the vacuum for cleaning on top of high furniture or shelves.

Maintenance

1. **Emptying the Bin:** Empty the bin as soon as debris reaches the MAX level. Hold the vacuum over a bin and push the red lever to release the bin flap and eject contents.
2. **Washing the Filter:** The filter should be washed at least once a month. Twist the filter counter-clockwise from the main

body and wash it under cold water until the water runs clear. Allow to air dry completely for at least 24 hours before reattaching.

3. **Clearing Blockages:** If suction power drops or the LCD screen indicates a blockage, check the cleaner head, wand, and main body for obstructions.

Troubleshooting

Problem	Solution
No power / Not turning on	Ensure the battery is charged. Check charger connection.
Loss of suction	Check for blockages in the cleaner head, wand, or bin. Clean the filter. Empty the bin.
Brush bar not spinning	Clear any obstructions from the brush bar. Ensure the cleaner head is properly attached.
Flashing lights on LCD screen	Refer to the user manual for specific error codes or contact Dyson support.

Specifications

Brand: Dyson

Model Name: Dyson V11 Extra

Item Model Number: 419639-01

Special Feature: Bagless

Filter Type: Cartridge

Is Cordless?: Yes

Capacity: 0.2 Gallons

Runtime: 1 hour

Maximum Suction: 185 Inches

Recommended Uses: Carpets and Hard Floors, Upholstery

Form Factor: Handheld

Color: Nickel/Red

Product Dimensions: 49.4"L x 9.8"W x 10.3"H

Noise Level: 82 dB

Number of Speeds: 3

Portable: Yes

Indoor/Outdoor Usage: Indoor

Item Weight: 6.5 pounds

Batteries: 1 Lithium Ion batteries required (included)

Warranty and Support

The Dyson V11 Extra Cordless Vacuum Cleaner comes with a **2-year warranty**. For support, troubleshooting, or warranty claims, please visit the official Dyson website or contact Dyson customer service.
Lifetime Dyson support is available for this product.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C1TJ26X9

More documents and user manuals: **https://manuals.plus/**