Music Sound BTSWAGV

Music Sound SWAG Wireless Capsule Earphones Instruction Manual

Model: BTSWAGV

Introduction What's in the Box Setup Operating Maintenance Troubleshooting Specifications Warranty & Support

Introduction

Thank you for choosing Music Sound SWAG Wireless Capsule Earphones. These earphones are designed to provide a balanced sound experience and optimal comfort with their capsule design. Featuring Bluetooth connectivity, automatic pairing, and intuitive touch controls, they offer extended music playback. This manual will guide you through the setup, operation, and maintenance of your new earphones.



Image: Music Sound SWAG Wireless Capsule Earphones in Lilac, showcasing their sleek design.

What's in the Box

Please check the package contents to ensure all items are present:

- Music Sound SWAG Wireless Capsule Earphones
- Charging Case
- USB-C Charging Cable
- User Manual



Image: The package contents, showing the earphones, charging case, USB-C cable, and user guide.

Setup

1. Charging the Earphones and Case

Before first use, fully charge the earphones and the charging case.

1. Place the earphones into the charging case.
2. Connect the USB-C charging cable to the charging port on the case and plug the other end into a USB power source (e.g., computer, wall adapter).
3. The LED indicator on the case will show charging status. Once fully charged, the indicator will change or turn off.



Image: The compact charging case for the earphones.

2. Pairing with Your Device

The earphones feature automatic pairing for easy connection.

1. Ensure the earphones are charged and inside the charging case.
2. Open the charging case. The earphones will automatically enter pairing mode.
3. On your device (smartphone, tablet, laptop), go to the Bluetooth settings.
4. Search for available devices and select "Music Sound SWAG" from the list.
5. Once connected, you will hear a confirmation tone, and the earphones will be ready for use.
6. For subsequent uses, the earphones will automatically connect to the last paired device when removed from the case.

Operating Your Earphones

Touch Controls

The Music Sound SWAG earphones are equipped with intuitive touch controls on each earbud for managing music and calls.



Image: Illustration of the touch control area on the earphone and its associated functions (call, volume, play/pause, skip track).

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud.
- **Reject Call:** Press and hold either earbud for 2 seconds.
- **Activate Voice Assistant:** Triple tap on either earbud (functionality may vary by device).

Battery Life and Charging

The earphones provide up to 15 hours of total playback time with the charging case. A single charge offers approximately 4 hours of listening.



Image: Visual representation of the earphones' battery life, indicating 15 hours with the charging case and 4 hours on a single charge.

The charging case features an LED battery level indicator to show the remaining power. When the earphones are placed in the case, the LEDs will indicate their charging status.

Maintenance

To ensure the longevity and optimal performance of your Music Sound SWAG earphones, follow these maintenance guidelines:

- **Cleaning:** Regularly clean the earphones and charging case with a soft, dry, lint-free cloth. Do not use abrasive cleaners, alcohol, or chemical solvents.
- **Storage:** When not in use, store the earphones in their charging case to protect them from dust and damage.
- **Water Resistance:** These earphones are not water-resistant. Avoid exposure to water, moisture, or extreme temperatures.
- **Charging:** Use only the provided USB-C cable or a certified equivalent for charging.

Troubleshooting

If you encounter any issues with your earphones, please refer to the following common solutions:

Problem	Solution
Earphones not pairing	Ensure earphones are charged. Turn off and on Bluetooth on your device. Forget "Music Sound SWAG" from your device's Bluetooth list and try pairing again. Place earphones back in the case, close it, wait a few seconds, then open to re-enter pairing mode.
No sound from one earbud	Ensure both earbuds are charged. Try resetting the earphones (refer to manual for specific reset instructions if available, otherwise try re-pairing). Clean the charging contacts on both the earbud and the case.
Low volume	Adjust the volume on both your device and the earphones (if touch controls support volume). Ensure the earphones are properly seated in your ears. Clean any debris from the earphone speakers.
Earphones not charging	Ensure the charging cable is securely connected. Try a different USB power source or cable. Clean the charging contacts on the earphones and inside the case.

Specifications

Key technical specifications for your Music Sound SWAG Wireless Capsule Earphones:

- **Model Name:** BTSWAGV
- **Brand:** Music Sound
- **Color:** Lilac
- **Ear Placement:** In-ear
- **Form Factor:** True Wireless (Capsule)
- **Noise Control:** Sound Isolation
- **Connectivity Technology:** Wireless (Bluetooth)
- **Bluetooth Version:** 5.0
- **Battery Life (Earphones):** Approximately 4 hours (single charge)
- **Total Playtime (with Charging Case):** Up to 15 hours
- **Frequency Range:** 20 Hz - 20,000 Hz
- **Control Method:** Touch
- **Material:** Plastic
- **Water Resistance Level:** Not water-resistant
- **Compatible Devices:** Mobile phones, Laptops, Tablets

Warranty and Support

Warranty Information

Your Music Sound SWAG Wireless Capsule Earphones come with a**2-year manufacturer's warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.
The warranty does not cover damage caused by misuse, accidents, unauthorized modifications, or exposure to water.

Customer Support

For further assistance, technical support, or warranty inquiries, please visit the official Music Sound website or contact their customer service. You can also refer to the Music Sound Store on Amazon for more information.

Product Video

Watch the official product video for an overview of the Music Sound SWAG Wireless Capsule Earphones.

Your browser does not support the video tag.

Video: An official product video showcasing the features and design of the Music Sound SWAG Wireless Capsule Earphones. (Note: Actual video URL was not provided in the input, a placeholder is used.)

© 2026 Music Sound. All rights reserved.