OSOTEK H200 Lite

OSOTEK H200 Lite 3-in-1 Cordless Wet Dry Vacuum Cleaner User Manual

Model: H200 Lite | Brand: OSOTEK

1. Introduction

Thank you for choosing the OSOTEK H200 Lite 3-in-1 Cordless Wet Dry Vacuum Cleaner. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read this manual thoroughly before first use and keep it for future reference.

2. Safety Instructions

To reduce the risk of fire, electric shock, or injury, always follow basic safety precautions when using an electrical appliance. This includes:

- Read all instructions before using the appliance.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not immerse the appliance in water or other liquids.
- Do not handle the charger or appliance with wet hands.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Exercise extra care when cleaning on stairs.
- Always turn off the appliance before connecting or disconnecting the motorized nozzle.
- Store the appliance indoors in a cool, dry place.

3. Package Contents

Ensure all items are present in the package:

- 1 x OSOTEK H200 Lite Vacuum Cleaner
- 1 x Roller Brush (integrated)
- 1 x Filter
- 1 x OSOTEK Floor Cleaning Detergent
- 1 x Cleaning Tool
- 1 x Power Adapter
- 1 x Charging Station
- 1 x Warranty Card
- 1 x User Manual



Figure 3.1: Included Components. This image displays the OSOTEK H200 Lite vacuum cleaner along with its accessories: the base station, power adapter, integrated roller brush, filter, cleaning brush, and a bottle of cleaning solution.

4. Product Overview

The OSOTEK H200 Lite is a versatile 3-in-1 cordless wet and dry vacuum cleaner designed for efficient hard floor cleaning. Key features include:

- **3-in-1 Functionality:** Vacuums, mops, and washes simultaneously.
- **180° Flat Design:** Allows the vacuum to lay nearly flat, reaching deep under furniture like sofas and beds for thorough cleaning.
- **Powerful Suction:** Equipped with a motor providing 12500 Pa suction power for effective dirt and dust removal.
- **Anti-Tangle Roller Brush:** Innovative brush design minimizes hair tangles, ideal for pet owners.
- **Dual-Sided Edge Cleaning:** Effectively cleans along baseboards and into corners.
- **Smart LED Display:** Provides real-time information on battery status, cleaning modes, and error indicators for simplified operation.
- **Self-Cleaning Function:** Automatic self-cleaning cycle for the roller brush after use, activated with a single button press.
- **Multiple Cleaning Modes:** Includes Standard, Turbo, and Water Absorption modes.
- **Cordless Operation:** Powered by a Lithium-ion battery, offering up to 30 minutes of runtime.



Figure 4.1: 180° Flat Design for Easy Cleaning Under Furniture. The image shows the OSOTEK H200 Lite vacuum cleaner positioned almost flat to clean under a sofa, highlighting its ability to reach difficult areas.



Figure 4.2: Edge-to-Edge Cleaning. This image focuses on the vacuum's brush head, demonstrating its design that allows for thorough cleaning right up to walls and edges.



Figure 4.3: Anti-Tangle Roller Brush Design. A cutaway view of the brush head illustrates the innovative design that prevents hair from tangling around the roller, ensuring consistent cleaning performance.



Figure 4.4: Smart Display for Simpler Operation. This image highlights the vacuum's LED display, which shows the current cleaning mode (Standard, Turbo, Self-cleaning, Water Absorption), battery percentage, and any error indicators.

5. Setup

5.1 Assembly

1. Carefully unpack all components from the box.
2. Insert the handle into the main body of the vacuum cleaner until it clicks securely into place.
3. Place the vacuum cleaner onto the charging station.

5.2 Initial Charging

1. Connect the power adapter to the charging station and plug it into a wall outlet.
2. Ensure the vacuum cleaner is correctly seated on the charging station. The LED display will indicate charging status.
3. Charge the appliance fully before first use. A full charge takes approximately 4 hours.

5.3 Filling the Clean Water Tank

1. Remove the clean water tank (750ml capacity) from the main body of the vacuum.
2. Open the tank cap and fill with clean tap water. You may add a small amount of OSOTEK cleaning detergent as per instructions on the detergent bottle. Do not overfill.
3. Securely close the tank cap and reinsert the clean water tank into the vacuum cleaner until it clicks.



Figure 5.1: Water Tank Capacities and Runtime. This diagram shows the 750ml clean water tank and 640ml dirty water tank, along with the 30-minute battery runtime, indicating sufficient capacity for home cleaning.

6. Operating Instructions

6.1 Powering On/Off

- To turn on, press the Power button located on the handle.
- To turn off, press the Power button again. The vacuum will automatically turn off if left upright for a few seconds.

6.2 Selecting Cleaning Modes

Press the Mode button on the handle to cycle through the available cleaning modes:

- **Standard Mode:** For everyday cleaning of light dirt and spills.
- **Turbo Mode:** Provides maximum suction power for stubborn dirt and heavy messes.
- **Water Absorption Mode:** For quickly drying wet surfaces or picking up liquid spills without scrubbing.

6.3 Cleaning Operation

1. Tilt the vacuum cleaner back to engage the roller brush and start cleaning. The motorized traction will assist in movement.
2. Move the vacuum slowly over the desired area, allowing the wet and dry functions to work effectively.
3. For cleaning under low furniture, gently push the handle down to utilize the 180° flat design.
4. The dual-sided edge cleaning feature ensures thorough cleaning along walls and in corners.



Figure 6.1: Meets All Your Cleaning Needs. This image illustrates the vacuum cleaner being used in various household environments such as the living room, bathroom, kitchen, and bedroom, showcasing its adaptability for different cleaning tasks.



Figure 6.2: Effortless Motorized Traction. The image shows a user easily maneuvering the vacuum cleaner, with visual cues indicating the motorized assistance that reduces user effort during cleaning.

7. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your OSOTEK H200 Lite.

7.1 Self-Cleaning Function

1. After each use, place the vacuum cleaner back on the charging station.
2. Ensure there is sufficient clean water in the clean water tank.
3. Press the Self-Cleaning button (indicated on the LED display) to initiate the automatic cleaning cycle. The roller brush will be rinsed and spun dry.
4. The self-cleaning cycle typically lasts for a few minutes.



Figure 7.1: Self-Cleaning Technology. This image provides an internal view of the vacuum's self-cleaning system, illustrating how water is circulated to clean the roller brush automatically.

7.2 Emptying and Cleaning the Dirty Water Tank

1. After each use or when the dirty water tank (640ml capacity) is full, remove it from the vacuum cleaner.
2. Carefully open the tank and dispose of the dirty water.
3. Rinse the dirty water tank and its filter thoroughly with clean water. Allow it to air dry completely before reassembling.

7.3 Cleaning the Roller Brush

- Even with the self-cleaning function, it is recommended to periodically remove and manually clean the roller brush.
- Use the provided cleaning tool to remove any tangled hair or debris from the brush.
- Rinse the roller brush under running water and allow it to air dry completely before reinstalling.

7.4 Cleaning/Replacing the Filter

- The foam filter located in the dirty water tank should be rinsed regularly.

- Allow the filter to dry completely before placing it back into the tank.
- Replace the filter every 3-6 months, or as needed, to maintain optimal suction and air quality.

8. Troubleshooting

If you encounter issues with your OSOTEK H200 Lite, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Vacuum does not turn on	Battery is low or depleted.	Charge the vacuum fully (approx. 4 hours).
Poor suction power	Dirty water tank is full. Filter is clogged. Roller brush is tangled.	Empty and clean the dirty water tank. Clean or replace the filter. Clean the roller brush.
Water leakage	Clean/dirty water tank not properly installed. Tank cap not sealed.	Ensure tanks are securely clicked into place and caps are tightly sealed.
Self-cleaning not working	Insufficient clean water. Vacuum not properly on charging station.	Fill clean water tank. Ensure vacuum is correctly seated on the charging station.
LED display shows an error	Specific error condition (e.g., brush jam, water tank issue).	Refer to the LED display for the specific error code and consult the full manual or contact support.

9. Specifications

Feature	Specification
Model Number	H200 Lite
Brand	OSOTEK
Product Dimensions (L x W x H)	99.06 x 27.94 x 17.78 cm (39 x 11 x 7 inches)
Item Weight	9.42 Kilograms (20.77 lbs)
Clean Water Tank Capacity	750 Milliliters
Dirty Water Tank Capacity	640 Milliliters
Runtime	Up to 30 minutes
Charging Time	Up to 4 hours
Maximum Suction	12500 Pa
Power Source	Battery Powered (1 Lithium-ion battery included)
Filter Type	Foam
Surface Recommendation	Hard Floor

Feature	Specification
Special Features	180° Flexible Brush Head Rotation, 2-Sided Edge Cleaning, LED Display, 3 Cleaning Modes, Vacuum & Mop in One, One-Button Self-Cleaning, Pet Brush

10. Warranty and Support

Your OSOTEK H200 Lite comes with a warranty. Please refer to the included Warranty Card for detailed terms and conditions, including the warranty period and coverage.
For technical support, troubleshooting assistance beyond this manual, or to inquire about replacement parts, please contact OSOTEK customer service. Contact information can typically be found on the warranty card or the official OSOTEK website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question