GuliKit ZEN PRO

GuliKit ZEN PRO Wireless Gaming Controller User Manual

Model: ZEN PRO

1. Introduction

Thank you for choosing the GuliKit ZEN PRO Wireless Gaming Controller. This manual provides detailed instructions for setting up, operating, and maintaining your controller. The ZEN PRO is designed for multi-platform compatibility, supporting Nintendo Switch, PC (Xinput/Dinput), Android, iOS, and macOS devices. Please read this manual carefully to ensure optimal performance and longevity of your device.

2. Product Overview

2.1 Package Contents

- GuliKit ZEN PRO Wireless Gaming Controller
- USB-C Charging Cable
- User Manual

2.2 Controller Layout

The GuliKit ZEN PRO controller features a standard ergonomic layout with precise controls for an enhanced gaming experience.



Image: Front view of the GuliKit ZEN PRO Wireless Gaming Controller, showcasing its black finish, dual analog sticks, D-pad, A/B/X/Y buttons, and central function buttons.



Image: Close-up of the left analog stick on the GuliKit ZEN PRO controller, highlighting its textured cap and linear Hall sensing technology.



Image: Close-up of the A, B, X, Y action buttons on the GuliKit ZEN PRO controller, showing their clear labels and ergonomic placement.

3. Setup and Connection

3.1 Charging the Controller

Connect the supplied USB-C cable to the charging port on the controller and the other end to a USB power source (e.g., a computer USB port, a wall adapter). The controller's indicator light will show charging status. A full charge provides up to 25 hours of gameplay.

3.2 Pairing with Nintendo Switch

1. On your Nintendo Switch, go to the HOME Menu.
2. Select 'Controllers' > 'Change Grip/Order'.
3. Press and hold the pairing button on the GuliKit ZEN PRO controller until the indicator lights begin to flash.
4. Once paired, the controller will be recognized by the Switch, and the player indicator light(s) will illuminate steadily.
5. The controller supports Switch console wake-up functionality.

3.3 Pairing with PC (Windows - Xinput/Dinput)

1. Ensure your PC has Bluetooth enabled.
2. On your PC, go to 'Settings' > 'Devices' > 'Bluetooth & other devices'.
3. Select 'Add Bluetooth or other device' > 'Bluetooth'.

4. Press and hold the pairing button on the GuliKit ZEN PRO controller until the indicator lights begin to flash.
5. Select 'GuliKit ZEN PRO' from the list of available devices to pair.
6. The controller will automatically detect Xinput or Dinput mode based on the game or application.

3.4 Pairing with Android/iOS/macOS

1. Enable Bluetooth on your Android, iOS, or macOS device.
2. Go to the Bluetooth settings on your device.
3. Press and hold the pairing button on the GuliKit ZEN PRO controller until the indicator lights begin to flash.
4. Select 'GuliKit ZEN PRO' from the list of available devices to pair.

4. Operating Instructions

4.1 AI Key Functionality

The special AI Key allows you to record and replay up to 10 minutes of operations. This feature is useful for automating repetitive in-game actions or executing complex sequences with a single press.

- **To Record:** Press and hold the AI Key until the indicator light changes (refer to controller LED guide for specific indication). Perform your desired actions. Press the AI Key again to stop recording.
- **To Play:** Briefly press the AI Key to execute the recorded sequence.

4.2 Vibration Adjustment

The GuliKit ZEN PRO features dual vibration motors with four adjustable intensity levels, including an option for no vibration. Adjustments can be made directly on the controller without external software.

- Consult the controller's specific button combination (e.g., Function button + D-pad Up/Down) to cycle through vibration levels.

4.3 Rapid Fire Settings

The controller supports semi-auto and auto rapid fire for the A-B-X-Y buttons. This allows for quick, repeated inputs by holding down a button.

- Specific button combinations are used to activate and cycle through rapid fire modes for individual buttons. Refer to the quick start guide for these combinations.

4.4 Automatic Shutdown

To conserve battery, the controller will automatically shut down if there is no button action for 10 minutes while connected wirelessly.

5. Maintenance

5.1 Cleaning

Use a soft, dry cloth to clean the controller's surface. For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive materials, as these can damage the controller's finish and internal components.

5.2 Storage

Store the controller in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, ensure the controller is fully charged to maintain battery health.

6. Troubleshooting

6.1 Controller Not Pairing

- Ensure the controller is sufficiently charged.
- Verify that Bluetooth is enabled on your device (Switch, PC, Android, iOS).
- Make sure the controller is in pairing mode (indicator lights flashing).
- Try resetting the controller by pressing the gear button and the minus (-) button simultaneously.
- Remove any previous pairings of the controller from your device's Bluetooth settings and attempt to pair again.
- If connecting to Switch, ensure you are in the 'Change Grip/Order' menu.

6.2 Buttons Not Responding or Sticking

- Perform a controller reset as described above.
- Ensure the controller's firmware is up to date (check the GuliKit official website for updates).
- Clean around the affected buttons with a soft, dry cloth to remove any debris.
- If the issue persists, contact GuliKit customer support.

6.3 Rumble Sticking

- Try adjusting the vibration intensity to a different level.
- Reset the controller.
- If the rumble motor continues to stick, this may indicate a hardware issue.

7. Specifications

- **Model:** ZEN PRO
- **Connectivity:** Wireless (Bluetooth), Wired (USB-C)
- **Compatibility:** Nintendo Switch, PC (Xinput/Dinput), Android, iOS, macOS
- **Joystick Technology:** Linear Hall Sensing (Electromagnetic Stick)
- **Special Features:** AI Key (Macro Recording), Adjustable Vibration, Rapid Fire, Six-axis Gyroscope
- **Battery Life:** Up to 25 hours (approx.)
- **Dimensions:** 7.24 x 5.28 x 3.86 inches (Package)
- **Weight:** 13.4 ounces (Item)
- **Manufacturer:** GuliKit
- **First Available:** April 15, 2023

8. Warranty and Support

For warranty information and technical support, please refer to the documentation included with your purchase or visit the official GuliKit website. Warranty terms and conditions may vary by region and retailer.

For the latest firmware updates and additional support resources, please visit:www.gulikit.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question