Jectse Jectse6eao57zprw

Jectse HD 1080P WiFi Body Camera User Manual

Model: Jectse6eao57zprw

IMPORTANT SAFETY INFORMATION

Please read all safety warnings and instructions carefully before using this product. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Keep the device away from water and moisture.
- Do not attempt to disassemble or repair the device yourself. Refer all servicing to qualified personnel.
- Use only the specified charging voltage (DC 5V) and Type-C cable.
- Avoid exposing the device to extreme temperatures (hot or cold) or direct sunlight.
- Do not block the microphone hole or lens during operation.
- Dispose of the battery and device according to local regulations.

PRODUCT OVERVIEW

The Jectse HD 1080P WiFi Body Camera is a compact and versatile video recorder designed for personal security and documentation. It features a 1080P HD image sensor, 180-degree rotatable lens, built-in WiFi hotspot for real-time viewing, and one-button operation for ease of use. Its compact design with a back clip allows for convenient portability.

Image: The Jectse HD 1080P WiFi Body Camera shown alongside its USB Type-C charging cable.

Key Features

Image: Visual representation of the camera's main features including HD recording, video mode, WiFi hotspot, photo mode, voice recording, infrared night vision, long battery life, and motion detection.

- **HD 1080P Image Sensor:** Equipped with a high-definition sensor for clear image quality.

- **Built-in WiFi Hotspot:** Connect to a mobile app for real-time video playback and control.

- **Compact Back Clip Design:** Easily attach to clothing for portable use.

- **180-Degree Rotatable Lens:** Adjust the lens angle for flexible recording.

- **One-Button Operation:** Simple controls for recording video, taking photos, and voice recording.

- **HD Noise Cancelling:** Advanced microphone technology for clearer audio.

- **Infrared Night Vision:** Capable of recording in low-light conditions without auxiliary lights.

- **Extended Battery Life:** Approximately 5 hours of continuous recording.

- **Expandable Storage:** Supports up to 256GB small memory card (TF card, not included).

Components and Controls

① HD lens
② WiFi indicator light
③ Flip indicator light
④ Recording indicator light
⑤ Photo indicator light
⑥ Recording indicator light
⑦ Night vision indicator light
⑧ Charging indicator light
⑨ Flip key
⑩ Voice recording button
⑪ Night vision key
⑫ TF card slot
⑬ Microphone hole
⑭ Video recording button
⑮ Photo button
⑯ Power button

Image: Detailed diagram illustrating the various parts and controls of the body camera, including the lens, indicators, buttons, and ports.

No.	Component/Control
1	HD lens
2	WiFi indicator light
3	Flip indicator light
4	Recording indicator light
5	Photo indicator light
6	Recording indicator light
7	Night vision indicator light
8	Charging indicator light
9	Flip key
10	Voice recording button
11	Night vision key
12	TF card slot
13	Microphone hole
14	Video recording button
15	Photo button
16	Power button

SETUP

1. Charging the Device

Before first use, fully charge the body camera. Connect the provided Type-C USB cable to the camera's Type-C interface and the other end to a DC 5V power source (e.g., computer USB port, USB wall adapter). The charging indicator light (8) will illuminate during charging and turn off when fully charged. A full charge provides approximately 5 hours of continuous recording.

2. Inserting/Removing Memory Card

The camera supports small memory cards (TF cards) up to 256GB (not included). Locate the TF card slot (12) on the side of the camera. Gently insert the memory card with the gold contacts facing down until it clicks into place. To remove, push the card in slightly until it springs out.

Note: Ensure the device is powered off before inserting or removing the memory card to prevent data loss or damage.

3. Initial Setup and App Connection (WiFi)

The camera features a built-in WiFi hotspot for real-time viewing and control via a mobile application. Follow these steps to connect:

1. Power on the camera by pressing and holding the Power button (16).
2. On your phone or tablet, go to your WiFi settings.
3. Search for a WiFi network named "CS05" (e.g., CS05 CE01) and connect to it.
4. Once connected, open the "Sports Camera" application on your mobile device.
5. From the main interface of the app, enter the real-time preview interface. You can now view live footage and control recording/photo functions from the app, or continue to use the physical buttons on the camera.

Built-in WIFI
Connected to the cell phone APP, and supports real time video playback

Image: Illustration of the camera's built-in WiFi functionality, allowing connection to a smartphone app for real-time video playback.

OPERATING INSTRUCTIONS

1. Power On/Off

- **Power On:** Press and hold the Power button (16) until the indicator lights illuminate.
- **Power Off:** Press and hold the Power button (16) again until the indicator lights turn off.

2. Video Recording

The camera supports 1080P video recording.

- **Start Recording:** Press the Video recording button (14) once. The recording indicator light (4) will flash to indicate recording is in progress.
- **Stop Recording:** Press the Video recording button (14) again. The recording indicator light will stop flashing.

3. Photo Capture

Capture still images with a single press.

- **Take Photo:** Press the Photo button (15) once. The photo indicator light (5) will flash briefly.

4. Voice Recording

Record audio only using the dedicated voice recording function.

- **Start Voice Recording:** Press the Voice recording button (10) once. The recording indicator light (6) will illuminate.
- **Stop Voice Recording:** Press the Voice recording button (10) again. The recording indicator light will turn off.

Image: Visual guide to the camera's one-key control system, highlighting the buttons for starting video recording, taking photos, and voice recording.

5. 180-Degree Lens Rotation

The camera lens can be manually rotated up to 180 degrees to capture footage from various angles (forward, backward, upward). Adjust the lens (1) to your desired orientation before recording.

Image: Diagram demonstrating the camera's 180-degree rotatable lens, showing how it can be adjusted for different recording perspectives.

6. Night Vision

The camera is equipped with infrared night vision for recording in low-light or dark environments without the need for external illumination.

- **Activate Night Vision:** Press the Night vision key (11) once. The night vision indicator light (7) will illuminate.
- **Deactivate Night Vision:** Press the Night vision key (11) again. The night vision indicator light will turn off.

Image: A split image demonstrating the effectiveness of HD infrared night vision, showing a scene in normal light and the same scene clearly visible in darkness.

7. Using the Back Clip

The integrated back clip allows for convenient attachment to clothing, such as a jacket pocket, making it easy to carry and record discreetly.

Image: The compact body camera shown clipped into the breast pocket of a suit jacket, demonstrating its portable and discreet design.

MAINTENANCE

Cleaning

To maintain the performance and appearance of your camera:

- Wipe the camera body with a soft, dry cloth.
- For the lens, use a specialized lens cleaning cloth and solution to avoid scratches.
- Do not use harsh chemicals, cleaning solvents, or strong detergents.

Storage

When not in use, store the camera in a cool, dry place, away from direct sunlight and extreme temperatures. Ensure the battery is partially charged (around 50%) if storing for extended periods to prolong battery life.

TROUBLESHOOTING

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Camera does not power on.	Low battery.	Charge the camera fully.
Cannot connect to WiFi hotspot.	Incorrect WiFi name selected; camera WiFi not active.	Ensure the camera is powered on and its WiFi hotspot is active. Select the correct "CS05" network.
Recording stops unexpectedly.	Memory card full; low battery.	Check memory card storage and delete unnecessary files or replace card. Charge the camera.
Video playback issues.	Corrupted file; incompatible playback software.	Try playing on a different device or using standard video playback software. Ensure memory card is not corrupted.
Poor image/video quality.	Dirty lens; insufficient lighting (if night vision is off).	Clean the lens. Activate night vision in low-light conditions.

SPECIFICATIONS

Feature	Specification
Product Type	WiFi Body Camera
Material	Plastic
Video Resolution	1920x1080P
Video Encoding	M-JPEG
Video Format	AVI
Image Ratio	16:9
Recording Format	WAV
Battery Capacity	3.7V 1000mAh Lithium Battery (Built-in)
Working Time	Approx. 5 hours continuous recording
Lens Adjustment	180-degree rotation
Storage Support	Up to 256GB small memory card (TF card, not included)
Interface Type	Type-C
Charging Voltage	DC 5V
Playback Software	System comes with conventional sound and video playback software

Feature	Specification
Dimensions (Package)	13 x 9 x 5 cm
Weight (Package)	165 g
Model Number	Jectse6eao57zprw

WARRANTY AND SUPPORT

Jectse is committed to providing high-quality products and customer service. While specific warranty details are not provided in this manual, please retain your proof of purchase for any warranty claims.

For further assistance, technical support, or inquiries, please visit the official Jectse brand store or contact their customer service through the platform where you purchased the product.

You can visit the Jectse store here: Jectse Official Store