Anchilly Door Switch Button

Anchilly Door Switch Button Instruction Manual

For Galanz Microwave Oven Models WD800T, WP750, WD800B

1. Product Overview

The Anchilly Door Switch Button is a replacement component designed for specific Galanz Microwave Oven models. This switch plays a crucial role in the microwave's safety interlock system, ensuring the appliance operates only when the door is securely closed. It is engineered for durability and reliability, providing a straightforward solution for common microwave door-related issues.

1.1 Key Features

- **Compatibility:** Specifically designed to fit Galanz Microwave Oven models WD800T, WP750, and WD800B.
- **Durable Construction:** Manufactured from high-quality materials to ensure long-lasting performance and reliability.
- **Easy Installation:** Engineered for simple and direct replacement, facilitating a quick repair process.
- **Functionality Restoration:** Helps resolve issues such as the microwave not starting, the light remaining on when the door is closed, or improper door latching.

1.2 Product Views




Figure 1: Side view of the Anchilly Door Switch Button, showing its general shape and mounting points.



Figure 2: Angled perspective of the Anchilly Door Switch Button, highlighting its structural design and brace hook.

2. Installation Guide

Important Safety Notice: Before attempting any repair or replacement on a microwave oven, ensure the appliance is unplugged from the power outlet. Microwave ovens contain high-voltage capacitors that can store a lethal electrical charge even after being unplugged. It is highly recommended that this procedure be performed by a qualified technician. If you are not comfortable with electrical repairs, please seek professional assistance.

2.1 Required Tools

- Screwdriver set (Phillips and/or flathead, depending on microwave model)
- Needle-nose pliers (optional, for wire connections)
- Multimeter (for testing, recommended for technicians)

2.2 Replacement Steps

1. **Disconnect Power:** Unplug the microwave oven from the wall outlet.
2. **Access the Switch:** Carefully remove the outer casing of the microwave oven. This usually involves unscrewing screws on the back and sides. Consult your microwave's specific service manual for exact instructions on casing

removal.

3. **Locate the Old Switch:** Identify the faulty door switch. Microwave ovens typically have multiple door switches (primary, secondary, and monitor switches). The door switch button is usually associated with the primary or secondary switch that the door latch engages.
4. **Discharge Capacitor (Critical Safety Step):** If you are a qualified technician, safely discharge the high-voltage capacitor using a properly insulated tool. **Do not skip this step.**
5. **Disconnect Wires:** Carefully disconnect the electrical wires from the old door switch. Note their positions or take a photo before disconnecting to ensure correct re-connection.
6. **Remove Old Switch:** Unclip or unscrew the old door switch from its mounting bracket.
7. **Install New Switch:** Insert the new Anchilly Door Switch Button into the mounting bracket, ensuring it clicks securely into place.
8. **Reconnect Wires:** Reconnect the electrical wires to the new switch in the exact same configuration as they were on the old switch.
9. **Test (Before Reassembly):** With extreme caution, and ensuring no body parts are near internal components, plug the microwave back in briefly to test the switch functionality. The microwave should not start with the door open, and should start when closed and a cooking cycle is initiated. If it functions correctly, unplug it again.
10. **Reassemble:** Carefully reattach the outer casing of the microwave oven, ensuring all screws are tightened.
11. **Final Test:** Plug the microwave back into the outlet and perform a final functional test.

3. Operation

The Anchilly Door Switch Button is an integral part of the microwave oven's safety interlock system. It operates passively by being engaged or disengaged by the microwave door's latch mechanism. When the microwave door is closed, the latch presses against the switch, completing an electrical circuit that allows the microwave to operate. When the door is opened, the switch disengages, breaking the circuit and preventing the microwave from starting or immediately stopping any ongoing operation. This ensures user safety by preventing microwave radiation leakage while the door is open.

4. Maintenance

The Anchilly Door Switch Button is designed for long-term reliability and typically requires minimal maintenance. However, regular inspection can help prolong its lifespan and ensure continued safe operation of your microwave oven.

- **Keep Clean:** Ensure the area around the door latch and switch is free from food debris or spills, which could impede the switch's movement.
- **Inspect for Wear:** Periodically, if the microwave casing is open for other maintenance, visually inspect the switch for any signs of physical damage, cracks, or excessive wear on the plastic components.
- **Gentle Use:** Always close the microwave door gently. Slamming the door can put undue stress on the door switches and latch mechanism, potentially leading to premature failure.

5. Troubleshooting

If your microwave oven is exhibiting symptoms related to the door switch, the Anchilly Door Switch Button may be the necessary replacement. Below are common issues that a faulty door switch can cause:

- **Microwave Does Not Start:** If the microwave does not power on or start a cooking cycle when the door is closed, a faulty door switch may be preventing the circuit from completing.
- **Light Stays On:** If the interior light of the microwave remains on even when the door is fully closed, it could indicate that a door switch is not disengaging properly.
- **Intermittent Operation:** The microwave may start and stop unexpectedly, or require jiggling the door to operate,

suggesting a loose or failing door switch connection.

- **Fuse Blowing:** In some cases, a shorted monitor switch (a type of door switch) can cause the microwave's internal fuse to blow.

If you experience any of these issues, and after ensuring the microwave is unplugged, a visual inspection of the door switch button for physical damage or proper engagement with the door latch is recommended. If the switch appears damaged or does not click reliably, replacement is likely required.

6. Specifications

The Anchilly Door Switch Button is designed to meet the functional requirements for compatible Galanz microwave models. Its dimensions are critical for proper fit and function.

- **Manufacturer:** Anchilly
- **Part Type:** Microwave Door Switch Button / Brace Hook
- **Compatibility:** Galanz Microwave Oven models WD800T, WP750, WD800B
- **Material:** High-quality durable plastic

6.1 Dimensions




Figure 3: Detailed dimensions of the Anchilly Door Switch Button. Please verify these measurements against your existing part for accurate fitment.

- **Overall Length:** Approximately 8.8 cm
- **Overall Height (including hooks):** Approximately 3.6 cm
- **Main Body Width:** Approximately 6.4 cm
- **Main Body Height:** Approximately 2.2 cm
- **Top Brace Length:** Approximately 6.8 cm
- **Top Brace Height:** Approximately 2.1 cm

7. Warranty and Support

For specific warranty information regarding your Anchilly Door Switch Button, please refer to the purchase documentation

or contact the seller directly. Warranty terms typically cover manufacturing defects for a specified period from the date of purchase.

7.1 Customer Support

If you require further assistance with installation, troubleshooting, or have questions about the product, please contact the seller, Parts-Access Store, through the platform where the purchase was made. Provide your order details for prompt support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question