Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Vicloon A380

Vicloon Kids Digital Watch Model A380 User Manual

Your guide to operating and maintaining your new digital watch.

1. Introduction

Thank you for choosing the Vicloon Kids Digital Watch Model A380. This watch is designed for children aged 3-10, featuring a fun cartoon design, a comfortable silicone strap, and multiple functions including a 7-color LED backlight, stopwatch, alarm, and calendar. This manual will guide you through the setup, operation, and maintenance of your watch to ensure optimal performance and enjoyment.

2. Product Features

The Vicloon Kids Digital Watch Model A380 comes equipped with several features to enhance usability and fun:

- **Digital Time Display:** Clear and easy-to-read digital time.
- **7-Color LED Backlight:** Press the LIGHT button to illuminate the display with various colors, making it easy to read in the dark.
- **Stopwatch Function:** Perfect for timing activities and games.
- **Alarm Clock:** Set a daily alarm to help with routines.
- **Calendar Display:** Shows the current date.
- **12/24 Hour Format:** Option to switch between 12-hour (AM/PM) and 24-hour time formats.
- **30M Water Resistance:** Suitable for daily use like hand washing and rain splashes (not for swimming or showering).
- **Durable & Comfortable:** High-quality silicone strap and high-transparency resin glass for durability and comfort.



Image: Overview of the watch's multi-functional capabilities, including calendar, night lights, stopwatch, 7 colors of light, 30m waterproof, alarm clock, and 12/24 hour format.

3. Setup and Basic Operation

3.1 Button Identification

Familiarize yourself with the watch buttons:



Image: Close-up view of the watch face highlighting the multifunction buttons and digital display. The buttons are labeled LIGHT (top left), MODE (bottom left), START (top right), and RESET (bottom right).

- **LIGHT (Top Left):** Activates the 7-color LED backlight.
- **MODE (Bottom Left):** Cycles through time display, alarm setting, and stopwatch modes. Used to select setting items.
- **START (Top Right):** Starts/stops the stopwatch. Used to adjust values during setting.
- **RESET (Bottom Right):** Resets the stopwatch. Used to confirm settings or move to the next setting item.

3.2 Setting Time and Date

1. From the normal time display, press the **MODE** button three times. The seconds will start flashing.
2. Press the **RESET** button to move to the next setting item (hours, minutes, month, date, day of the week).
3. While an item is flashing, press the **START** button to adjust its value.
4. To switch between 12-hour and 24-hour format, when the hour is flashing, press **START** until 'A' (AM) or 'P' (PM) appears for 12-hour format, or 'H' for 24-hour format.
5. Once all settings are correct, press the **MODE** button to return to the normal time display.

4. Operating Instructions

4.1 Using the LED Backlight

Press the **LIGHT** button (top left) at any time to illuminate the display. The backlight will cycle through 7 different colors each time it is activated, or display a single color for a few seconds before turning off automatically.

4.2 Using the Stopwatch

1. From the normal time display, press the **MODE** button once to enter stopwatch mode. The display will show "00:00:00".
2. Press the **START** button to begin timing.
3. Press the **START** button again to pause timing.
4. Press the **START** button again to resume timing.
5. While the stopwatch is paused, press the **RESET** button to reset the stopwatch to "00:00:00".
6. Press the **MODE** button to exit stopwatch mode and return to the normal time display.

4.3 Setting and Using the Alarm

1. From the normal time display, press the **MODE** button twice to enter alarm setting mode. The hour digits will flash.
2. Press the **START** button to adjust the alarm hour.
3. Press the **RESET** button to move to the minute digits, which will flash.
4. Press the **START** button to adjust the alarm minutes.
5. Press the **MODE** button to exit alarm setting mode.
6. To turn the alarm ON/OFF: In normal time display, press and hold the **RESET** button, then press the **START** button. An alarm icon will appear/disappear to indicate ON/OFF status.
7. When the alarm sounds, press any button to stop it.

5. Maintenance

5.1 Water Resistance

Your Vicloon Kids Digital Watch is rated **30 meters (3ATM) water-resistant**. This means it is suitable for daily use, such as accidental splashes, rain, and hand washing. However, it is **NOT suitable for showering, bathing, swimming, or diving**. Exposure to hot water or steam can damage the watch's seals.



Image: Illustration of the watch's 30M water resistance, showing it can withstand splashes and rain but explicitly states "NO shower" and "NO swim".

5.2 Cleaning and Care

- Wipe the watch with a soft, dry cloth to remove dirt and moisture.
- For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying.
- Avoid using chemical cleaners, solvents, or abrasive materials, as these can damage the watch's finish and seals.
- Keep the watch away from extreme temperatures, direct sunlight for prolonged periods, and strong magnetic fields.

5.3 Battery Replacement

The watch uses a standard button cell battery. When the display becomes dim or functions become erratic, it may be time to replace the battery. It is recommended to have the battery replaced by a qualified watch technician to ensure the water resistance seal is properly maintained.

6. Troubleshooting

Problem	Possible Cause	Solution
Display is blank or dim.	Low battery.	Replace the battery.
Time is incorrect.	Time not set correctly or accidentally changed.	Reset the time and date as per Section 3.2.
Buttons are unresponsive.	Low battery or internal malfunction.	Try replacing the battery. If the issue persists, contact customer support.
Water inside the watch.	Exceeded water resistance limits (e.g., swimming, showering).	Stop using the watch immediately. Seek professional repair; water damage is typically not covered by warranty.

7. Specifications

Model Number	A380
Display Type	Digital
Movement Type	Automatic (Digital Quartz)
Case Material	Resin
Band Material	Silicone
Dial Window Material	Mineral Glass
Water Resistance Depth	30 Meters (3ATM)
Power Source	Battery Powered
Package Dimensions	23.09 x 4.5 x 1.5 cm
Item Weight	41 grams



Image: Diagram showing the dimensions of the watch face (3.5cm diameter), strap width (1.4cm), total watch length (21cm), and packaging dimensions (23cm length, 4.5cm width).

8. Warranty and Support

Vicloon products are manufactured with quality and care. For any issues not covered in this manual, or for warranty inquiries, please refer to the purchase platform or contact Vicloon customer support directly. Please retain your proof of purchase for any warranty claims.

For further assistance, please visit the official Vicloon website or contact their customer service department through the retailer where the product was purchased.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C2VQTDFQ

More documents and user manuals: **https://manuals.plus/**