Aquasonic Vibe-Pro

Aquasonic Vibe Series PRO Electric Toothbrush User Manual

Model: Vibe-Pro

Introduction

Welcome to the Aquasonic Vibe Series PRO Ultra-Whitening Electric Toothbrush user manual. This guide provides detailed instructions on how to set up, operate, maintain, and troubleshoot your new electric toothbrush. The Vibe Series PRO is designed to deliver a superior cleaning experience with its powerful motor, multiple brushing modes, and advanced UV sanitizing base.

For optimal oral hygiene and product longevity, please read this manual thoroughly before first use and retain it for future reference.

What's in the Box

Carefully unpack all components and ensure the following items are included:

- 1 x Aquasonic Vibe Series PRO Toothbrush Handle
- 1 x UV Sanitizing & Wireless Charging Dock
- 6 x ProFlex Brush Heads
- 1 x Travel Case
- 1 x User Manual (this document)
- 1 x Warranty Card



Image: All components included in the Aquasonic Vibe Series PRO package, featuring the toothbrush handle, UV sanitizing and wireless charging dock, six ProFlex brush heads, and a travel case.

Setup

Charging the Device

Before first use, fully charge your Aquasonic Vibe Series PRO toothbrush. The UV Sanitizing & Wireless Charging Dock serves as the charging station.

1. Connect the power cord of the charging dock to a suitable power outlet.
2. Place the toothbrush handle onto the charging post of the dock. Ensure it is seated correctly.
3. The indicator light on the toothbrush handle will illuminate to confirm it is charging. A full charge typically takes several hours.



Image: The Aquasonic Vibe Series PRO toothbrush handle placed on its inductive charging base, demonstrating the UV clean technology in action.

Attaching a Brush Head

The Aquasonic Vibe Series PRO uses snap-on ProFlex brush heads.

1. Align the brush head with the metal shaft on the toothbrush handle.
2. Push the brush head down firmly until it clicks into place. Ensure there is a small gap between the brush head and the handle to allow for proper vibration.
3. To remove, simply pull the brush head straight off the handle.

Operating Instructions

Powering On/Off

Press the On/Off button located on the toothbrush handle to turn the device on or off. The toothbrush will start in the last used mode.

Brushing Modes

The Vibe Series PRO features 5 unique brushing modes to cater to various oral care needs. Press the On/Off button repeatedly to cycle through the modes while the toothbrush is on.

- **Clean:** Standard brushing mode for daily plaque removal.
- **Soft:** Gentle mode for sensitive teeth and gums.
- **Whiten:** Helps remove daily surface stains for a brighter smile.
- **Massage:** Delivers vibrating microbursts to gently stimulate gums.
- **Deep Clean:** Targets stubborn discoloration and polishes teeth for an intensive clean.



Image: A detailed view of the Aquasonic Vibe Series PRO toothbrush handle, highlighting the five distinct brushing modes and their descriptions.

Smart Timers

The Vibe Series PRO is equipped with smart timers to guide your brushing routine:

- **30-Second Notification Timer:** The toothbrush will pause briefly every 30 seconds to signal you to move to the next quadrant of your mouth.

- **2-Minute Auto Shut-Off:** The toothbrush will automatically turn off after 2 minutes of continuous brushing, indicating the dentist-recommended brushing time has been reached.



Image: An internal diagram of the Aquasonic Vibe Series PRO toothbrush, illustrating its powerful 50,000 vibrations per minute motor, smart chip for timers, and long-lasting lithium-ion battery.

Brushing Technique

For effective cleaning, follow these guidelines:

1. Wet the brush head and apply a small amount of toothpaste.
2. Place the brush head against your teeth at a slight angle towards the gumline.
3. Turn on the toothbrush and gently move it slowly across each tooth, allowing the sonic vibrations to do the work. Do not scrub aggressively.
4. Divide your mouth into four quadrants (upper right, upper left, lower right, lower left) and brush each quadrant for 30 seconds.
5. After brushing, rinse your mouth and the brush head thoroughly.



Image: A close-up of the Aquasonic Vibe Series PRO brush head in action, demonstrating its ability to remove plaque and whiten teeth with 50,000 vibrations per minute technology.

Maintenance

Cleaning the Toothbrush Handle

After each use, rinse the brush head and the top part of the handle under running water. Wipe the handle with a soft, damp cloth. Do not submerge the entire handle in water for extended periods, although it is IPX7 waterproof.

UV Sanitization

The UV Sanitizing Base helps to sanitize your brush heads between uses.

1. After rinsing your brush head, place it into the designated slot within the UV sanitizing chamber of the charging dock.
2. Close the lid of the UV chamber.
3. The UV light will automatically activate for a timed cycle to sanitize the bristles.

4. Ensure the dock is connected to power for the UV sanitization feature to function.



Image: The Aquasonic Vibe Series PRO toothbrush handle placed on its inductive charging base, demonstrating the UV clean technology in action.

Replacing Brush Heads

For optimal performance and hygiene, it is recommended to replace your brush head every 3 months, or sooner if the bristles become frayed or worn. The Vibe Series PRO comes with 6 ProFlex brush heads, providing over 1.5 years of brushing.

Troubleshooting

If you encounter any issues with your Aquasonic Vibe Series PRO, please refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Toothbrush does not turn on.	Low battery or not charged.	Place the toothbrush on the charging dock and ensure it is properly connected to power. Allow it to charge for several hours.
Weak vibrations.	Low battery.	Recharge the toothbrush.
UV sanitizing light not working.	Lid not closed properly or dock not powered.	Ensure the UV chamber lid is fully closed and the charging dock is plugged into a working power outlet.
Brush head feels loose.	Brush head not fully seated.	Remove the brush head and reattach it, pushing down firmly until it clicks into place.

Specifications

- **Model Number:** Vibe-Pro
- **Vibrations Per Minute:** Up to 50,000 VPM
- **Brushing Modes:** 5 (Clean, Soft, Whiten, Massage, Deep Clean)
- **Timers:** 30-second quadrant timer, 2-minute auto shut-off
- **Waterproof Rating:** IPX7
- **Power Source:** Corded Electric (for charging dock)
- **Battery Type:** Lithium-ion (rechargeable)
- **Brush Head Type:** ProFlex (Medium firmness)
- **UV Sanitization:** Auto-timed UV-C light
- **Dimensions (Package):** 9.45 x 9.33 x 3.5 inches
- **Weight (Package):** 2.45 Pounds

Warranty and Support

Your Aquasonic Vibe Series PRO Electric Toothbrush comes with a manufacturer's warranty. Please refer to the included Warranty Card for specific terms, conditions, and registration details.

For technical support, troubleshooting assistance, or warranty claims, please contact Aquasonic customer service. Contact information can typically be found on the product packaging, the official Aquasonic website, or the warranty card.

Thank you for choosing Aquasonic for your oral care needs.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question