Aquasonic Vibe-Pro

Aquasonic Vibe Series PRO Ultra-Whitening Electric Toothbrush User Manual

Model: Vibe-Pro | Brand: Aquasonic

Introduction

Welcome to your Aquasonic Vibe Series PRO electric toothbrush. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance and oral hygiene.



The Aquasonic Vibe Series PRO electric toothbrush, complete with its UV sanitizing and wireless charging base, and a set of replacement brush heads.

Safety Information

CAUTION: Keep out of reach of children. This product is intended for adult use only. Do not use for purposes other than oral hygiene. Avoid looking directly into the UV sanitizing base while in use to prevent eye injury. Replace brush heads every 3 months for optimal performance and hygiene.

What's in the Box

- 1 AquaSonic Vibe Series Pro Toothbrush
- 1 UV Sanitizing & Wireless Charging Dock
- 6 ProFlex brush heads
- 1 Travel Case
- User Manual and Warranty Card



All components included in the Aquasonic Vibe Series PRO package, neatly arranged.

Setup

Charging the Toothbrush

1. Connect the power adapter of the UV Sanitizing & Wireless Charging Dock to a power outlet.
2. Place the Aquasonic Vibe Series PRO toothbrush onto the charging post of the dock. The indicator light on the toothbrush will illuminate to confirm charging.
3. Allow the toothbrush to fully charge before first use. A full charge typically takes approximately 24 hours and provides extended brushing time.

Attaching Brush Heads

1. Align the brush head with the metal shaft of the toothbrush handle.
2. Push the brush head down firmly until it clicks into place. Ensure it is securely attached to prevent detachment during brushing.

Operating Instructions

Powering On/Off

- Press the On/Off button once to turn the toothbrush on. It will start in the last used mode.
- Press the On/Off button again to cycle through the brushing modes.
- To turn off the toothbrush, press and hold the On/Off button for 2-3 seconds, or cycle through all modes until it turns off automatically.

Brushing Modes

The Aquasonic Vibe Series PRO offers 5 distinct brushing modes for comprehensive oral care:

- **Clean:** Standard brushing mode for daily plaque removal.
- **Soft:** Gentle mode for sensitive teeth and gums.
- **Whiten:** Helps remove daily surface stains for a brighter smile.
- **Massage:** Delivers vibrating microbursts to gently stimulate gums.
- **Deep Clean:** Targets stubborn discoloration and polishes teeth for an intensive clean.



The toothbrush handle displaying the five distinct brushing modes: Clean, Soft, Whiten, Massage, and Deep Clean.

Smart Timers

- The toothbrush features a built-in 2-minute smart timer, which is the dentist-recommended brushing time. The toothbrush will automatically shut off after 2 minutes.
- Additionally, a 30-second interval timer will briefly pause the vibrations every 30 seconds, signaling you to move to the next quadrant of your mouth for an even clean.

Brushing Technique

1. Apply a small amount of toothpaste to the brush head.
2. Place the brush head against your teeth at a slight angle towards the gumline.
3. Gently move the brush head slowly across each tooth surface, allowing the sonic vibrations to do the work. Do not scrub vigorously.
4. Divide your mouth into four quadrants (upper right, upper left, lower right, lower left) and brush each quadrant for 30 seconds, guided by the interval timer.



Visual representation of the toothbrush's sonic vibrations effectively cleaning tooth surfaces and removing plaque.

Maintenance

Cleaning the Toothbrush

- After each use, rinse the brush head thoroughly under running water while the toothbrush is still on to remove any remaining toothpaste or debris.
- Turn off the toothbrush and wipe the handle with a soft, damp cloth. Do not immerse the handle in water.
- Periodically remove the brush head and rinse the metal shaft to prevent toothpaste buildup.

UV Sanitization

- After brushing and rinsing your brush head, place it into the UV sanitizing chamber on the charging dock.
- Close the lid. The UV light will automatically activate for a timed cycle to help sanitize the bristles.
- Avoid looking directly at the UV light during operation.



The UV sanitizing base in operation, showing the blue UV light that helps clean brush heads.

Replacing Brush Heads

For optimal performance and hygiene, it is recommended to replace your ProFlex brush head every 3 months, or sooner if the bristles become frayed.

Troubleshooting

Problem	Solution
Toothbrush does not turn on.	Ensure the toothbrush is fully charged. Place it on the charging dock for at least 24 hours.
Weak vibrations.	The battery may be low. Recharge the toothbrush. Ensure the brush head is securely attached.

Problem	Solution
UV sanitizer not working.	Ensure the dock is plugged in and the lid is fully closed.
Toothbrush stops before 2 minutes.	This is normal operation for the 2-minute smart timer. If it stops significantly earlier, ensure it is fully charged.

Specifications

Feature	Detail
Package Dimensions	9.49 x 9.33 x 3.5 inches; 2.45 Pounds
Item Model Number	Vibe-Pro
Manufacturer	Aquasonic
Brand	Aquasonic
Age Range (Description)	Adult
Special Feature	Brushing Timer
Power Source	Corded Electric
Item Firmness Description	Medium

Warranty and Support

Your Aquasonic Vibe Series PRO comes with a warranty. Please refer to the warranty card included in your package for details on coverage and duration.
For further assistance, product support, or to purchase replacement brush heads, please visit the official Aquasonic website or contact their customer service.

© 2023 Aquasonic. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question