Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY QYSY-AKTV505T-QYSY

ALLIMITY Replacement Remote Control User Manual

For AKAI TV Models: AKTV505T, AKTV4620, AKTV3924M

1. Introduction

This manual provides instructions for the ALLIMITY replacement remote control, designed to operate various AKAI TV models. This remote offers full functionality without requiring any complex programming. Simply insert batteries, and it is ready for use with compatible AKAI televisions.

Compatible AKAI TV Models:

- AKTV505T
- AKTV4620
- AKTV3924M
- AKTV 505 T
- AKTV 4620
- AKTV 3924 M





Figure 1: Front view of the ALLIMITY Replacement Remote Control.

2. Setup

2.1 Battery Installation

The remote control requires two AAA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover off.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside

the compartment.

4. Slide the battery compartment cover back into place until it clicks securely.

2.2 Initial Use

No programming is required for this replacement remote control. Once batteries are correctly installed, the remote is ready to operate your compatible AKAI TV.

3. Operating Instructions

This section outlines the primary functions of the remote control buttons.





Figure 2: Angled view of the remote control, highlighting button layout.

- **Power Button (Red)**: Turns the TV on or off.
- **Mute Button (Green)**: Mutes or unmutes the TV sound.
- **Number Buttons (0-9)**: Directly select TV channels.
- **TV/RADIO**: Switches between TV and Radio modes.
- **P.MODE (Picture Mode)**: Adjusts picture settings.
- **S.MODE (Sound Mode)**: Adjusts sound settings.
- **NICAM A2**: Selects audio system.
- **SLEEP**: Sets the sleep timer.
- **SOURCE**: Selects input source (HDMI, AV, etc.).
- **CH +/- (Channel Up/Down)**: Changes TV channels.
- **VOL +/- (Volume Up/Down)**: Adjusts the volume level.
- **INFO**: Displays channel or program information.
- **FAV (Favorite)**: Accesses favorite channels list.
- **Lightbulb Icon (Backlight/Brightness)**: Adjusts screen brightness or backlight.
- **ASP (Aspect Ratio)**: Changes the screen aspect ratio.
- **Directional Arrows (Up, Down, Left, Right)**: Navigate menus and options.
- **OK Button**: Confirms selections in menus.
- **MENU**: Opens the main TV menu.
- **EXIT**: Exits the current menu or function.
- **TEXT**: Activates Teletext.
- **SUBPAGE**: Navigates Teletext subpages.
- **SIZE**: Adjusts Teletext display size.
- **REVEAL**: Reveals hidden Teletext information.
- **INDEX**: Accesses Teletext index.
- **HOLD**: Holds Teletext page.
- **CANCEL**: Cancels current action or exits Teletext.

- **SUBTITLE**: Toggles subtitles on/off.
- **REPEAT**: Repeats playback (for media functions).
- **AUTO**: Automatic function (e.g., auto-scan).
- **A-B**: Repeats a section of media.
- **MEDIA**: Accesses media player functions.
- **Colored Buttons (Red, Green, Yellow, Blue)**: Functionality varies depending on the TV menu or specific applications.

***Important Note:* Some users have reported that the Channel Up/Down and Volume Up/Down buttons may be inverted on certain AKAI TV models. If you experience this, please refer to the Troubleshooting section for guidance.**

4. Maintenance

4.1 Cleaning

To clean the remote control, use a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote's surface or internal components.

4.2 Battery Replacement

Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries.

4.3 Storage

If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the device.

5. Troubleshooting

- **Remote not responding:**
  - Ensure batteries are installed correctly with the correct polarity.
  - Replace old batteries with new AAA alkaline batteries.
  - Check for any obstructions between the remote and the TV's infrared sensor.
  - Ensure you are within the effective range (typically up to 10 meters) and pointing the remote directly at the TV.
- **Buttons are inverted (e.g., Volume changes Channel):**

  This is a known characteristic for some AKAI TV models when using this replacement remote. There is no programming fix for this specific inversion. Users will need to adapt to the inverted functionality for these specific buttons. All other buttons should function as labeled.
- **Specific functions not working:**

  While this remote is designed to cover all functions of the original, some advanced or model-specific features might behave differently or not be supported. Refer to your TV's original manual for specific feature operations.

6. Specifications

Brand	ALLIMITY

Model Number	QYSY-AKTV505T-QYSY
Color	Black
Connectivity Technology	Infrared
Special Feature	Ergonomic design
Compatible Devices	AKTV505T, AKTV4620, AKTV3924M, AKTV 505 T, AKTV 4620, AKTV 3924 M
Maximum Range	10 Meters
Number of Buttons	20

7. Warranty and Support

Information regarding specific warranty terms or direct manufacturer support for this ALLIMITY replacement remote control is not available in the provided product details. For any issues or inquiries, please refer to the retailer or point of purchase for assistance.

© 2023 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C38TB6PL

More documents and user manuals: **https://manuals.plus/**