Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY QYSY-RC1910-SSST-QYSY

ALLIMITY Replacement Remote Control User Manual

Model: QYSY-RC1910-SSST-QYSY

1. Introduction

This manual provides instructions for the ALLIMITY Replacement Remote Control, model QYSY-RC1910-SSST-QYSY. This remote is designed to function as a direct replacement for original remote controls of various TV models, including those from Saba, Salora, Schneider, Sunstech, Techwood, Telefunken, Tucson, and Westline.
Compatible TV models include: **S22R, 32LED9500BK, NINZA2602PVR, TLEI32HDWSLIMBK, TC3211-HD906, TLFK-22LEDPVR, IL3204BMS12, WI32HD11**.

2. Setup and Battery Installation

The ALLIMITY Replacement Remote Control requires no programming. Simply install the batteries, and it will be ready for use with your compatible television.

2.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery compartment cover.
3. Insert two new **AAA alkaline batteries**, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Close the battery compartment cover securely.

Note: Ensure batteries are inserted correctly to prevent damage to the remote control. Do not mix old and new batteries, or different types of batteries.

3. Operating Instructions

This remote control is designed to replicate the functions of your original TV remote. Point the remote directly at your television's infrared receiver for optimal performance.

3.1 Key Functions Overview




SLEEP
SCREEN
PRESETS
FAV
LANG.
SUBTITLE
TXT
1
2
3
4
5
6
7
8
9
EPG
0
SWAP
SOURCE
MENU
OK
C
RETURN
DISP.
SEARCH MODE
CH
INFO
V
ROOT
TITLE
ZOOM
REPEAT
LCD TV



Image 1: Front view of the ALLIMITY Replacement Remote Control. This image displays the layout of all buttons, including power, number keys, navigation, volume, channel, and media controls.

- **Power Button (●):** Turns the TV on or off.
- **Number Keys (0-9):** Directly select TV channels.
- **Volume Up/Down (VOL +/-):** Adjusts the sound level.
- **Channel Up/Down (CH +/-):** Changes the TV channel.
- **Mute:** Silences the TV audio.
- **Source/Input:** Selects the input source (e.g., HDMI, AV).
- **Navigation Pad (Up, Down, Left, Right, OK):** Used for menu navigation and selection.
- **Menu:** Accesses the TV's main menu.
- **Return/Back:** Returns to the previous screen or menu.
- **EPG (Electronic Program Guide):** Displays program information.
- **FAV (Favorites):** Accesses favorite channels list.
- **LANG (Language):** Changes audio language.
- **SUBTITLE:** Toggles subtitles on/off.
- **TXT (Teletext):** Accesses teletext services.
- **Media Control Buttons (Play, Pause, Stop, Rewind, Fast Forward, Previous, Next):** Controls media playback if supported by the TV.
- **Colored Buttons (Red, Green, Yellow, Blue):** Functionality varies by TV model and context, often used for interactive features or specific menu options.

For specific functions not listed, refer to your television's original user manual, as this remote aims to replicate those functions.

4. Maintenance and Care

To ensure the longevity and proper functioning of your remote control, follow these maintenance guidelines:

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, abrasive materials, or chemical solvents.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries simultaneously.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal components.
- **Liquid Exposure:** Keep the remote away from water and other liquids to prevent short circuits.

5. Troubleshooting

If you experience issues with your ALLIMITY Replacement Remote Control, consult the following troubleshooting steps:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Remote is not working.	Dead or incorrectly inserted batteries.	Replace batteries with new AAA alkaline batteries, ensuring correct polarity.
Remote has limited range or intermittent response.	Weak batteries; obstruction between remote and TV; remote not pointed at TV's IR receiver.	Replace batteries. Ensure a clear line of sight to the TV. Point the remote directly at the TV.
Certain buttons do not function.	Button malfunction; TV does not support the specific function.	Test other buttons. Verify if your TV model supports the function. If multiple buttons fail, the remote may be faulty.
Remote works for some TVs but not mine.	TV model is not compatible.	Double-check the list of compatible models in the Introduction section.

If the issue persists after attempting these solutions, please contact ALLIMITY customer support for further assistance.

6. Product Specifications

- **Brand:** ALLIMITY
- **Model Number:** QYSY-RC1910-SSST-QYSY
- **Connectivity Technology:** Infrared (IR)
- **Compatible Devices:** Saba, Salora, Schneider, Sunstech, Techwood, Telefunken, Tucson, Westline TVs (Specific models: S22R, 32LED9500BK, NINZA2602PVR, TLEI32HDWSLIMBK, TC3211-HD906, TLFK-22LEDPVR, IL3204BMS12, WI32HD11)
- **Special Features:** Ergonomic design
- **Maximum Range:** Approximately 10 meters (33 feet)
- **Battery Type:** 2 x AAA Alkaline batteries (not included)
- **Controller Type:** Button Control
- **Number of Buttons:** 18

7. Warranty and Support

Information regarding specific warranty terms is not provided in the product details. For warranty claims, technical support, or further inquiries, please refer to the seller's return policy or contact ALLIMITY customer service directly through your purchase platform.
Seller: MAXCONTROL INC
Return Policy: 31-day refund/replacement policy (as per Amazon.com.be buybox winner information).

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C38TZJBK

More documents and user manuals: **https://manuals.plus/**