Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY QYSY-741-JC-QYSY

ALLIMITY Replacement Remote Control User Manual

Model: QYSY-741-JC-QYSY

Introduction

This manual provides instructions for the ALLIMITY Replacement Remote Control, model QYSY-741-JC-QYSY. This remote is designed to replace your original remote for various JTC TV models, offering full functionality without the need for programming. Simply insert batteries to begin use.
Compatible JTC TV models include, but are not limited to: DVB-14809, GQ0DD-AS55, LEDTV21II, LEDTV4022IT, 2021KL, 2024D2, 2032C, 2032C2, 87261, D242KL, DVB-73203, DVB-PM13209HCATS, DVB-PM14809HCATS, DVB-PM15509HCATS, DVB-PMU14909HCATS, DVB-PS1320023HCAS, DVB-PS13203, DVB-PS13209HCAS, G0C5-GSU40, GRODD-AS55, LEDTV2040C, LEDTV2101, LTV-2401, LTV-D242KL, LTV-J2024D2, PDVB-PM13209HCATS, PDVB-PT14009HCAS, PDVD-PM13209HCATS, TV4022II.

Setup

1. Battery Installation

The remote control requires two AAA alkaline batteries (not included).

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.





Image: Rear view of the remote control, highlighting the battery compartment cover.

2. Initial Use

This replacement remote control does not require any programming. Once the batteries are correctly installed, it is ready for immediate use with your compatible JTC TV.

Operating Instructions

The remote control features a standard layout for easy navigation and control of your JTC TV. Below is a general overview of the main buttons and their functions.



Image: Front view of the ALLIMITY replacement remote control, displaying all buttons and their labels.

Button Functions

- **POWER**: Turns the TV on or off.
- **TV/RADIO**: Switches between TV and Radio modes.
- **GOTO**: Jumps to a specific time in media playback.
- **ANGLE**: Changes the viewing angle (if supported by content).

- **REPEAT**: Repeats current track/chapter.
- **A-B**: Repeats a specific segment.
- **FAV**: Accesses favorite channels.
- **TEXT**: Opens Teletext.
- **HOLD**: Holds the current Teletext page.
- **FREEZE**: Freezes the current image on screen.
- **SLEEP**: Sets the sleep timer.
- **SUBTITLE**: Toggles subtitles on/off or selects subtitle language.
- **SIZE**: Adjusts screen size/aspect ratio.
- **ZOOM**: Zooms in on the screen.
- **ASPECT**: Changes the aspect ratio.
- **SUBPAGE**: Navigates Teletext subpages.
- **MEDIA**: Accesses media player functions.
- **D.SETUP**: Enters digital setup menu.
- **MENU**: Opens the main TV menu.
- **OK**: Confirms selections in menus.
- **Arrow Buttons (Up, Down, Left, Right)**: Navigates through menus and channels.
- **SOURCE**: Selects input source (HDMI, AV, etc.).
- **D.MENU/EPG**: Opens digital menu or Electronic Program Guide.
- **MUTE**: Mutes or unmutes the TV sound.
- **VOL +/-**: Adjusts volume up or down.
- **DISPLAY**: Shows on-screen information.
- **CH +/-**: Changes channels up or down.
- **Number Buttons (0-9)**: Directly selects channels or enters numerical values.
- **-/--**: Toggles between single and double-digit channel input.
- **AUDIO**: Selects audio track or mode.
- **LANG**: Changes language settings.
- **P-MODE**: Cycles through picture modes.
- **S-MODE**: Cycles through sound modes.
- **TITLE**: Accesses DVD/Blu-ray disc title menu.
- **EXIT**: Exits current menu or function.
- **Playback Controls (Play, Pause, Stop, Rewind, Fast Forward, Previous, Next)**: Controls media playback.
- **INDEX**: Accesses index function.

Maintenance

Battery Replacement

Replace batteries when the remote control becomes unresponsive or its range decreases significantly. Always replace

both batteries at the same time with new AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries.

Cleaning

To clean the remote control, wipe it with a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these can damage the remote's surface or internal components.

Troubleshooting

- **Remote not responding:**
  - Ensure the remote is pointed directly at the TV's infrared sensor.
  - Check if the batteries are correctly inserted with the correct polarity (+/-).
  - Replace the batteries with fresh ones.
  - Remove any obstructions between the remote and the TV.
- **Limited range or intermittent response:**
  - This usually indicates low battery power. Replace the batteries.
  - Ensure there are no strong light sources (like direct sunlight or bright fluorescent lights) interfering with the infrared signal.
- **Specific buttons not working:**
  - Clean the remote control, especially around the unresponsive buttons, to remove any dirt or debris that might be preventing proper contact.
  - If only a few buttons are affected after cleaning and battery replacement, the remote may be damaged and require replacement.

Specifications

Feature	Detail
Brand	ALLIMITY
Model Number	QYSY-741-JC-QYSY
Color	Black
Connectivity Technology	Infrared
Special Feature	Ergonomic
Compatible Devices	JTC TVs (various models including DVB-14809, GQ0DD-AS55, LEDTV21II, LEDTV4022IT, etc.)
Maximum Range	10 Meters
Battery Description	Alkaline (AAA)
Manufacturer	ALLIMITYQYSY

Feature	Detail
Country of Origin	China

Warranty and Support

Information regarding specific warranty terms or dedicated support channels for this product is not available in the provided documentation. For any issues or inquiries, please refer to the retailer or your point of purchase.
Spare parts availability: Information unavailable.
Software update guarantees: Information unavailable.

© 2024 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C38WB68W

More documents and user manuals: **https://manuals.plus/**