Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Joyroom JR-DB1

JOYROOM Jdots Series True Wireless Mini Earbuds JR-DB1 User Manual

Model: JR-DB1

1. Introduction

Thank you for choosing the JOYROOM Jdots Series True Wireless Mini Earbuds. This manual provides detailed instructions for the proper use, setup, and maintenance of your earbuds to ensure optimal performance and longevity.

1.1 Package Contents

- JOYROOM Jdots Series True Wireless Mini Earbuds (Left and Right)
- Charging Case
- USB Charging Cable
- Eartips (S/M/L sizes)
- User Manual

2. Product Overview

The JOYROOM Jdots Series True Wireless Mini Earbuds are designed for high-quality audio and comfortable wear, featuring Bluetooth 5.3 for stable connections and extended battery life.



Image 2.1: JOYROOM Jdots Series True Wireless Mini Earbuds and Charging Case.

2.1 Key Features

- **High-Quality Sound:** Bio-fiber diaphragm dynamic speaker with AAC and SBC audio decoding for clear, high-fidelity audio.
- **Comfortable Design:** Ergonomic in-ear design with a secure fit for extended wear. Includes three sizes of environment-friendly silicone eartips (S/M/L).
- **Dual Main Ear Mode:** Seamless switching between single and double ear modes. Earbuds connect automatically when removed from the charging case.
- **Water-Resistant:** IPX4 rating provides protection against splashes and sweat.
- **Passive Noise Reduction:** In-ear design helps block out external noise for clearer audio.
- **Long Battery Life:** Up to 8 hours of music time and 6.5 hours of talk time on a single charge. The charging case provides an additional 48 hours of battery life.
- **Bluetooth 5.3:** Low power consumption and stable transmission without delay.



Image 2.2: Illustration of the earbuds' battery life, showing 8 hours for a single earbud, 28 hours simultaneous use with case, and 48 hours alternative use with case.



Image 2.3: Depiction of a person wearing the earbuds during activity, emphasizing the secure and comfortable ergonomic in-ear design and the included S/M/L eartips.



Image 2.4: Exploded view diagram of the earbud's internal speaker, highlighting the 6mm large speaker and 99.99% pure copper coil for deep and powerful bass.

3. Setup

3.1 Initial Charging

1. Place both earbuds into the charging case.
2. Connect the USB charging cable to the charging port on the case and a power source.
3. The indicator lights on the charging case will illuminate to show charging status. Ensure the case and earbuds are fully charged before first use.

3.2 Pairing with a Device

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, etc.), enable Bluetooth.

3. Search for available Bluetooth devices and select "JR-DB1" from the list.
4. Once connected, a voice prompt will confirm successful pairing.



Image 3.1: Illustration of the earbuds being taken out of the charging case and pairing with a smartphone via Bluetooth settings, demonstrating the 'Free Switching' feature.

4. Operating Instructions

4.1 Touch Controls

The earbuds feature intuitive touch controls for managing audio playback and calls.



Image 4.1: Visual guide to the touch control functions on the earbuds, including Play/Pause, Activate Voice Assistant, Previous Track, Next Track, Factory Reset, Reject Call, and Answer/End Call.

Function	Action
Play/Pause	Double-click either earbud's multifunctional touch area.
Activate Voice Assistant	Press & hold either earbud's multifunctional touch area for 1 second.
Previous Track	Triple-click the left earbud's multifunctional touch area.
Next Track	Triple-click the right earbud's multifunctional touch area.
Answer/End Call	Double-click either earbud's multifunctional touch area.
Reject Call	Press & hold either earbud's multifunctional touch area for 1 second.

Function	Action
Factory Reset	Five-click either earbud's multifunctional touch area.

4.2 Single and Dual Earbud Mode

The earbuds support seamless switching between using one or both earbuds. Simply take one earbud out of the case to use it individually, or take both out for stereo sound. They will automatically connect to your paired device.

4.3 Bluetooth 5.3 and Noise Reduction

Equipped with the latest Bluetooth 5.3 chip, the earbuds provide a stable and low-latency connection. The in-ear design offers passive noise reduction, enhancing your listening experience by minimizing ambient sounds.



Image 4.2: Diagram showing the internal Bluetooth 5.3 chip and illustrating the effect of noise reduction, comparing sound before and after.

5. Maintenance

5.1 Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove eartips and clean them with mild soap and water, then dry thoroughly before reattaching.
- Ensure charging contacts on both earbuds and case are free from dust and debris.

5.2 Storage

- Store the earbuds in their charging case when not in use to protect them and keep them charged.
- Avoid storing in extreme temperatures or high humidity.

5.3 Water Resistance

The earbuds are rated IPX4 water-resistant, meaning they are protected against splashing water from any direction. They are not designed for submersion in water. Avoid exposing them to heavy rain or swimming.

6. Troubleshooting

If you encounter issues with your earbuds, refer to the following common problems and solutions:

Problem	Possible Solution
Earbuds not pairing	◦ Ensure earbuds are charged and out of the case. ◦ Turn off and on Bluetooth on your device. ◦ Forget/delete "JR-DB1" from your device's Bluetooth list and try pairing again. ◦ Perform a factory reset (five-click either earbud).
Only one earbud working	◦ Place both earbuds back into the charging case, close it, then open it again. ◦ Ensure both earbuds are charged. ◦ Perform a factory reset.
No sound or low volume	◦ Adjust volume on both your device and the earbuds (if applicable via touch controls). ◦ Ensure earbuds are properly seated in your ears. ◦ Check for debris blocking the earbud speakers.
Charging case not charging	◦ Check the USB cable and power adapter for damage. ◦ Ensure the charging cable is securely connected. ◦ Try a different charging cable or power source.

7. Specifications

Feature	Detail
Brand Name	Joyroom
Model Name	MINI EARBUDS (JR-DB1)
Connectivity Technology	Wireless (Bluetooth)
Wireless Communication Technology	Bluetooth 5.3
Headphones Form Factor	In Ear
Headphones Ear Placement	In Ear
Noise Control	Sound Isolation (Passive Noise Reduction)
Color	BLACK
Water Resistance Rating	IPX4
Music Playtime (single charge)	Up to 8 hours
Talk Time (single charge)	Up to 6.5 hours
Total Battery Life (with charging case)	Up to 48 hours
Included Components	Cable
Manufacturer	JOYROOOM
Package Dimensions	18.7 x 9.9 x 3.2 cm
Item Weight	90 g

8. Warranty and Support

For warranty information and customer support, please refer to the warranty card included in your product packaging or visit the official Joyroom website. Keep your purchase receipt as proof of purchase for any warranty claims.

© 2023 Joyroom. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C3CHSNXT

More documents and user manuals: **https://manuals.plus/**