Hasbro F7565

Electronic Battleship Reloaded Board Game Instruction Manual

Model: F7565 | Brand: Hasbro Gaming

Product Overview

Step behind the control panel and into the action with the Electronic Battleship Reloaded game, as each player sets out to destroy their opponent's fleet before their own is eliminated. This edition of the classic game of naval combat features an easier set-up than previous versions of the Electronic Battleship board game. With up to 64 preset layouts and an option for custom layouts, the battle will change all the time! Brace for action as electronic voice commands and sound effects signal a search-and-destroy mission to take out opponent’s ships! Play solo or challenge a friend in the incredible game of Battleship!

- **Electronic Battleship Game:** Features sounds, lights, and special attacks for an immersive experience. Easier setup than previous versions.
- **Lights and Sounds:** Voice commands, sound effects, and lights enhance gameplay. Players enter coordinates and press the fire button to sink ships.
- **Quick and Easy Set-Up:** Customize layouts or use preset ship layouts for immediate play.
- **Classic and Advanced Mode:** Choose between Classic Mode or Advanced Mode, which includes special weapon pegs.
- **Solo Play:** Practice Battleship skills against the computer.
- **Portable Design:** Features a folding game unit for easy storage and on-the-go play.

What's in the Box

- Folding command unit
- 10 ships
- 12 advanced weapon pegs
- 8 layout cards
- 170 "miss" pegs
- 75 "hit" pegs

- 4 reference panels
- Instructions



Image: All components of the Electronic Battleship Reloaded game, including the main game unit, various ship pieces, and colored pegs for hits and misses.

Setup

1. **Install Batteries:** Locate the battery compartment on the underside of the main game unit. Insert 3 AA batteries (not included), ensuring correct polarity. Secure the battery compartment cover.
2. **Unfold Game Unit:** Carefully unfold the game unit to reveal the two playing grids and the central electronic console. Each player will have their own grid.
3. **Distribute Pegs:** Separate the red "hit" pegs and white/yellow "miss" pegs into their respective storage compartments within the game unit.
4. **Place Ships:** Each player takes their set of 5 ships (Carrier, Battleship, Destroyer, Submarine, Patrol Boat). Strategically place your ships on your lower grid (your ocean grid) by inserting them into the holes. Ships cannot overlap and must be placed horizontally or vertically. You can use the provided layout cards for quick setup or create your own custom layout.
5. **Prepare Target Grid:** The upper grid (target grid) is where you will mark your shots. Ensure it is clear of pegs before starting the game.



Image: A close-up view of the game board, showing ships placed on the lower grid and the various colored pegs stored in the side compartments, ready for gameplay.

Operating Instructions

Game Modes

- **Classic Mode:** Standard Battleship rules. Players take turns calling out coordinates to hit opponent's ships.
- **Advanced Mode:** Introduces special weapon pegs (Torpedo, Salvo, Radar) for strategic attacks.
- **Solo Play Mode:** Play against the electronic console. The system will track hits and misses for the computer opponent.

Gameplay

1. **Start Game:** Turn on the electronic unit. Select your desired game mode using the console buttons.
2. **Taking a Turn:**
    - **Enter Coordinates:** Use the dials on the electronic console to select a letter (A-J) and a number (1-10) for

your target.

- **Fire:** Press the large red "Fire" button. The unit will announce the result (Hit or Miss) with sound effects.
- **Mark Your Shot:** If it's a hit, place a red "hit" peg on your target grid at the corresponding coordinate. If it's a miss, place a white/yellow "miss" peg.
- **Opponent's Turn:** Your opponent will announce if your shot hit one of their ships. If it did, they will place a red peg on their ocean grid. If it missed, they place a white/yellow peg.

3. **Sinking a Ship:** When all holes of an opponent's ship have been hit, the ship is sunk. The electronic unit will announce the type of ship sunk.
4. **Using Advanced Weapons (Advanced Mode Only):**
    - Press the "Advanced Weapons" button to cycle through available special attacks (Torpedo, Salvo, Radar).
    - Follow the on-screen prompts or voice commands to execute the attack.
    - Mark hits and misses as usual.
5. **Winning the Game:** The first player to sink all of their opponent's ships wins the game. The electronic unit will announce the winner.



Image: A hand demonstrates how to select coordinates using the rotary dials on the electronic console, preparing to fire a shot.

Maintenance

- **Cleaning:** Wipe the game unit and plastic pieces with a soft, dry cloth. Do not use abrasive cleaners or immerse the electronic unit in water.
- **Storage:** Fold the game unit for compact storage. Ensure all pegs and ships are stored securely within their designated compartments to prevent loss. Store in a cool, dry place away from direct sunlight.
- **Battery Care:** Remove batteries if the game will not be used for an extended period to prevent leakage.

Troubleshooting

Problem	Solution

Problem	Solution
Game unit does not turn on.	Check if batteries are inserted correctly. Replace with fresh AA batteries. Ensure the power switch is in the "ON" position.
Sound effects are not working or are too low.	Check battery levels. The unit has an adjustable volume; ensure it is not set to minimum.
Electronic unit is not registering hits/misses correctly.	Ensure coordinates are entered precisely using the dials. If playing against the computer, verify that the computer's ships were placed according to the instructions or layout cards.
Missing pegs or ships.	Check all storage compartments within the game unit. For replacement parts, contact Hasbro customer support.

Safety Information

WARNING: Small parts may be generated. Not for children under 3 years.
Always supervise young children during play. Keep small components away from infants and toddlers to prevent choking hazards. Do not attempt to disassemble or modify the electronic unit, as this may cause damage or injury.

Specifications

- **Product Dimensions:** 2.52 x 15.75 x 9.02 inches
- **Item Weight:** 2.02 pounds
- **Item Model Number:** F7565
- **Manufacturer Recommended Age:** 8 years and up
- **Batteries:** 3 AA batteries required (not included)
- **Language:** English
- **Manufacturer:** Hasbro
- **Release Date:** January 1, 2024

Warranty and Support

For detailed warranty information, product support, or to inquire about replacement parts, please refer to the official Hasbro Gaming website or contact their customer service directly. This information is typically provided on the product packaging or within a separate warranty card included with your purchase.
You can visit the Hasbro Gaming official website for further assistance:www.hasbro.com/en-us/consumer-care

© 2025 Hasbro. All Rights Reserved.