Disney Disney Reader

Disney Me Reader Electronic Reader User Manual

Brand: Disney
Model: Disney Reader

1. Introduction

The Disney Me Reader Electronic Reader is an interactive learning system designed to help young children develop early reading skills. This bundle includes one electronic Me Reader module and eight beautifully illustrated storybooks featuring beloved Disney characters. The Me Reader module reads the stories aloud, providing an engaging and supportive environment for children to follow along and learn at their own pace.
This manual provides essential information on setting up, operating, maintaining, and troubleshooting your Disney Me Reader to ensure a safe and enjoyable experience.

2. What's Included

Your Disney Me Reader Electronic Reader 8 Book Bundle contains the following components:

- 1 x Disney Me Reader Electronic Module
- 8 x Disney Storybooks (featuring characters such as Mickey Mouse, Toy Story, Incredibles, Snow White, Mulan, Dumbo, Lady and the Tramp, Pinocchio)
- Bonus Tsum Tsum Stickers
- Bonus Barn Bots Door Hanger



Image: The complete Disney Me Reader Electronic Reader 8 Book Bundle, showcasing the electronic reader, the eight storybooks, the bonus Tsum Tsum stickers, and the Barn Bots door hanger, all within its packaging.



Image: A close-up view of the Disney Me Reader electronic module alongside the eight included storybooks, spread out to show their covers.



Image: A sheet of bonus Tsum Tsum stickers featuring various Disney characters in the Tsum Tsum style.






Image: The bonus Barn Bots door hanger, depicting farm-themed robots and the phrase "The Barn is Open Come On In".

3. Setup

3.1 Battery Installation

The Disney Me Reader module requires batteries to operate. Locate the battery compartment on the back of the Me Reader. Using a small Phillips head screwdriver, open the battery cover. Insert the required number of new batteries (typically AAA, check the compartment for specific type and polarity markings). Close the battery cover and secure it with the screw.
Important: Always use new batteries of the same type. Do not mix old and new batteries, or different types of batteries. Ensure correct polarity (+/-) when inserting batteries. Remove batteries if the device will not be used for an extended period.

3.2 Powering On

Once batteries are installed, locate the power button on the Me Reader module. Press and hold the power button for a few seconds until you hear a sound or see an indicator light, signifying the device is on and ready for use.

4. Operating Instructions

4.1 Selecting a Book

Each of the eight storybooks has a corresponding button on the Me Reader module. Identify the book you wish to read and locate its matching button on the Me Reader. Press the button firmly to select the story.

4.2 Reading the Story

Once a book is selected, open the physical book to the first page. The Me Reader will begin reading the story aloud. Follow along with the text in the book. When you are ready to turn the page, listen for the prompt or look for a visual cue (if available) on the Me Reader. Press the "Next Page" button (or similar, refer to your specific module's button layout) to advance the audio to the next page.

4.3 Volume Control

The Me Reader module typically includes volume control buttons. Use the '+' button to increase the volume and the '-' button to decrease it to a comfortable listening level.

4.4 Powering Off

To conserve battery life, always power off the Me Reader when not in use. Press and hold the power button until the device shuts down.

5. Maintenance

5.1 Cleaning

To clean the Me Reader module and books, gently wipe them with a soft, dry cloth. Do not use abrasive cleaners, solvents, or immerse the electronic module in water. Keep the books dry and away from direct sunlight to prevent damage.

5.2 Storage

Store the Me Reader and books in a cool, dry place away from extreme temperatures and humidity. If storing for an extended period, remove the batteries from the Me Reader module.

6. Troubleshooting

- **Problem: Me Reader does not turn on.**

  Solution: Check if batteries are inserted correctly with the correct polarity. Replace with fresh batteries. Ensure the power button is pressed and held for a few seconds.

- **Problem: No sound or low sound.**

  Solution: Check the volume level using the volume control buttons. Ensure batteries are not depleted. Try replacing batteries.

- **Problem: Incorrect story plays when a book button is pressed.**

  Solution: Ensure you are pressing the correct button corresponding to the book you wish to read. Each book has a unique identifier button on the Me Reader module.

- **Problem: Me Reader freezes or becomes unresponsive.**

  Solution: Turn the Me Reader off and then on again. If the issue persists, remove the batteries for a few minutes, then reinsert them and try again.

7. Specifications

Product Dimensions	9.38 x 8.06 x 3 inches
Item Weight	2.57 pounds
Item Model Number	Disney Reader
Manufacturer Recommended Age	18 months and up
ASIN	B0C3KRBMSK
Manufacturer	Officially Licensed Components

8. Safety Information

Please read and follow all safety instructions to prevent injury or damage:

- **WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years.** Adult supervision is recommended during use, especially for younger children.
- Do not immerse the electronic module in water or other liquids.
- Do not attempt to disassemble or modify the Me Reader module. This may cause damage and void any potential warranty.
- Keep batteries out of reach of small children. If swallowed, seek immediate medical attention.
- Dispose of used batteries properly according to local regulations.
- Avoid dropping the Me Reader or books, as this may cause damage.

9. Warranty and Support

This Disney Me Reader Electronic Reader is an officially licensed product. For any questions regarding product functionality, troubleshooting, or potential defects, please refer to the contact information provided on the product packaging or visit the official Disney consumer products website for support.
For more information about Disney products, you may visit the Disney Store on Amazon.

© 2023 Disney. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question