SMAEL SL-8080

SMAEL SL-8080 Sport Watch User Manual

Model: SL-8080

1. Introduction

This manual provides detailed instructions for the operation and maintenance of your SMAEL SL-8080 Sport Watch. Please read this manual carefully to ensure proper use and to maximize the lifespan of your watch.



Figure 1: SMAEL SL-8080 Sport Watch (ArmyGreen)

2. Product Features

The SMAEL SL-8080 Sport Watch is designed for durability and functionality, offering a range of features:

- Dual Time Display (Analog and Digital)
- LED Backlight Function
- 50-Meter Water Resistance
- Stopwatch Function
- Alarm Function
- 12/24 Hour Time Format
- Calendar (Day of the Week)
- Shockproof Design
- Durable Silicone (PU) Strap

- Japan Original Digital Movement



Figure 2: Key Features of the SMAEL SL-8080 Watch

3. Watch Components and Button Functions

Familiarize yourself with the watch's buttons and their primary functions:



Figure 3: Watch Button Layout and Functions

- **LIGHT Button (Top Left):** Activates the LED backlight for visibility in low light conditions.
- **MODE Button (Bottom Left):** Cycles through different operational modes: Time Display, Alarm Setting, Stopwatch, and Dual Time.
- **START/STOP Button (Top Right):** Used to start and stop the stopwatch. Also used for adjusting values during setting modes.
- **RESET Button (Bottom Right):** Used to reset the stopwatch. Also used for selecting items or confirming settings in various modes.
- **Pointer Adjustment (Crown, Right Side):** Used to set the analog time. Pull out to adjust, push in to set.

4. Setup and Time Setting

4.1 Setting Analog Time

1. Pull out the **Pointer Adjustment** crown on the right side of the watch.
2. Rotate the crown to move the analog hands to the correct time.
3. Push the crown back in to set the analog time.

4.2 Setting Digital Time and Date

1. From the normal time display mode, press the**MODE** button repeatedly until the seconds start flashing. This indicates you are in setting mode.
2. Press the **RESET** button to cycle through the setting items: Seconds → Hours → Minutes → Month → Date → Day

of Week.

3. While an item is flashing, use the **START/STOP** button to adjust the value. Hold the button to change values quickly.
4. Once all settings are correct, press the **MODE** button to exit the setting mode and return to the normal time display.
5. To switch between 12-hour and 24-hour format, press the **START/STOP** button while the hour setting is flashing.

5. Operating Instructions

5.1 Using the LED Backlight

Press the **LIGHT** button (top left) to illuminate the digital display. The backlight will remain on for a few seconds.

5.2 Setting and Using the Alarm

1. Press the **MODE** button until "AL" (Alarm) appears on the digital display.
2. Press the **RESET** button to select the hour or minute setting. The selected value will flash.
3. Use the **START/STOP** button to adjust the hour or minute.
4. Press the **MODE** button to confirm the alarm time and exit setting mode.
5. To turn the alarm ON/OFF, press the **START/STOP** button while in the alarm display mode (without flashing digits). An alarm icon will appear/disappear.
6. When the alarm sounds, press any button to stop it.

5.3 Using the Stopwatch

1. Press the **MODE** button until "ST" (Stopwatch) appears on the digital display.
2. Press the **START/STOP** button to start the stopwatch.
3. Press the **START/STOP** button again to pause the stopwatch.
4. Press the **RESET** button to reset the stopwatch to zero while it is paused.
5. To return to normal time display, press the **MODE** button.

5.4 Dual Time Function

The watch supports a dual time display, allowing you to view a second time zone. The exact method to set and display the second time zone may vary slightly. Typically, you would:

1. Press the **MODE** button until you reach the Dual Time mode (often indicated by "DT" or a similar symbol).
2. Follow a similar procedure to setting the main digital time, using the **RESET** and **START/STOP** buttons to adjust the hours and minutes for the second time zone.
3. Press the **MODE** button to exit setting mode.

6. Water Resistance Guidelines

Your SMAEL SL-8080 watch is water-resistant up to 50 meters (5 ATM). This means it is suitable for everyday use, including splashes, rain, and brief immersion in water. However, please observe the following precautions:

- **Do NOT press any buttons underwater.** Pressing buttons underwater can compromise the watch's water resistance seals.
- Avoid exposing the watch to hot water or steam (e.g., hot showers, saunas, hot tubs). Extreme temperature changes can cause the seals to expand and contract, leading to water ingress.
- Do not use the watch for diving or snorkeling.
- After exposure to saltwater, rinse the watch with fresh water and dry it thoroughly.

Your browser does not support the video tag.

Video 1: Demonstration of SMAEL watch water resistance. This video illustrates the watch's ability to withstand water exposure up to 50 meters, suitable for daily activities but not for pressing buttons underwater or exposure to hot water/steam.

7. Maintenance

- **Cleaning:** Wipe the watch case and strap regularly with a soft, dry cloth. For stubborn dirt, use a slightly damp cloth and mild soap, then dry thoroughly.
- **Avoid Chemicals:** Do not expose the watch to solvents, detergents, perfumes, or cosmetic sprays, as these can damage the case, strap, or seals.
- **Battery Replacement:** When the display dims or the watch stops functioning, the battery may need replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure the water resistance is maintained.
- **Storage:** Store your watch in a cool, dry place away from direct sunlight and extreme temperatures when not in use.

8. Troubleshooting

- **Digital Display is Blank or Dim:**
  - The battery may be low or depleted. Replace the battery.
  - Ensure the watch has not been exposed to extreme temperatures or moisture that could affect the internal components.
- **Analog Hands Not Moving:**
  - Check if the **Pointer Adjustment** crown is pushed in completely. If it's pulled out, the hands will not move.
  - The battery for the analog movement might be depleted (some watches have separate batteries for analog and digital). Consult a technician.
- **Time is Inaccurate:**
  - Re-set both the analog and digital times following the instructions in Section 4.
  - Exposure to strong magnetic fields can affect watch accuracy. Keep the watch away from strong magnets.
- **Water Inside the Watch:**
  - If you notice condensation or water droplets inside the watch, immediately take it to a professional watch repair service. Do not attempt to open it yourself, as this can cause further damage.

9. Specifications

SMAEL SL-8080 Watch Specifications

Feature	Detail
Brand	SMAEL
Model Number	SL-8080
Movement Type	Quartz + Electronic (Japan Original Digital Movement)
Display Type	Analog-Digital
Water Resistance Depth	50 Meters (5 ATM)
Case Material	Plastic

Feature	Detail
Band Material	Silicone (PU)
Mirror Material	Acrylic (Mineral Glass)
Case Diameter	55 mm
Case Thickness	19 mm
Band Width	22 mm
Total Strap Length	255 mm
Clasp Type	Hook Buckle
Power Source	Battery Powered
Additional Features	Alarm, Light Up, Stopwatch, Water Resistant



Figure 4: Detailed Product Specifications

10. Warranty

The SMAEL SL-8080 Sport Watch comes with a**Lifetime Warranty**. This warranty covers manufacturing defects under normal use. It does not cover damage resulting from improper use, accidents, unauthorized repairs, or normal wear and tear. Please retain your proof of purchase for warranty claims.

11. Customer Support

For any questions, concerns, or technical assistance regarding your SMAEL SL-8080 Sport Watch, please contact our customer support team. Refer to the retailer's website or your purchase documentation for specific contact information. You can also visit the official SMAEL store for more information:SMAEL Official Store

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question