**De'Longhi EN 640.B**

# DeLonghi Nespresso Gran Lattissima EN 640.B Capsule Coffee Machine User Manual

Model: EN 640.B

## 1. Introduction

This manual provides essential information for the safe and efficient operation of your DeLonghi Nespresso Gran Lattissima EN 640.B coffee machine. Please read all instructions carefully before first use and retain this manual for future reference.




*Image 1.1: Front view of the DeLonghi Nespresso Gran Lattissima EN 640.B coffee machine. This image displays the sleek black design, the Nespresso capsule insertion area, the milk carafe, and the control panel with various beverage selection buttons.*

## 2. Safety Instructions

- Always ensure the machine is placed on a stable, flat surface.
- Do not immerse the machine, power cord, or plug in water or other liquids.

- Keep out of reach of children.
- Unplug the machine before cleaning and when not in use for extended periods.
- Do not operate the machine with a damaged cord or plug.
- Use only Nespresso capsules in this machine.

# 3. Setup and First Use

## 3.1 Unpacking

1. Carefully remove the machine from its packaging.
2. Remove all protective films and packaging materials.
3. Place the machine on a clean, dry, and stable surface.

## 3.2 Initial Rinse

1. Fill the water tank with fresh drinking water up to the 'MAX' level.
2. Place a container (at least 0.5L) under the coffee outlet.
3. Plug the machine into a grounded power outlet.
4. Press any coffee button to start the rinsing cycle. Repeat this process 2-3 times until clean water flows through.
5. Rinse the milk carafe and its components thoroughly with warm water.

## 3.3 Power Connection

Connect the power cord to the machine and then to a suitable wall socket. The machine will automatically turn on.

# 4. Operating Instructions

## 4.1 Turning On/Off

- To turn on: Press any coffee button. The buttons will flash while heating up and become steady when ready.
- To turn off: Press and hold any coffee button for 3 seconds. The machine will enter eco-mode after 9 minutes of inactivity.

## 4.2 Preparing Coffee (Espresso, Lungo)

1. Ensure the water tank is filled with fresh water.
2. Lift the lever to open the capsule insertion slot.






*Image 4.1: Top view of the DeLonghi Nespresso Gran Lattissima EN 640.B with the capsule insertion lid open. This image highlights the mechanism for placing a Nespresso capsule into the machine.*

3. Insert a Nespresso capsule into the slot and close the lever firmly.
4. Place a cup under the coffee outlet.
5. Press the desired coffee button (e.g., Espresso or Lungo). The machine will automatically stop when the selected volume is reached.
6. After brewing, lift and close the lever to eject the used capsule into the internal container.

## 4.3 Preparing Milk-Based Drinks (9 One-Touch Programs)

The Gran Lattissima offers 9 one-touch recipes including Cappuccino, Latte Macchiato, Flat White, Caffè Latte, Hot Milk,

and Hot Foam.

1. Fill the milk carafe with fresh, cold milk up to the desired level.
2. Attach the milk carafe to the machine. Ensure it is securely connected.
3. Lift the lever, insert a Nespresso capsule, and close the lever.
4. Place a suitable cup under the milk spout.
5. Press the button for your desired milk-based beverage. The machine will automatically prepare the drink.
6. After preparation, remove the milk carafe and clean it immediately (see Maintenance section).

# 5. Maintenance

## 5.1 Daily Cleaning

- **Empty Drip Tray and Used Capsule Container:** After each use, or when the 'empty' indicator appears, remove and empty the drip tray and used capsule container. Rinse them with warm water.
- **Clean Milk Carafe:** After each milk preparation, detach the milk carafe. Disassemble its components (lid, milk spout, suction tube) and rinse thoroughly under running water. For a more thorough clean, the components are dishwasher safe.
- **Wipe Exterior:** Wipe the machine's exterior with a soft, damp cloth.

## 5.2 Water Tank Cleaning

Periodically clean the water tank with warm water and a mild detergent. Rinse thoroughly to remove any soap residue.

## 5.3 Descaling

Descaling is crucial for maintaining machine performance and coffee quality. The descaling alert will illuminate when descaling is required. Refer to the full descaling instructions provided in the separate descaling guide or on the DeLonghi Nespresso website. Use only Nespresso descaling solution.

# 6. Troubleshooting

If you encounter issues with your machine, consult the following common problems and solutions:

| Problem | Possible Cause | Solution |
|---|---|---|
| No coffee flow | Water tank empty; machine not primed; clogged nozzle; descaling needed. | Fill water tank; perform initial rinse; clean coffee outlet; descale machine. |
| Milk not frothing correctly | Milk carafe dirty; incorrect milk type/temperature; milk spout clogged. | Clean milk carafe components thoroughly; use cold, fresh, semi-skimmed milk; clean milk spout. |
| Machine leaking | Water tank not correctly positioned; drip tray full. | Ensure water tank is seated correctly; empty and clean drip tray. |
| Machine does not turn on | No power; power cord not connected. | Check power outlet; ensure power cord is securely plugged in. |

# 7. Specifications

- **Brand:** De'Longhi

- **Model Number:** EN 640.B
- **Dimensions (L x W x H):** 36.7 x 20.3 x 27.6 cm
- **Weight:** 5.2 Kilograms
- **Water Tank Capacity:** 1.3 Liters
- **Power:** 1450 Watts
- **Voltage:** 240 Volts
- **Material:** Stainless Steel
- **System:** Nespresso
- **Features:** Programmable, Removable water tank, 9 One-Touch programs

## 8. Warranty and Support

Your DeLonghi Nespresso Gran Lattissima EN 640.B machine is covered by a manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions.

For further assistance, troubleshooting, or to purchase accessories and descaling kits, please visit the official DeLonghi or Nespresso website, or contact customer support:

- **DeLonghi Official Website:** www.delonghi.com
- **Nespresso Official Website:** www.nespresso.com
- **Customer Support:** Refer to your regional DeLonghi or Nespresso contact information.

© 2023 De'Longhi. All rights reserved.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question