Kitchen in the box BM01

Kitchen in the box Bread Maker Machine User Manual

Model: BM01 | Brand: Kitchen in the box

1. Important Safety Instructions

Please read all instructions carefully before using your Kitchen in the box Bread Maker Machine. Keep this manual for future reference.

- Always ensure the appliance is unplugged from the outlet before cleaning or when not in use.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Avoid contact with moving parts.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Do not touch hot surfaces. Use handles or knobs.
- This appliance is for household use only.

2. Product Components

Your Kitchen in the box Bread Maker Machine comes with the following components:

- 1 x Bread Machine Unit
- 1 x Non-stick Ceramic Pan
- 1 x Kneading Paddle
- 1 x Measuring Cup
- 1 x Measuring Spoon
- 1 x Hook (for removing kneading paddle)
- 1 x Instruction Manual (this document)
- 1 x Recipe Book



Figure 2.1: Included components of the bread maker machine.

3. Setup

Before first use, clean all removable parts (bread pan, kneading paddle, measuring cup, measuring spoon, hook) with warm, soapy water. Wipe the exterior of the machine with a damp cloth. Ensure all parts are completely dry before assembly.

3.1 Installing the Bread Pan and Kneading Paddle

1. Place the kneading paddle onto the shaft at the bottom of the bread pan. Ensure it is securely seated.
2. Insert the bread pan into the bread maker unit. Push down firmly and twist clockwise until it locks into place. To remove, twist counter-clockwise and lift.



Figure 3.1: Visual guide for adding ingredients and placing the bread pan.

4. Operating Instructions

The Kitchen in the box Bread Maker features an intuitive control panel and 15 pre-programmed settings for various bread types and functions.

4.1 Control Panel Overview



Figure 4.1: Detailed view of the control panel and menu options.

- **MENU Button:** Press to cycle through the 15 pre-programmed settings.
- **LOAF Button:** Selects the loaf size (1LB, 1.5LB, 2LB).
- **COLOR Button:** Adjusts crust darkness (Light, Medium, Dark).
- **START/STOP/PAUSE Button:** Initiates, pauses, or cancels a program.
- **+/- Buttons:** Adjust the delay timer for delayed baking.

4.2 Pre-programmed Settings

The bread maker offers 15 versatile programs:

No.	Program	Description
1	Soft Bread	For soft, fluffy bread.
2	Sweet Bread	For breads with high sugar content.

No.	Program	Description
3	Natural Sourdough	For authentic sourdough.
4	French Bread	For light, crispy crust French bread.
5	Whole-Wheat	For whole wheat flour breads.
6	Quick Bread	For quick baking cycles.
7	Sugar-Free	For sugar-free recipes.
8	Multigrain	For breads with various grains.
9	Milky Loaf	For milk-based loaves.
10	Cake	For baking cakes.
11	Raw Dough	Prepares dough for manual baking.
12	Leaven Dough	For leavened dough recipes.
13	Gluten-Free	Specifically for gluten-free recipes.
14	Bake	Baking only function.
15	Yogurt	For making homemade yogurt.

4.3 Basic Bread Making Steps

1. Add all ingredients to the bread pan according to your chosen recipe (refer to the included Recipe Book). Typically, liquids first, then dry ingredients, with yeast added last on top of the flour.
2. Place the bread pan into the machine and close the lid.
3. Plug in the bread maker. The display will light up.
4. Press the **MENU** button to select your desired program (e.g., '1' for Soft Bread).
5. Press the **LOAF** button to select the loaf size (1LB, 1.5LB, or 2LB).
6. Press the **COLOR** button to select your preferred crust darkness (Light, Medium, or Dark).
7. If using the delay timer, press the **+/-** buttons to set the desired delay time.
8. Press the **START/STOP/PAUSE** button to begin the baking process. The machine will automatically mix, knead, rise, and bake.
9. Once the program is complete, the machine will beep and enter the 1-hour automatic keep warm cycle.
10. Unplug the machine and carefully remove the bread pan using oven mitts. Allow the bread to cool on a wire rack before slicing.



Figure 4.2: Utilize the 15-hour delay timer for fresh bread at your convenience.



Figure 4.3: Choose from 3 loaf sizes and 3 crust colors.

5. Maintenance and Cleaning

Proper maintenance ensures the longevity and optimal performance of your bread maker.

- Always unplug the appliance and allow it to cool completely before cleaning.
- **Bread Pan and Kneading Paddle:** Hand wash only with warm, soapy water. Do not use abrasive cleaners or scouring pads as this may damage the non-stick coating.
- **Exterior:** Wipe with a dry cloth. Do not use harsh chemicals or immerse the main unit in water.
- **Interior:** Wipe the interior of the baking chamber with a soft, damp cloth.
- Ensure all parts are thoroughly dry before storing or next use.

6. Troubleshooting

If you encounter issues with your bread maker, please refer to the following common solutions. For more detailed troubleshooting, consult the Recipe Book or contact customer support.

Problem	Possible Cause / Solution
Bread does not rise	Check yeast freshness, water temperature (too hot/cold), or ingredient measurements. Ensure correct program selected.
Kneading paddle stuck in bread	Use the provided hook tool to carefully remove the paddle after baking and cooling.
Bread pan difficult to remove	Ensure the pan is twisted counter-clockwise to unlock before lifting. It may be stiff when new.
Machine not starting	Check if plugged in correctly. Ensure the bread pan is properly seated. Press START/STOP/PAUSE button firmly.

7. Specifications

Detailed technical specifications for the Kitchen in the box Bread Maker Machine:

- **Model Number:** BM01
- **Brand:** Kitchen in the box
- **Color:** Silver
- **Product Dimensions:** 12.8"D x 10.3"W x 11.3"H
- **Item Weight:** 15.07 pounds
- **Wattage:** 710 watts
- **Number of Programs:** 15
- **Loaf Capacity:** 1LB, 1.5LB, 2LB
- **Crust Options:** Light, Medium, Dark
- **Delay Timer:** Up to 15 hours
- **Keep Warm Function:** 1 hour automatic
- **Power Failure Backup:** 15 minutes
- **Material:** Full Stainless Steel exterior
- **Pan Material:** Non-stick Ceramic
- **Noise Level:** Less than 40 dB

8. Warranty and Support

Kitchen in the box is committed to providing high-quality products and customer satisfaction. Your bread maker machine is covered by an after-sales guarantee.

- For any questions, concerns, or warranty claims, please contact Kitchen in the box customer service.
- Please retain your proof of purchase for warranty validation.

© 2024 Kitchen in the box. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

I am using the Bake option on my Kitchen in the box BM01 Bread Maker and the lights are blinking while the clock is ticking down. Is this normal?

Yes, this behavior is generally normal for the Kitchen in the box BM01 Bread Maker. When a program is active, the display typically shows the remaining time counting down, and an indicator light or...

Read full answer

What are the ingredient amounts and mixtures required to make bread in the Kitchen in the box BM01 Bread Maker?

The Kitchen in the box BM01 bread maker includes a dedicated Recipe Book in the box that contains specific measurements for various loaf sizes (1LB, 1.5LB, and 2LB). While the manual does not list...

Read full answer