ENUOLI nXLC.32W

ENUOLI Mini Strobe Light

Model: nXLC.32W

1. Important Safety Information

Please read and understand all safety instructions before using this product. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Indoor Use Only:** This device is designed for indoor use. Do not expose to moisture, rain, or use in damp environments.
- **Power Source:** Connect only to a grounded 110V AC power outlet. Ensure the power cord is not damaged or pinched.
- **Ventilation:** Ensure adequate ventilation around the unit. Do not block ventilation openings.
- **Temperature:** Operate within a temperature range of 0°C to 40°C (32°F to 104°F).
- **Cleaning:** Disconnect from power before cleaning. Use a soft, dry cloth. Do not use liquid cleaners.
- **Repairs:** Do not attempt to repair this unit yourself. Refer all servicing to qualified personnel.
- **Eye Safety:** Avoid direct eye exposure to the light source, as it can be intense.

2. Product Overview

The ENUOLI Mini Strobe Light (Model nXLC.32W) is a compact and portable lighting unit featuring 32 super bright LED bulbs. It is designed to produce a variable flash effect, suitable for various indoor events and decorative purposes. The unit includes an adjustable bracket for flexible positioning.



Figure 2.1: Front view of the ENUOLI Mini Strobe Light, showcasing its 32 LED bulbs.

3. Setup

Follow these steps to set up your ENUOLI Mini Strobe Light:

1. **Unpack:** Carefully remove the strobe light from its packaging.
2. **Placement:** Choose a suitable indoor location for the strobe light. The integrated bracket allows for various mounting options, such as placing it on a flat surface or hanging it from a truss or ceiling.
3. **Adjust Angle:** Loosen the screws on the sides of the bracket to adjust the light's angle. Tighten the screws once the desired angle is achieved.
4. **Power Connection:** Ensure the speed control knob is set to the minimum (off) position. Plug the power cord into a standard 110V AC power outlet.



Figure 3.1: Product dimensions and adjustable bracket detail. The light measures approximately 4.3 inches (11 cm) in length, 3.3 inches (8.5 cm) in width, and 2 inches (5 cm) in height.

4. Operation

Operating the ENUOLI Mini Strobe Light is straightforward:

1. **Power On:** Once plugged in, the unit is ready for operation.
2. **Adjust Flash Speed:** Locate the variable speed control knob on the back of the unit. Rotate the knob clockwise to increase the flash speed (from slow to fast) and counter-clockwise to decrease it. Turning the knob fully counter-clockwise will turn the light off.



Figure 4.1: Detail of the adjustable speed control knob and power cable connection.

Demonstration Video

Video 4.1: This video demonstrates the ENUOLI Mini Strobe Light in operation, showcasing its adjustable flash speed and bright LED output. It highlights how the light can enhance various festive settings.

5. Maintenance

Proper maintenance ensures the longevity and optimal performance of your strobe light:

- **Cleaning:** Regularly wipe the exterior of the unit with a soft, dry, lint-free cloth. Do not use abrasive cleaners or solvents. Ensure the unit is unplugged before cleaning.
- **Storage:** When not in use, store the strobe light in a cool, dry place, away from direct sunlight and excessive dust.
- **Inspection:** Periodically inspect the power cord for any signs of damage. If damage is found, discontinue use and contact customer support.

6. Troubleshooting

If you encounter issues with your ENUOLI Mini Strobe Light, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	No power supply or loose connection.	Ensure the power cord is securely plugged into a working 110V AC outlet. Check if the speed control knob is turned to an 'on' position.
Light is not flashing.	Speed control knob set to minimum or off.	Rotate the speed control knob clockwise to increase the flash rate.
Flash speed is inconsistent.	Fluctuating power supply or internal issue.	Try plugging the unit into a different power outlet. If the issue persists, contact customer support.
Unit gets hot during operation.	Normal operation or insufficient ventilation.	The unit is designed for low power consumption and should not overheat. Ensure ventilation openings are not blocked. If it becomes excessively hot, discontinue use and contact support.

7. Specifications

Feature	Detail
Model Number	nXLC.32W
Light Source	32 LED Bulbs
Power Source	Corded Electric (110 Volts)
Wattage	10 Watts
Material	Plastic
Dimensions (L x W x H)	4.3" x 3.3" x 2" (11cm x 8.5cm x 5cm)
Item Weight	0.34 lbs (0.15 kg)
Control	Variable Flash Speed Knob
Mounting Type	Bracket Mount

8. Warranty and Support

For warranty information or technical support, please contact ENUOLI customer service. Keep your purchase receipt as proof of purchase.
Manufacturer: ENUOLI LIGHT
For further assistance, visit the ENUOLI Store on Amazon.

© 2026 ENUOLI. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question