De'Longhi EC9335R

De'Longhi La Specialista Espresso Machine User Manual

Model: EC9335R
Brand: De'Longhi

1. Introduction and Overview

This manual provides comprehensive instructions for the safe and efficient operation, maintenance, and troubleshooting of your De'Longhi EC9335R La Specialista Espresso Machine. This machine is designed to allow users to precisely craft espresso and coffee beverages with advanced features such as Sensor Grinding Technology, a Smart Tamping Station, a Dual Heating System, and an Advanced Latte System.



Figure 1.1: De'Longhi EC9335R La Specialista Espresso Machine and included double-walled latte glasses.

2. Important Safety Information

Please read all instructions carefully before using the appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Ensure the appliance is connected to a grounded power outlet with the correct voltage.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Keep hands and fingers away from hot surfaces and steam during operation. Use handles and knobs.
- Unplug the machine from the outlet when not in use and before cleaning. Allow it to cool before handling parts.
- Do not operate the appliance with a damaged cord or plug, or if it malfunctions or has been damaged in any way.
- Use only cold, fresh water in the water tank. Do not use hot water or other liquids.
- Regularly descale the machine as instructed to prevent mineral buildup.
- Keep out of reach of children.

3. Product Components

Familiarize yourself with the various parts of your espresso machine and accessories:

- **Bean Hopper:** Located at the top, for whole coffee beans.
- **Integrated Grinder:** Grinds beans directly into the portafilter.
- **Portafilter:** Holds ground coffee for brewing.
- **Smart Tamping Station:** Integrated lever for consistent tamping.
- **Water Tank:** Removable tank for water supply.
- **Steam Wand/Advanced Latte System:** For frothing milk.
- **Hot Water Spout:** Dispenses hot water for Americanos or tea.
- **Drip Tray:** Collects excess liquid.
- **Control Panel:** Buttons and dials for operation.
- **Double-Walled Thermo Latte Glasses:** Included accessories for serving.



Figure 3.1: Detailed view of the espresso machine's front panel and components.



Figure 3.2: Exploded diagram illustrating the machine's various parts and accessories.



Figure 3.3: The included double-walled thermo latte glasses.

4. Setup

1. **Unpacking:** Carefully remove all packaging materials and ensure all components are present.

2. **Placement:** Place the machine on a stable, flat surface, away from heat sources and water. Ensure adequate ventilation.
3. **Water Tank:** Remove the water tank, rinse it, and fill it with fresh, cold water up to the MAX level. Reinsert it securely.
4. **Bean Hopper:** Fill the bean hopper with your preferred whole coffee beans. Ensure the lid is properly sealed.
5. **Initial Rinse Cycle:** Before first use, perform an initial rinse cycle to clean the internal circuits. Refer to the quick start guide for specific steps, typically involving running hot water through the steam wand and coffee spout without coffee.

5. Operating Instructions

5.1. Sensor Grinding Technology

The integrated grinder uses sensor technology to deliver a precise and consistent dose of ground coffee. Adjust the grind setting according to your preference (finer for espresso, coarser for other methods).

1. Select the desired grind size using the dial on the bean hopper.
2. Insert the portafilter into the grinding cradle.
3. Press the grind button to start grinding. The sensor will automatically stop when the optimal dose is reached.

5.2. Smart Tamping Station

Achieve perfect tamping without removing the portafilter, ensuring optimal coffee extraction.

1. After grinding, ensure the portafilter is securely in the grinding cradle.
2. Pull the tamping lever down firmly until it clicks, then release. This applies the correct pressure for an even tamp.

5.3. Espresso Extraction (Active Temperature Control)

The dual heating system ensures optimal temperature stability for brewing and steaming, allowing simultaneous preparation.

1. Insert the tamped portafilter into the brewing group and lock it into place.
2. Place your cup(s) under the coffee spouts.
3. Select your desired espresso shot size (single or double) using the control panel. The machine will automatically brew.

5.4. Advanced Latte System

Create perfect milk texture for lattes and cappuccinos.

1. Fill a milk pitcher with cold milk.
2. Position the steam wand into the milk.
3. Select your desired froth style (Flat or Foam) using the steam wand selector.
4. Activate the steam function. The system will automatically froth the milk to the desired texture.
5. Once complete, turn off the steam and clean the wand immediately.

5.5. Hot Water Spout

Use the dedicated hot water spout for Americanos or tea.

1. Place a cup under the hot water spout.
2. Activate the hot water function on the control panel.

3. Dispense the desired amount of hot water.



Figure 5.1: Preparing an Americano using the hot water spout.

6. Maintenance and Cleaning

Regular cleaning and maintenance are crucial for the longevity and performance of your espresso machine.

- **Drip Tray:** Empty and clean the drip tray daily or when the indicator shows it's full. Wash with warm, soapy water.
- **Portafilter:** After each use, remove spent coffee grounds and rinse the portafilter and filter basket under hot water.
- **Steam Wand:** Immediately after frothing milk, wipe the steam wand with a damp cloth to remove any milk residue. Purge the wand briefly to clear any internal blockages.
- **Grinder:** Periodically clean the grinder burrs and chute to prevent buildup of coffee oils and grounds. Refer to the full manual for detailed instructions.
- **Descaling:** The machine will indicate when descaling is required. Use a De'Longhi descaling solution and follow the instructions provided with the descaler. This removes mineral buildup and maintains optimal performance.

- **Water Tank:** Clean the water tank regularly with warm, soapy water and rinse thoroughly.
- **Latte Glasses:** The double-walled thermo latte glasses are dishwasher safe for easy cleaning.



Figure 6.1: A latte served in a double-walled glass.

7. Troubleshooting

If you encounter issues with your De'Longhi La Specialista, refer to the common problems and solutions below. For more complex issues, contact customer support.

Problem	Possible Cause	Solution
No coffee dispenses.	Water tank empty; brewing group clogged; machine not primed.	Fill water tank; clean brewing group; perform initial rinse cycle.
Coffee is too weak/watery.	Grind too coarse; insufficient coffee dose; tamping too light.	Adjust grind to finer setting; ensure proper dose; tamp firmly.
No steam from wand.	Wand clogged; machine not heated to steam temperature.	Clean steam wand; wait for steam indicator light; purge wand.
Machine leaks water.	Water tank not seated correctly; drip tray full; internal seal issue.	Reseat water tank; empty drip tray; contact support if persistent.
Grinder not working.	Bean hopper empty; beans jammed; grinder clogged.	Fill bean hopper; clear any jammed beans; clean grinder.

8. Specifications

- **Brand:** De'Longhi
- **Model:** EC9335R La Specialista
- **Color:** Red
- **Special Feature:** Advanced Latte System, Sensor Grinder, Dual Heating System
- **Coffee Maker Type:** Espresso Machine
- **Filter Type:** Reusable
- **Included Components:** Milk Frother, Latte Glasses (Set of 2, 330ml each)
- **Operation Mode:** Fully Automatic
- **Human Interface Input:** Buttons
- **Water Tank Capacity:** Approximately 67.6 oz (2 liters)

9. Warranty and Support

The De'Longhi EC9335R La Specialista Espresso Machine comes with a standard warranty. Product registration may extend your warranty. Please refer to the official De'Longhi website or the warranty card included in your product packaging for the most current and detailed warranty information.
For technical support, service, or to order replacement parts, please visit the official De'Longhi support page or contact their customer service directly. Keep your proof of purchase and model number (EC9335R) ready when contacting support.
Warranty Information: 2+1=3 Years Warranty with Product Registration.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question