**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**RAINPOINT 105**

# RAINPOINT Sprinkler Timer Model 105 Instruction Manual

Brand: RAINPOINT | Model: 105

## Introduction

The RAINPOINT Sprinkler Timer Model 105 is designed for automated garden watering, providing convenience and efficiency for your irrigation needs. This manual provides comprehensive instructions for the installation, programming, operation, and maintenance of your sprinkler timer to ensure optimal performance and longevity.




Image: The RAINPOINT Sprinkler Timer Model 105, a programmable water timer for garden hoses.

## Setup

1. **Unpacking:** Carefully remove the timer from its packaging. Ensure all components are present.
2. **Battery Installation:** The timer requires two AA batteries (not included). Open the battery compartment on the back of the unit, insert the batteries according to the polarity markings, and securely close the compartment. The large LCD screen will display information once batteries are installed.
3. **Connecting to Faucet:**
   - Ensure the faucet is off.
   - Screw the timer's brass swivel inlet onto your outdoor garden hose faucet. Hand-tighten only to prevent damage.
   - Connect your garden hose to the outlet of the timer.

- Turn on the faucet. The timer is designed with a 360° brass inlet and internal filter to be leak-proof and durable.

4. **Initial Time Setting:** Rotate the dial to the "SET CLOCK" position. Use the "+" and "-" buttons to adjust the current time. Press "OK" to confirm the setting.




Image: A hand adjusting the 'HOW LONG' setting on the timer's display, demonstrating easy setup.

# Operating Instructions

The RAINPOINT Sprinkler Timer offers various programming options and manual control for flexible watering.

1. **Setting Start Time:** Rotate the dial to "START TIME". Use the "+" and "-" buttons to set the desired watering start time. Press "OK" to confirm.
2. **Setting Watering Duration (How Long):** Rotate the dial to "HOW LONG". Use the "+" and "-" buttons to set the watering duration from 1 minute to 8 hours. Press "OK" to confirm.
3. **Setting Watering Frequency (How Often):** Rotate the dial to "HOW OFTEN". Use the "+" and "-" buttons to set the watering frequency (e.g., every 1 day, every 2 days, or specific days of the week). Press "OK" to confirm.
4. **Activating Program:** Rotate the dial to the "ON" position to activate your programmed watering schedule. The timer will now operate according to your settings.
5. **Manual Watering:** To water immediately without interrupting your set program, rotate the dial to "ON". Press the "MANUAL" button. Use the "+" and "-" buttons to set the desired manual watering duration. Press "OK" to start. To stop manual watering, press "MANUAL" again or rotate the dial to "OFF".
6. **Rain Delay Function:** If rain is expected or occurring, you can temporarily pause your watering schedule. Rotate the dial to "ON". Press the "DELAY" button. Use the "+" and "-" buttons to select a delay period of 24, 48, or 72 hours. The timer will automatically resume its schedule after the selected delay period.




Image: The timer's display showing a custom watering cycle set to 'Every 03 Days', highlighting flexible programming options.




Image: The timer's display showing a 'delay 24 H' setting, indicating the rain delay feature is active.

## Maintenance

- **Battery Replacement:** When the low-battery indicator appears on the LCD screen, replace the batteries promptly. The

valve will automatically close if the battery level is critically low to prevent continuous watering and conserve water.

- **Filter Cleaning:** Periodically check and clean the built-in metal filter at the water inlet to prevent debris from clogging the timer and ensure optimal water flow. Unscrew the timer from the faucet, remove the filter, rinse it under running water, and reinsert it.
- **Winterization:** Before freezing temperatures occur, disconnect the timer from the faucet and hose. Remove the batteries. Store the timer indoors in a dry, frost-free location to prevent damage from ice expansion.



Image: Close-up of the timer's battery compartment and a visual representation of its IP65 waterproof and dustproof rating.

## Troubleshooting

- **No Water Flow:**
  - Check if the faucet is fully open.
  - Ensure batteries are installed correctly and have sufficient charge. Replace if necessary.
  - Verify the program is set to "ON" and a watering schedule is active, or manual mode is engaged.
  - Clean the inlet filter for any blockages.
- **Leaking from Connections:**
  - Ensure all connections (faucet to timer, timer to hose) are hand-tightened securely.
  - Check for damaged washers or O-rings and replace if necessary.
  - Ensure the brass swivel is properly seated.
- **Timer Not Responding:**
  - Replace batteries with new ones.
  - Try resetting the timer by removing batteries for a few minutes and reinserting them.
- **Inaccurate Watering Times:**
  - Re-check your programmed "HOW LONG" and "HOW OFTEN" settings.
  - Ensure the clock is set to the correct current time.

## Specifications

| Feature | Detail |
|---|---|
| Brand | RAINPOINT |
| Model Number | 105 |
| Material | Metal (Brass Swivel) |
| Color | Green |
| Product Dimensions | 1"D x 1"W x 1"H |
| Number of Settings | 9 |
| Watering Duration | 1 minute to 8 hours |
| Watering Frequency | Daily, every few days, or specific days |
| Max. Working Pressure | 180 psi |
| Weather Resistance | IP65 |

## Warranty and Support

This RAINPOINT product is covered by a manufacturer's warranty. For specific warranty details, product support, or technical assistance, please refer to the documentation included with your purchase or visit the official RAINPOINT website. You can often find additional resources, FAQs, and contact information on the manufacturer's support pages.

© 2023 RAINPOINT. All rights reserved.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question



**Open the live page**

**https://manuals.plus/asin/B0C4D9ZVGQ**

More documents and user manuals: **https://manuals.plus/**