SCHLEICH 42593 & 42541

SCHLEICH Horse Club Playset User Manual

Models: 42593 Caravan for Secret Club Meetings & 42541 Lisa & Storm

Introduction

Welcome to the world of SCHLEICH Horse Club! This user manual provides essential information for the assembly, operation, and care of your SCHLEICH 42593 Caravan for Secret Club Meetings and 42541 Lisa & Storm playsets. These sets are designed for children aged 5-12 years, offering imaginative play scenarios centered around horse adventures and secret club gatherings.



Image: The complete SCHLEICH Horse Club bundle, featuring the detailed caravan playset and the Lisa & Storm horse and rider figures.

What's Included

Your SCHLEICH Horse Club bundle includes the following components:

- **SCHLEICH 42593 Caravan for Secret Club Meetings:**
  - Caravan structure with wheels
  - Removable roof (doubles as horse shelter)
  - Interior furniture (e.g., sofa, table)
  - Various accessories (e.g., cushions, umbrella, ladder, campfire, bucket, hay bale)
  - Additional figures (e.g., squirrel)
- **SCHLEICH 42541 Lisa & Storm:**
  - Fully movable Lisa figure
  - Storm horse figure (Hanoverian gelding)
  - Horse tack (bridle, saddle)
  - Lisa's riding helmet

Setup

The SCHLEICH Horse Club playsets require minimal assembly. Follow these steps to prepare your playset for use:

1. **Unpacking:** Carefully remove all components from the packaging. Ensure all listed items are present.
2. **Caravan Assembly:**
    - Attach any loose parts to the caravan as indicated in the visual guides (e.g., wheels if detached, roof, ladder). The roof is designed to be removable and can be used as a separate horse shelter.
    - Place interior furniture and accessories within the caravan as desired. Many items can be stored inside the caravan for portability.



Image: The SCHLEICH Horse Club Caravan playset, showing its detailed interior and various accessories like the campfire, bucket, and hay bale.

3. **Lisa & Storm Preparation:**
    - Attach the bridle and saddle to the Storm horse figure.
    - Place the riding helmet on the Lisa figure.
    - The Lisa figure is fully movable, allowing for various poses and interaction with the horse and caravan.





Image: Close-up of the SCHLEICH Horse Club Lisa figure mounted on her horse, Storm, with saddle and bridle.

Operating the Playset

The SCHLEICH Horse Club playsets are designed for imaginative play. Here are some key features and how to interact with them:

- **Caravan Features:**
    - **Removable Roof:** The caravan's roof can be easily removed and placed on the ground to create a horse

shelter, providing a versatile play environment.

- **Movable Parts:** The caravan features functional elements such as a foldable table, movable window shutters, and doors that open and close.
- **Storage:** All figures and accessories can be stored inside the caravan, making it easy to pack up and transport for play on the go.



Image: The SCHLEICH Horse Club Caravan with its roof detached and positioned as a horse shelter, demonstrating its dual functionality.

- **Lisa & Storm Interaction:**

- **Articulated Figure:** The Lisa figure is fully articulated, allowing her to sit on Storm, stand, and interact with other elements of the playset.
- **Removable Tack:** The saddle and bridle on Storm are removable, enabling different play scenarios.





Image: The SCHLEICH Horse Club Lisa figure demonstrating her movable joints, allowing for dynamic posing.

Maintenance

To ensure the longevity and cleanliness of your SCHLEICH Horse Club playsets, follow these simple maintenance guidelines:

- **Cleaning:** Wipe figures and playset components with a damp cloth. Do not use harsh chemicals or abrasive cleaners, as these may damage the paint or plastic.
- **Storage:** Store the playset in a clean, dry place away from direct sunlight and extreme temperatures to prevent fading or warping.
- **Handling:** Handle figures and small accessories with care to prevent breakage.

Troubleshooting

If you encounter any issues with your SCHLEICH Horse Club playset, refer to the following common solutions:

Problem	Possible Cause	Solution
Figure parts not moving smoothly.	Dust or debris in joints.	Gently clean joints with a soft, dry brush. Avoid forcing movement.
Accessories do not fit correctly.	Incorrect orientation or minor manufacturing variation.	Ensure accessories are aligned correctly. Do not force. If a part is consistently ill-fitting, contact customer support.
Playset appears unstable.	Parts not fully connected or placed on an uneven surface.	Verify all caravan components are securely attached. Ensure the playset is on a flat, stable surface.

Specifications

Key specifications for the SCHLEICH Horse Club Playset Bundle:

- **Product Models:** 42593 (Caravan for Secret Club Meetings), 42541 (Lisa & Storm)
- **Recommended Age:** 5-12 years
- **Material:** High-quality plastic
- **Color:** Multi-color (Caravan primarily white/red/turquoise, Lisa & Storm figures as depicted)
- **Assembly Required:** No (minimal setup of components)
- **ASIN:** B0C6K4SKNZ

Warranty and Support

SCHLEICH products are manufactured with high standards of quality. For any questions, concerns, or issues regarding your playset, please contact SCHLEICH customer support.

- **Manufacturer:** SCHLEICH
- **Website:** www.schleich-s.com (Please refer to the official website for regional contact information and warranty details.)
- **Return Policy:** As per retailer's policy (e.g., Amazon's 14-day return policy mentioned in product data).

Note: Warranty terms may vary by region and retailer. Please retain your proof of purchase.

© 2024 SCHLEICH. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question