Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Azwok AN-MR700

Azwok AN-MR700 USB Magic Remote Control User Manual

Replacement Remote for LG OLED Smart TVs

1. Introduction

This manual provides instructions for the Azwok AN-MR700 USB Magic Remote Control, a replacement unit designed for use with various LG OLED Smart TV models. This remote control offers the primary functions of the original AN-MR700 remote, enabling convenient operation of your television.

2. Product Overview





Image 1: The Azwok AN-MR700 USB Magic Remote Control, featuring a silver lower body and a black upper section with various control buttons. A compact USB dongle is also shown, which is essential for the remote's functionality.

The Azwok AN-MR700 remote control is designed to replicate the functionality of the original LG AN-MR700. It features a standard layout including a numeric keypad, volume and channel controls, navigation buttons, and dedicated buttons for popular streaming services. A USB dongle is included and required for the remote to communicate with your television.

3. Setup

3.1. Battery Installation

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover open in the direction indicated by the arrow.

3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover, sliding it until it clicks securely into place.

3.2. Connecting the USB Dongle

The AN-MR700 remote control requires the included USB dongle for operation. This dongle facilitates communication between the remote and your LG Smart TV.

1. Ensure your LG Smart TV is powered on.
2. Locate an available USB port on your LG Smart TV.
3. Insert the provided USB dongle firmly into the USB port.
4. The remote control should automatically pair with the TV. No manual programming is typically required.

Note: *If the remote does not respond after inserting the dongle and batteries, ensure the dongle is fully inserted and the batteries are correctly oriented. Some TV models may require a brief moment for the connection to establish.*

4. Operating Instructions

This section details the primary functions of the buttons on your Azwok AN-MR700 remote control.

- **Power Button ( ):** Turns the TV on or off.
- **Input/Source Button ( ):** Switches between different input sources (e.g., HDMI 1, HDMI 2, TV).
- **Numeric Keypad (0-9):** Used for direct channel selection or entering numbers.
- **LIST:** Displays a list of channels or other content.
- **QUICK ACCESS:** Provides quick access to frequently used apps or functions.
- **Volume Up/Down (+/-):** Adjusts the audio volume.
- **Mute (⏏):** Mutes or unmutes the TV audio.
- **Channel Up/Down (P^/Pˇ):** Changes TV channels.
- **Navigation Buttons (Up, Down, Left, Right):** Navigates through menus and options.
- **OK/Scroll Wheel:** Confirms selections and can be used to scroll through content.
- **RECENTS (⌂):** Accesses recently viewed content or applications.
- **Settings (⚙):** Opens the TV's settings menu.
- **BACK/EXIT:** Returns to the previous screen or exits a menu.
- **GUIDE:** Displays the electronic program guide.
- **Dedicated App Buttons (NETFLIX, Amazon, Movies, Disney+):** Provides direct access to these streaming services.
- **Media Control Buttons (Play, Pause):** Controls playback of media content.
- **Colored Buttons (Red, Green, Yellow, Blue):** These buttons typically perform specific functions within certain applications or menus, as indicated on-screen.

5. Maintenance

5.1. Cleaning

To clean the remote control, gently wipe it with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the remote's surface or

internal components.

5.2. Battery Replacement

Replace the batteries when the remote control becomes unresponsive or its range decreases significantly. Always replace both AAA batteries at the same time with new ones. Do not mix old and new batteries, or different types of batteries.

5.3. Storage

When not in use for extended periods, it is recommended to remove the batteries from the remote control to prevent potential leakage and damage. Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.

6. Troubleshooting

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace the batteries with fresh AAA batteries.
  - Ensure the USB dongle is securely plugged into a USB port on your TV.
  - Try plugging the USB dongle into a different USB port on your TV.
  - Ensure there are no obstructions between the remote control and the TV.
- **Specific buttons not working:**
  - This may indicate a faulty button or low battery power. Try replacing the batteries.
- **Remote control range is reduced:**
  - This is typically a sign of low battery power. Replace the batteries.

If issues persist after following these steps, please refer to the Warranty and Support section for further assistance.

7. Specifications

Model Number	AN-MR700 (RM-AN-MR700-LG106)
Brand	Azwok
Compatible Devices	LG OLED Smart Televisions (various models, see product description for list)
Power Source	2 x AAA Batteries (not included)
Color	Black
Product Dimensions	9.45 x 2.36 x 1.06 inches
Item Weight	4.9 ounces

8. Warranty and Support

8.1. Warranty Information

This Azwok AN-MR700 remote control comes with a 12-month warranty from the date of purchase. This warranty covers manufacturing defects and ensures replacement or refund if the product fails to function as intended under normal use. Please retain your proof of purchase for warranty claims.

8.2. Customer Support

If you encounter any issues not covered in the troubleshooting section, or if you require assistance with compatibility or warranty claims, please contact Azwok customer support. Contact details are typically available through your purchase platform or the retailer from whom you purchased the product.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C4JKSRRZ

More documents and user manuals: **https://manuals.plus/**