Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

eufy T2276

eufy X8 Pro Robot Vacuum Self-Empty Station User Manual

Model: T2276

1. Introduction

The eufy X8 Pro Robot Vacuum with Self-Empty Station is designed to provide an efficient and hands-free cleaning experience for your home. Equipped with Twin-Turbine 2x 4,000 Pa suction power, iPath Laser Navigation, and a unique Tangle-Free Roller Brush, it offers deep cleaning, especially effective for pet hair, and automatically empties its dustbin for up to 45 days of maintenance-free operation.

2. Setup

Follow these steps for initial setup of your eufy X8 Pro Robot Vacuum:

1. **Unboxing:** Carefully remove all components from the packaging. Ensure all accessories are present.
2. **Charging Station Placement:** Place the Self-Empty Station against a wall on a hard, level surface. Ensure there is at least 1.5 ft (0.5 m) of clear space on either side and 5 ft (1.5 m) in front of the station for optimal navigation.
3. **Power Connection:** Connect the power adapter to the charging station and plug it into a wall outlet.
4. **Initial Charge:** Place the robot vacuum onto the charging station. The indicator lights on the robot and station will illuminate to confirm charging. Fully charge the robot before first use (approximately 6 hours).
5. **App Download & Connection:** Download the 'eufy Clean' app from your mobile app store. Follow the in-app instructions to connect your eufy X8 Pro to your home Wi-Fi network.
6. **Initial Mapping:** Once connected, initiate a full cleaning cycle through the app. The robot will begin mapping your home using its iPath Laser Navigation system. This map will be saved for future cleaning sessions.



Figure 2.1: The eufy X8 Pro Robot Vacuum, its Self-Empty Station, and the accompanying mobile application interface.

3. Operating Instructions

Your eufy X8 Pro offers various cleaning modes and smart features for tailored cleaning.

3.1 Starting a Clean

- **Manual Start:** Press the power button on the robot to start an auto-clean cycle.
- **App Control:** Use the 'eufy Clean' app to start, pause, or stop cleaning. You can also select specific cleaning modes or areas.

3.2 Cleaning Modes

- **Auto Clean:** The robot intelligently cleans your entire home based on the mapped layout.
- **Spot Clean:** Direct the robot to clean a specific area with concentrated suction.

- **Zone Clean:** Define custom cleaning zones on the app's map for targeted cleaning.

3.3 Smart Navigation and Mapping

The eufy X8 Pro utilizes **iPath Laser Navigation** and **AI.Map 2.0** for precise mapping and efficient cleaning routes.

- **Real-time Mapping:** The robot creates and updates a detailed map of your home, allowing it to track its cleaning path and avoid obstacles.
- **Customizable Maps:** Through the app, you can set **No-Go Zones** to restrict access to certain areas, create **virtual boundaries**, and define specific rooms for cleaning.



Figure 3.1: The robot vacuum employing iPath Laser Navigation to accurately map its surroundings and plan efficient cleaning paths.



Figure 3.2: Illustration of the Twin-Turbine 2x 4,000 Pa suction power effectively lifting debris from carpet fibers.

3.4 Suction Power

The **Twin-Turbine 2x 4,000 Pa suction** provides powerful cleaning, especially for embedded dirt and pet hair in carpets. You can adjust suction levels via the app for different floor types and cleaning needs.

4. Maintenance

Regular maintenance ensures optimal performance and longevity of your eufy X8 Pro.

4.1 Self-Empty Station

- The 2.5L dust bag in the Self-Empty Station allows for up to 45 days of hands-free cleaning, depending on usage and pet hair volume.
- Replace the dust bag when the indicator on the station or app notifies you.



Figure 4.1: The Self-Empty Station automatically transfers collected debris from the robot's internal dustbin into a larger, sealed bag.

4.2 Tangle-Free Roller Brush

- The Pro-Detangle Comb automatically removes entwined hair from the roller brush after each cleaning cycle, minimizing manual intervention.
- Periodically check the roller brush for any remaining debris and clean as needed.



Figure 4.2: Visual comparison demonstrating the superior hair detangling rate of the eufy X8 Pro's roller brush.



Figure 4.3: The roller brush reverses direction, and the Pro-Detangle Comb flips down to loosen wrapped hair.

4.3 Dust Bin and Filter

- Although the robot self-empties, occasionally check the internal dust bin for any blockages.
- Clean the washable filter regularly to maintain suction performance. Allow it to air dry completely before reinserting.

4.4 Sensors and Charging Contacts

- Wipe the sensors (cliff sensors, anti-collision sensors) and charging contacts on both the robot and the station with a clean, dry cloth to ensure proper function.

5. Troubleshooting

If you encounter issues with your eufy X8 Pro, refer to the following common solutions:

Problem	Possible Cause	Solution
Robot does not charge.	Charging contacts are dirty or misaligned.	Clean charging contacts on both robot and station. Ensure robot is properly docked.
Poor suction or debris left behind.	Dust bin full, filter clogged, or roller brush tangled.	Check if the self-empty station bag needs replacement. Clean the dust bin and filter. Clear any tangles from the roller brush.
Robot gets stuck frequently.	Obstacles in path, dark surfaces, or dirty sensors.	Clear obstacles. Use No-Go Zones in the app. Clean cliff sensors.
Robot does not connect to Wi-Fi.	Incorrect Wi-Fi password, router issues, or out of range.	Verify password. Restart router. Ensure robot is within Wi-Fi range. Try re-pairing via the app.
Self-empty function not working.	Dust bag full or port blocked.	Replace the dust bag. Check the dust transfer port for blockages.

For more detailed troubleshooting, refer to the 'eufy Clean' app or the full user manual PDF.

6. Specifications

Feature	Description
Brand	eufy
Model Name	X8 Pro SES
Item Model Number	T2276
UPC	194644136741
Special Features	Active Detangling Roller Brush, Self-Emptying, Twin-Turbine 2× 4,000 Pa Powerful Suction, iPath Laser Navigation
Color	Black
Product Dimensions	13.8"L x 18.03"W x 15.11"H
Item Weight	19.95 pounds
Included Components	Battery
Filter Type	Washable
Battery Life	100 minutes
Dust Bin Capacity	335 Milliliters (robot), 2.5L (station bag)

Feature	Description
Power Source	Battery Powered
Batteries Required	Yes (1 Lithium Ion battery included)
Control Method	App
Compatible Devices	Alexa, App, Button, Google Home
Form Factor	Robotic

7. Warranty and Support

eufy products typically come with a limited warranty. For specific warranty details, please refer to the warranty card included in your product packaging or visit the official eufy website.
For further assistance, technical support, or to purchase replacement parts, please contact eufy customer service or visit their official support page.
You can also download the complete User Manual in PDF format for more detailed information:Download User Manual (PDF)

© 2025 eufy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C4L8D11B

More documents and user manuals: **https://manuals.plus/**