SABA SA40S78GTV

SABA SA40S78GTV 40 inch Full HD Smart HDR Google TV User Manual

Model: SA40S78GTV

1. Safety Information

Please read all safety instructions carefully before using this television. Keep this manual for future reference.

- Do not expose the TV to rain or moisture to prevent fire or electric shock.
- Ensure proper ventilation. Do not block ventilation openings.
- Place the TV on a stable, level surface to prevent it from falling.
- Only use attachments/accessories specified by the manufacturer.
- Unplug the TV during lightning storms or when unused for long periods.
- Refer all servicing to qualified service personnel.

2. Product Overview

The SABA SA40S78GTV is a 40-inch Full HD Smart HDR Google TV, designed to provide a comprehensive entertainment experience. It features a vibrant display, integrated smart functionalities powered by Google TV, and versatile connectivity options.



This image displays the SABA SA40S78GTV television from the front, highlighting its slim bezels and the overall design. It is a 40-inch Full HD Smart HDR Google TV.

Key Features:

- 40-inch Full HD (1080p) LED Display
- Smart TV with Google TV Operating System
- HDR (High Dynamic Range) Support
- Integrated DVB-C/T2/S2 Tuner
- Bluetooth and WLAN Connectivity
- Multiple HDMI and USB Ports

3. Setup

3.1 Unpacking

Carefully remove the TV from its packaging. Ensure all accessories, including the remote control, power cable, and stand components, are present. Retain the packaging for potential future transport or service.

3.2 Stand Installation

1. Place the TV screen-down on a soft, clean surface to prevent scratches.
2. Align the stand components with the mounting holes on the bottom of the TV.
3. Secure the stand using the provided screws. Do not overtighten.

3.3 Wall Mounting (Optional)

If you choose to wall mount your TV, ensure you use a VESA-compatible wall mount kit (sold separately) that supports the TV's size and weight. Follow the instructions provided with your wall mount kit. **Warning:** Wall mounting should be performed by qualified personnel to prevent injury or damage.

3.4 Connecting Power

Connect the power cable to the TV's power input, then plug the other end into a suitable wall outlet. The TV will enter standby mode.

3.5 Initial Setup Wizard

Upon first power-on, the TV will guide you through an initial setup process. This includes:

- Language selection
- Network connection (Wi-Fi or Ethernet)
- Google account sign-in (optional, but recommended for full Smart TV features)
- Channel scanning (Antenna/Cable/Satellite)
- Accepting terms and conditions

4. Remote Control

The remote control allows you to operate your TV's functions. Insert two AAA batteries (not included) into the battery compartment, ensuring correct polarity.

Key Remote Functions:

- **Power Button:** Turns the TV on or off (standby mode).
- **Navigation Buttons (Up/Down/Left/Right):** Navigate menus and select options.
- **OK/Enter:** Confirms selections.
- **Back:** Returns to the previous screen.
- **Home:** Accesses the Google TV home screen.
- **Volume +/-:** Adjusts the volume level.
- **Channel +/-:** Changes TV channels.
- **Input:** Selects the input source (HDMI, AV, etc.).
- **Google Assistant Button:** Activates voice control (if supported and configured).

5. Connectivity

Your SABA SA40S78GTV offers various ports and wireless options for connecting external devices and networks.

5.1 Wired Connections

- **HDMI Ports:** Connect Blu-ray players, game consoles, set-top boxes, and other HDMI-enabled devices.
- **USB Ports:** Connect USB storage devices for media playback or software updates.
- **Antenna/Cable Input:** Connect an antenna for over-the-air broadcasts or a cable TV connection.
- **Ethernet (LAN) Port:** For a stable wired internet connection.

5.2 Wireless Connections

- **Wi-Fi:** Connect to your home wireless network for internet access and Smart TV features.
- **Bluetooth:** Pair with compatible Bluetooth devices such as headphones, soundbars, or game controllers.

6. Operating the TV

6.1 Power On/Off

Press the **Power** button on the remote control or on the TV to turn it on or put it into standby mode.

6.2 Channel Selection

Use the **Channel +/-** buttons to cycle through channels or enter a channel number directly using the numeric buttons on the remote.

6.3 Volume Control

Adjust the audio level using the **Volume +/-** buttons.

6.4 Input Source Selection

Press the **Input** button on the remote to open the input source menu. Use the navigation buttons to select the desired source (e.g., HDMI 1, USB, TV).

6.5 Picture and Sound Settings

Access the TV's settings menu to customize picture modes (Standard, Dynamic, Movie), color temperature, brightness, contrast, and sound modes (Standard, Music, Movie).

7. Smart TV Features (Google TV)

Your SABA SA40S78GTV runs on the Google TV operating system, offering a personalized and integrated smart experience.

7.1 Navigating Google TV

Press the **Home** button on your remote to access the Google TV home screen. Use the navigation buttons to browse content, apps, and settings.

7.2 Apps and Streaming

Download and manage your favorite streaming apps from the Google Play Store. Access popular services directly from the home screen.

7.3 Google Assistant

If your remote has a Google Assistant button, press it and speak into the remote to search for content, control smart home devices, get answers, and more.

7.4 Casting

Use the built-in Chromecast functionality to cast content from your compatible smartphone, tablet, or computer directly to your TV screen.

8. Maintenance

8.1 Cleaning the TV

- **Screen:** Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, use a screen-cleaning solution specifically designed for TVs, applied to the cloth, not directly to the screen.
- **Body:** Wipe the TV's frame and stand with a soft, dry cloth. Do not use abrasive cleaners or solvents.

8.2 Software Updates

The TV may receive software updates periodically to improve performance and add new features. Ensure your TV is connected to the internet. You can usually check for updates in the TV's settings menu under 'System' or 'About'.

9. Troubleshooting

If you encounter issues with your TV, refer to the following common solutions before contacting support.

Problem	Possible Solution
No power	Check if the power cable is securely connected to both the TV and the wall outlet. Try a different outlet.
No picture, but sound is present	Ensure the correct input source is selected. Check HDMI/AV cable connections.
No sound, but picture is present	Check volume level and mute status. Verify audio output settings. Disconnect any external audio devices to test internal speakers.
Remote control not working	Replace batteries. Ensure no obstructions between the remote and the TV's IR sensor.
Cannot connect to Wi-Fi	Check your router and modem. Restart the TV and router. Re-enter Wi-Fi password.
Smart TV features are slow or unresponsive	Ensure a stable internet connection. Close unused apps. Restart the TV.

10. Specifications

Feature	Detail
Model	SA40S78GTV
Screen Size	40 inches
Display Type	LED
Resolution	Full HD (1920 x 1080p)
Operating System	Google TV
HDR Support	Yes
Tuner Technology	DVB-C/T2/S2
Connectivity	Bluetooth, WLAN (Wi-Fi), HDMI, USB, Ethernet
Audio Output	2 Speakers
Color	Grey
Dimensions (W x H)	89.8 cm x 54.6 cm (without stand, approximate)

11. Warranty and Support

For warranty information, please refer to the warranty card included with your product or visit the official SABA website.

For technical support, product registration, or service inquiries, please contact SABA customer service through their official channels.
Keep your purchase receipt as proof of purchase for warranty claims.

© 2023 SABA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question