Noirot M112114

Noirot Eurospot 1250W Horizontal Convector Heater User Manual

Model: M112114

1. Introduction

Thank you for choosing the Noirot Eurospot 1250W Horizontal Convector Heater. This manual provides essential information for the safe and efficient installation, operation, and maintenance of your new heater. Please read these instructions carefully before use and retain them for future reference.

2. Safety Instructions

Always observe the following safety precautions to reduce the risk of fire, electric shock, or injury:

- Read all instructions before using this heater.
- Do not use this heater in the immediate vicinity of a bath, a shower, or a swimming pool.
- Do not cover the heater. Covering the heater may cause overheating.
- Do not insert any objects into the ventilation openings.
- Keep combustible materials such as furniture, curtains, and other flammable items at least 1 meter (3 feet) from the front and sides of the heater.
- Ensure the electrical supply matches the voltage specified on the heater's rating label.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons in order to avoid a hazard.

3. Package Contents

Please check the contents of the package:

- Noirot Eurospot 1250W Horizontal Convector Heater

- Wall mounting bracket(s)
- Mounting hardware (screws, wall plugs)
- User Manual

4. Setup and Installation

This convector heater is designed for wall mounting. Ensure the chosen location is suitable and adheres to all safety clearances.

4.1 Choosing a Location

- Select a wall location that is firm and can support the weight of the heater (approximately 4.5 kg).
- Maintain minimum clearances: at least 15 cm (6 inches) from the floor, 15 cm (6 inches) from the ceiling, and 15 cm (6 inches) from adjacent walls or furniture.
- Avoid locations directly below an electrical outlet.
- Ensure the location is not exposed to direct water spray or excessive humidity.

4.2 Wall Mounting

1. Carefully remove the wall mounting bracket from the back of the heater.
2. Hold the bracket against the wall at the desired height and mark the drilling points. Use a spirit level to ensure it is horizontal.
3. Drill holes at the marked points using an appropriate drill bit for your wall type.
4. Insert the wall plugs into the drilled holes.
5. Secure the mounting bracket to the wall using the provided screws. Ensure it is firmly attached.
6. Carefully hang the heater onto the mounted bracket, ensuring it clicks securely into place.



Figure 1: Front view of the Noirot Eurospot 1250W Horizontal Convector Heater. This image shows the compact, white, horizontal design with top ventilation grilles, illustrating the unit's appearance when mounted.

4.3 Electrical Connection

Connect the heater to a suitable electrical outlet. Ensure the outlet is properly grounded and rated for the heater's power consumption (1250W). Do not use extension cords or multi-plugs with this appliance.

5. Operating Instructions

Your Noirot Eurospot convector heater is designed for simple and efficient operation.

5.1 Powering On/Off

- To turn the heater ON, plug it into a suitable electrical outlet. The heater will typically have a power switch or a thermostat control that also acts as an on/off switch.
- To turn the heater OFF, switch off the power switch or unplug the unit from the electrical outlet.

5.2 Temperature Control

The heater is equipped with a thermostat to maintain your desired room temperature.

1. Locate the thermostat control dial or buttons, usually on the side or front of the unit.
2. Turn the dial clockwise or press the '+' button to increase the desired temperature.
3. Turn the dial counter-clockwise or press the '-' button to decrease the desired temperature.

4. The heater will cycle on and off to maintain the set temperature, providing consistent warmth.

6. Maintenance

Regular maintenance ensures the longevity and efficient operation of your heater.

6.1 Cleaning

- Always unplug the heater from the power outlet and allow it to cool completely before cleaning.
- Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Use a vacuum cleaner with a brush attachment to gently remove dust from the air inlet and outlet grilles.
- Never immerse the heater in water or any other liquid.

6.2 Storage

If storing the heater for an extended period, ensure it is clean and dry. Store it in a cool, dry place, preferably in its original packaging, to protect it from dust and damage.

7. Troubleshooting

If you encounter issues with your heater, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Heater does not turn on.	No power supply. Thermostat set too low. Overheat protection activated.	Check if the heater is plugged in and the outlet is working. Increase the thermostat setting. Unplug the heater, let it cool for 30 minutes, then plug it back in. Ensure ventilation is not blocked.
Heater is on but not heating.	Thermostat set too low. Room temperature already reached.	Increase the thermostat setting. The heater will cycle off once the desired temperature is reached. This is normal operation.
Unusual smell or noise.	New heater smell (temporary). Dust accumulation.	A slight odor is normal during initial use. Ensure good ventilation. Unplug and clean the heater as per maintenance instructions. If the smell or noise persists, discontinue use and contact support.

If the problem persists after trying these solutions, please contact customer support.

8. Specifications

Model Number	M112114
Brand	Noirot
Type	Electric Convector Heater
Power Output	1250 W
Heating Method	Convection

Heating Coverage	12 to 13 m² (approx.)
Form Factor	Horizontal
Usage	Indoor
Power Source	Electric Cable
Weight	4.5 kg
Color	White

9. Warranty and Support

Your Noirot Eurospot heater comes with a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions. For technical support, spare parts, or warranty claims, please contact your retailer or the official Noirot customer service in your region. Keep your proof of purchase for warranty purposes.