Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Kärcher VC 4 Cordless myHome Pet

Kärcher VC 4 Cordless myHome Pet - Instruction Manual

Model: VC 4 Cordless myHome Pet

Introduction

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your Kärcher VC 4 Cordless myHome Pet vacuum cleaner. Please read it thoroughly before first use and keep it for future reference.



Figure 1: Kärcher VC 4 Cordless myHome Pet vacuum cleaner with its sleek design.

Package Contents

Upon unboxing, please ensure all components listed below are present:

- VC 4 Cordless myHome Pet vacuum cleaner unit
- Wall mount
- Floor nozzle
- Crevice nozzle
- Mini turbo brush
- 2-in-1 furniture brush
- 21.6 V battery
- Charger



Figure 2: The Kärcher VC 4 Cordless myHome Pet vacuum cleaner shown with its various attachments, including the floor nozzle, crevice nozzle, mini turbo brush, and 2-in-1 furniture brush.

Setup

1. ### Charging the Battery

   Before first use, fully charge the 21.6 V battery. Connect the charger to a power outlet and then to the battery. The charging indicator will show the charging status. A full charge provides up to 30 minutes of runtime.

2. ### Assembling the Vacuum Cleaner

   Insert the main vacuum unit into the extension tube, ensuring it clicks securely into place. Then, attach the desired nozzle (e.g., floor nozzle) to the other end of the extension tube until it locks.

3. ### Mounting the Wall Holder (Optional)

   The included wall mount allows for convenient storage and charging. Choose a suitable location near a power outlet. Use appropriate screws and anchors for your wall type to secure the mount firmly.

Operating Instructions

1. ### Powering On/Off

   Press the power button (Controller Type: Push Button) located on the handle to turn the vacuum cleaner on or off.

2. ### Selecting Suction Mode

   The VC 4 Cordless myHome Pet offers two power levels (Number of Power Levels: 2):

   - **Default Mode:** Suitable for general cleaning tasks and maximizing battery life.
   - **Boost Mode:** Provides maximum suction power for stubborn dirt or pet hair. Use this mode for intensive cleaning, noting it will reduce runtime.

   Switch between modes using the control method (Control Method: Touch) on the unit.

3. ### Using Attachments

   - **Floor Nozzle:** Ideal for cleaning hard floors and carpets.
   - **Crevice Nozzle:** Perfect for reaching tight spaces, corners, and edges.
   - **Mini Turbo Brush:** Specifically designed for efficient removal of pet hair from upholstery, carpets, and pet beds.
   - **2-in-1 Furniture Brush:** Use for delicate surfaces, curtains, or furniture.

   To use as a handheld vacuum, simply detach the extension tube from the main unit. Attach the desired accessory directly to the handheld unit.



Figure 3: A user demonstrating the Kärcher VC 4 Cordless myHome Pet vacuum cleaner in action on a hard floor surface.



Figure 4: The mini turbo brush attachment being used to effectively clean pet hair from a pet bed.

Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

1. ### Emptying the Dust Container

   The dust container has a capacity of 0.65 Liters. Empty it regularly, especially when the fill line is reached, to maintain suction power. Detach the container and dispose of collected debris.

2. ### Cleaning the Filter

   The vacuum cleaner uses a Cloth or Foam Filter. Clean the filter periodically according to the instructions provided in the full user manual (not included here). A clogged filter can significantly reduce suction efficiency.

3. ### Cleaning Nozzles and Brushes

   Remove any tangled hair or debris from the floor nozzle and mini turbo brush. This is particularly important for the mini turbo brush when cleaning pet hair.

Troubleshooting

Problem	Possible Cause	Solution
Vacuum cleaner does not turn on.	Battery is not charged or not inserted correctly.	Ensure battery is fully charged and properly seated in the unit.
Low suction power.	Dust container full, filter clogged, or nozzle/tube blocked.	Empty dust container. Clean or replace filter. Check nozzles and tubes for blockages.
Short runtime.	Battery not fully charged or operating in Boost mode excessively.	Ensure battery is fully charged. Use Default mode for longer cleaning sessions.
Mini turbo brush not rotating.	Hair or debris tangled in the brush roll.	Clean the brush roll, removing any obstructions.

Specifications

- **Model Name:** myhome (VC 4 Cordless myHome Pet)
- **Brand:** Kärcher
- **Capacity:** 0.65 Liters
- **Runtime:** Up to 30 minutes
- **Battery:** 21.6 V (22.2 volts)
- **Wattage:** 100 watts
- **Noise Level:** 85 dB

- **Filter Type:** Cloth or Foam Filter
- **Product Dimensions:** 9.06"L x 9.29"W x 43.9"H
- **Item Weight:** 9.68 pounds
- **Special Features:** Compact, Animal Hair removal
- **Control Method:** Touch
- **Controller Type:** Push Button
- **Number of Power Levels:** 2
- **Indoor/Outdoor Usage:** Indoor

Warranty and Support

For warranty information and customer support, please refer to the official Kärcher website or the warranty card included with your product. Keep your proof of purchase for any warranty claims.
Manufacturer: Kärcher
EU Spare Part Availability Duration: 1 Year
For further assistance, you may visit the Kärcher Store on Amazon.

© 2024 Kärcher. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C4LTPPBN

More documents and user manuals: **https://manuals.plus/**