Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Varmilo VXT67

Varmilo x MK Glintstone Minilo VXT67 Mechanical Keyboard User Manual

Model: VXT67

Introduction

Thank you for choosing the Varmilo x MK Glintstone Minilo VXT67 Mechanical Keyboard. This keyboard features a unique MK-exclusive colorway and offers versatile connectivity options, including wired USB-C, Bluetooth 5.1, and 2.4 GHz wireless modes. Designed for a superior typing experience, it includes per-key RGB backlighting, durable 1.5mm thick ABS Double Shot keycaps, and Type-Cool sound dampening for enhanced acoustics. This manual will guide you through the setup, operation, and maintenance of your new keyboard.



Image: Top-down view of the Varmilo x MK Glintstone Minilo VXT67 mechanical keyboard.

What's in the Box

Please check the contents of your package:

- Varmilo x MK Glintstone Minilo VXT67 Mechanical Keyboard
- USB-C Cable
- 2.4 GHz USB Receiver (Dongle)

- Keycap Puller
- Extra Keycaps (e.g., Esc key with Glintstone logo, alternative spacebar)



Image: Varmilo x MK Glintstone Minilo VXT67 keyboard and included accessories.

Setup

The Varmilo Minilo VXT67 keyboard supports three connection modes: Wired, 2.4 GHz Wireless, and Bluetooth.

1. Wired Mode

1. Locate the USB-C port on the back of the keyboard.
2. Connect the provided USB-C cable to the keyboard and the other end to an available USB port on your computer.
3. The keyboard will be automatically recognized and ready for use.



Image: USB-C port for wired connection and charging.

2. 2.4 GHz Wireless Mode

1. Locate the 2.4 GHz USB receiver (dongle) included in the package.
2. Plug the USB receiver into an available USB port on your computer.
3. On the keyboard, switch the mode selector (usually located on the back or side) to the 2.4 GHz position.
4. The keyboard should automatically connect to the receiver.

3. Bluetooth Mode

1. On the keyboard, switch the mode selector to the Bluetooth position.
2. To enter pairing mode, press and hold the Fn key + one of the Bluetooth profile keys (e.g., Fn + Q, W, or E) for 3-5 seconds until the indicator light flashes rapidly.
3. On your device (computer, smartphone, tablet), go to Bluetooth settings and search for new devices.
4. Select "Varmilo VXT67" (or similar name) from the list of available devices.
5. Once paired, the indicator light will stop flashing.
6. You can pair up to three Bluetooth devices by assigning them to Fn+Q, Fn+W, and Fn+E. To switch between paired devices, simply press Fn + the corresponding key (Q, W, or E).

Operating Instructions

Function Key Combinations (Fn)

The Varmilo Minilo VXT67 utilizes the Fn key for various secondary functions. Press and hold the Fn key, then press the desired function key.

Combination	Function
Fn + Q/W/E	Switch Bluetooth device (Q, W, E for device 1, 2, 3)
Fn + F1-F12	Multimedia controls (e.g., volume, play/pause) - specific functions may vary.
Fn + Right Shift	Toggle arrow keys (if applicable to layout)

Combination	Function
Fn + Esc	Restore factory settings (hold for 5 seconds)
Fn + Backspace	Delete (if applicable)
Fn + Insert	Insert (if applicable)
Fn + PgUp/PgDn	Page Up/Page Down (if applicable)

RGB Backlighting Control

The keyboard features per-key RGB backlighting. Use the following combinations to control the lighting effects:

- **Fn +** \|: Cycle through lighting modes.
- **Fn + <**: Decrease brightness.
- **Fn + >**: Increase brightness.
- **Fn + ;:**: Decrease animation speed.
- **Fn + ':**: Increase animation speed.
- **Fn + Spacebar (hold 3s)**: Reset RGB lighting to default.

Battery Indicator

The keyboard is equipped with a flashing indicator light that warns of low battery. When charging, the Escape key will light up to indicate the charging status.

Maintenance

To ensure the longevity and optimal performance of your Varmilo keyboard, follow these maintenance guidelines:

- **Cleaning Keycaps:** Use the provided keycap puller to carefully remove keycaps. Clean them with a soft cloth dampened with a mild cleaning solution or water. Ensure they are completely dry before reattaching.
- **Cleaning the Board:** Use compressed air to remove dust and debris from between the keys. For stubborn dirt, use a small brush or cotton swab.
- **Avoid Liquids:** Do not spill liquids on the keyboard. If a spill occurs, immediately disconnect the keyboard and allow it to dry completely before reconnecting.
- **Storage:** When not in use for extended periods, store the keyboard in a dry, dust-free environment.



Image: Close-up of keycaps, illustrating the texture and spacing for cleaning.

Troubleshooting

If you encounter issues with your keyboard, please refer to the following common problems and solutions:

- **Keyboard not responding (Wired Mode):**
  - Ensure the USB-C cable is securely connected to both the keyboard and the computer.
  - Try a different USB port on your computer.
  - Test with a different USB-C cable if available.
- **Keyboard not connecting (2.4 GHz Wireless Mode):**
  - Ensure the 2.4 GHz USB receiver is properly plugged into a USB port.
  - Verify the keyboard's mode switch is set to 2.4 GHz.
  - Ensure the keyboard battery is charged.
- **Keyboard not connecting (Bluetooth Mode):**
  - Ensure the keyboard's mode switch is set to Bluetooth.
  - Make sure Bluetooth is enabled on your device.
  - Put the keyboard into pairing mode (Fn + Q/W/E, hold for 3-5 seconds).

- Remove previous pairings from your device's Bluetooth list and try pairing again.
- Ensure the keyboard battery is charged.

- **RGB Backlighting not working or incorrect:**
  - Check the brightness settings (Fn + < / >).
  - Try cycling through lighting modes (Fn + \|).
  - Reset RGB settings by holding Fn + Spacebar for 3 seconds.
  - Ensure the keyboard battery is sufficiently charged, as low battery can affect lighting.

- **Keys not responding or double-typing:**
  - Ensure the keyboard is fully charged.
  - Try resetting the keyboard to factory settings (Fn + Esc, hold for 5 seconds).
  - If using wireless mode, try switching to wired mode to rule out wireless interference.

- **Low Battery Warning:**
  - When the indicator light flashes, connect the USB-C cable to charge the keyboard. The Escape key will light up during charging.

Specifications

Feature	Detail
Brand	Varmilo
Model	Minilo VXT67
Connectivity Technology	Bluetooth 5.1, 2.4 GHz RF, USB-C (Wired)
Keyboard Description	Mechanical
Number of Keys	67
Keycap Material	1.5mm thick ABS Double Shot
Backlighting	Per-key RGB
Special Features	Indicator Light (low battery, charging), Type-Cool Sound Dampening
Compatible Devices	Laptop, PC, Smartphone, Tablet
Color	Gat G Pro 2.0 Brown (switch type)
Manufacturer	Varmilo

Warranty Information

Varmilo products are manufactured to high-quality standards. This product is covered by a limited warranty against

defects in materials and workmanship. The specific terms and duration of the warranty may vary by region and retailer. Please retain your proof of purchase for warranty claims.
For detailed warranty information, please refer to the warranty card included with your product or visit the official Varmilo website.

Customer Support

If you require further assistance or have questions not covered in this manual, please contact Varmilo customer support or the retailer from whom you purchased the product.

- **Online Support:** Visit the official Varmilo website for FAQs, drivers, and support resources.
- **Retailer Support:** Contact Mechanical Keyboards Inc. for product-specific inquiries related to this exclusive model.
- **Amazon Store:** You can also visit the Varmilo Store on Amazon for more information.

© 2023 Varmilo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C4LV9FBD

More documents and user manuals: **https://manuals.plus/**