Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Claesydorn P10

Claesydorn Cordless Vacuum Cleaner User Manual

Model: P10

Introduction

Thank you for choosing the Claesydorn Cordless Vacuum Cleaner. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new vacuum cleaner. Please read this manual thoroughly before first use and retain it for future reference.

Product Overview and Components

The Claesydorn P10 Cordless Vacuum Cleaner is designed for versatile cleaning across various surfaces. Below are the main components included with your vacuum.



Figure 1: Main components of the Claesydorn P10 Cordless Vacuum Cleaner, including the main unit, extension wand, motorized floor brush, crevice tool, 2-in-1 brush, wall mount, and cleaning tool.

Included Components:

- Main Vacuum Unit (with dustbin and motor)
- Extension Wand
- Motorized Floor Brush with LED lights
- Crevice Tool
- 2-in-1 Brush Tool
- Wall Mount Bracket
- Cleaning Tool
- Power Adapter/Charger

- Detachable Battery Pack

Setup and Assembly

Follow these steps to assemble and prepare your vacuum cleaner for first use.

1. **Charge the Battery:** Before first use, fully charge the detachable lithium-ion battery. Connect the power adapter to the battery or the main unit. A full charge takes approximately 4 hours.



Figure 2: Illustration of the detachable battery and its charging status, indicating a 2000mAh capacity and 25-40 minutes runtime.

2. **Assemble the Main Unit:**
    - Attach the extension wand to the main vacuum unit until it clicks into place.
    - Attach the motorized floor brush to the other end of the extension wand until it clicks.
    - For handheld use, attach desired accessories (crevice tool or 2-in-1 brush) directly to the main unit.
3. **Wall Mount Installation (Optional):** Choose a suitable location and securely install the wall mount bracket using appropriate hardware (not specified if included, assume standard).

Operating Instructions

Your Claesydorn P10 vacuum cleaner offers powerful and versatile cleaning.

Powering On/Off and Suction Modes:

- Press the power button to turn the vacuum on.

- Press the mode button (if available, implied by "powerful suction") to switch between suction modes. The vacuum features a 250W motor for continuous powerful suction.



Figure 3: The vacuum cleaner effectively picking up dust, pet hair, crumbs, and pet food from a carpeted surface, highlighting its 250W brushless motor.

Versatile Cleaning with 6-in-1 Design:

The modular design allows for various cleaning configurations:

- **Stick Vacuum Mode:** For hard floors, low-pile carpets, and rugs. The motorized floor brush adapts to different ground types for deeper cleaning.



Figure 4: The 2-in-1 floor and carpet brush designed to adapt to and clean various surfaces including low pile carpet, tile floor, rug, and wooden floor.

- **Handheld Vacuum Mode:** Detach the extension wand to use the main unit with accessories for cleaning furniture, car interiors, stairs, and curtains.



Figure 5: Examples of the vacuum cleaner's versatility, showing its use for cleaning curtains, sofas, home furnishings, and automobile interiors.

- **Flexible Maneuverability:** The motorized floor brush features LED lights to illuminate dark areas and offers 180° left and right swivel and 90° up and down movement for easy navigation under furniture and around obstacles.



Figure 6: The vacuum cleaner's flexible design, illustrating its ability to swivel 180° left and right and bend 90° up and down for reaching under furniture.

Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

Emptying and Cleaning the Dustbin:

- The 1-liter dustbin is designed for multiple cleanings. Empty the dustbin with a single click when it reaches the MAX fill line.
- The dustbin and filter components are washable.



Figure 7: Demonstrates the one-click dustbin emptying mechanism and the process of washing the filtered components under running water.

Filter Maintenance:

The vacuum features a 5-stage high-efficiency filtration system. Regularly clean or replace filters to maintain suction power and air quality.



Figure 8: Exploded view of the 5-stage high-efficiency filtration system, including the 1st Cyclone, Metal Dust Filter, Multi-cone Cyclonic Filter, Pre-Filter, and H10 HEPA filter, designed to catch 99.99% of particles.

- Remove the filter components from the dustbin.
- Tap off loose dust.
- Rinse washable components under cold water. Ensure they are completely dry before reassembling.
- Replace the HEPA filter periodically as recommended (check product packaging or manufacturer website for specific intervals).

Brush Roll Cleaning:

- Periodically check the brush roll for tangled hair or debris.
- Use the provided cleaning tool to cut and remove any tangled hair.
- Ensure the brush roll spins freely after cleaning.

Troubleshooting

If you encounter issues with your vacuum cleaner, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Vacuum does not turn on.	Battery is not charged or not properly installed.	Ensure battery is fully charged and securely inserted.
Loss of suction.	Dustbin is full; filters are clogged; brush roll is obstructed.	Empty dustbin. Clean or replace filters. Remove obstructions from brush roll.
Brush roll not spinning.	Obstruction in brush roll; brush roll not properly installed.	Remove any tangled hair or debris. Reinstall brush roll correctly.
Short runtime.	Battery not fully charged; battery degradation.	Ensure battery is fully charged. If issue persists, battery may need replacement.

If the problem persists after attempting these solutions, please contact customer support.

Specifications

Feature	Detail
Brand	Claesydorn
Model	P10
Motor Power	250 watts
Battery Capacity	2200mAh (Lithium-ion)
Runtime	Up to 45 minutes
Charging Time	Approx. 4 hours
Dustbin Capacity	1 Liters
Filtration System	5-Stage HEPA Cyclone Filtration
Noise Level	63 dB
Item Weight	1.5 kg (Main host at 2.64 pounds)
Product Dimensions	27.94 x 17.78 x 43.18 cm
Color	Blue
Cordless	Yes
Surface Recommendation	Carpet, Hard Floor

Warranty and Support

Claesydorn offers a **12-month warranty** for your Cordless Vacuum Cleaner. This warranty covers manufacturing defects and ensures accessories replacement service.
For any concerns, technical assistance, or warranty claims, please contact our customer support. We aim to resolve all inquiries within 12 hours.

Please refer to your purchase documentation for specific contact details or visit the official Claesydorn website.

© 2023 Claesydorn. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C4PN64G5

More documents and user manuals: **https://manuals.plus/**