Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Stepeak 230311A1

Stepeak Floor Lamp with Shelves (Model 230311A1) Instruction Manual

1. Safety Information

Please read these instructions carefully before assembly and use. Keep this manual for future reference.

- Ensure the power is off before installing or replacing bulbs.
- Use only E26 base bulbs, maximum 40W. Compatible bulb types include LED, CFL, incandescent, tungsten, and halogen.
- Do not exceed the maximum wattage to prevent overheating and potential fire hazards.
- The lamp is designed for indoor use only. Do not expose to moisture or extreme temperatures.
- Place the lamp on a stable, level surface to prevent tipping. The weighted base is designed for stability.
- Keep the power cord away from heat sources, sharp edges, and heavy traffic areas.
- Do not attempt to modify the lamp's electrical components. Contact qualified personnel for repairs.

2. Package Contents

Verify that all components are present before beginning assembly:

- 3 Fabric Lampshades
- On-Off Foot Switch
- Power Cable (79 inches long)
- Lamp Poles (various lengths)
- Double Shelf (10.2 inch diameter)
- Weighted Base
- Assembly Hardware (screws, connectors)
- Instruction Manual

3. Setup and Assembly

The Stepeak Floor Lamp is designed for easy assembly without the need for additional tools. Follow these steps:

1. Unpack all components and lay them out on a clean, flat surface.
2. Attach the longest lamp pole to the weighted base by screwing it clockwise until secure.
3. Thread the power cable through the center of the lamp poles as you assemble them.
4. Attach the lower shelf to the designated position on the central pole.
5. Connect the remaining lamp poles and the upper shelf, ensuring all connections are tight.
6. Screw the three E26 UL sockets onto the top of each lamp pole.
7. Place the fabric lampshades over each socket.
8. Install E26 base bulbs (not included) into each socket.
9. Position the lamp in your desired location, ensuring the power cable reaches an outlet without tension.



Figure 3.1: Key components of the Stepeak Floor Lamp.



Figure 3.2: Dimensions of the assembled floor lamp.

4. Operating Instructions

4.1 Powering On/Off

The Stepeak Floor Lamp features a convenient foot switch located on the power cable. To turn the lamp on or off, simply press the foot switch with your foot.



Figure 4.1: Foot switch for easy operation.

4.2 Bulb Compatibility and Light Effects

The lamp is compatible with various E26 base bulbs (not included). Different color temperature bulbs can create unique lighting effects to suit your ambiance preferences.



Figure 4.2: Examples of different light color temperatures.

4.3 Integrated Shelves

The lamp includes two integrated shelves made of high-density fiber material, each capable of holding up to 50 pounds. These shelves can be used to display small plants, photo frames, books, or other decorative items, enhancing the lamp's functionality and aesthetic appeal.



Figure 4.3: Floor lamp with items displayed on its shelves.

4.4 Product Video

Watch this video for a visual overview of the Stepeak 3-Lights Boho Rattan Floor Lamp with Shelf Display:

Video 4.4: Stepeak 3-Lights Boho Rattan Floor Lamp with Shelf Display. This video demonstrates the features and aesthetic of the floor lamp.

5. Maintenance

- **Cleaning:** Disconnect the power before cleaning. Wipe the lamp with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Bulb Replacement:** Ensure the lamp is unplugged and bulbs are cool before attempting to replace them. Screw in new E26 base bulbs, ensuring they do not exceed 40W.
- **Shade Care:** The fabric lampshades can be gently dusted or wiped with a slightly damp cloth if necessary.

6. Troubleshooting

- **Lamp does not turn on:**
  - Check if the power cord is securely plugged into a working outlet.
  - Ensure the foot switch is pressed to the 'ON' position.
  - Verify that the bulbs are correctly installed and not burnt out. Replace if necessary.
- **Lamp is wobbly:**
  - Ensure all lamp poles and shelves are securely screwed together.
  - Place the lamp on a flat, even surface.
- **Lights flicker:**
  - Check if bulbs are screwed in tightly.
  - Try different bulbs to rule out faulty bulbs.

7. Specifications

Feature	Detail
Model Number	230311A1
Overall Dimensions (L x W x H)	10.2" x 10.2" x 66.1" (Approx. 16.9"D x 12.9"W x 7"H for base/shelf area)
Shade Dimensions (L x H)	4.9" x 5.7"
Shelf Diameter	10.2 inches
Cord Length	79 inches
Number of Lights	3
Bulb Base	E26 UL Socket
Max Wattage per Bulb	40W
Compatible Bulb Types	LED, CFL, Incandescent, Tungsten, Halogen
Switch Type	Foot Switch
Material	Fabric, Metal
Color	Black (frame), Beige (shades)
Power Source	Corded Electric
Voltage	120 Volts
Indoor/Outdoor Use	Indoor Use Only

8. Warranty and Support

Stepeak provides a **24-month parts replacement service** from the date of purchase. All sockets, wires, and the switch of this lamp have passed UL certification, ensuring safety and reliability.

For any questions or concerns regarding your Stepeak Floor Lamp, please contact our professional after-sales team.

Refer to your purchase documentation for contact details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C4TKKDF5

More documents and user manuals: **https://manuals.plus/**