Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY QYSY-LED24165-QYSY

ALLIMITY Replacement Remote Control Instruction Manual

For NEO LED TV Models: LED-19000DVBT, LED-19965, LED-23914, LED-24165, LED-24180, LED-32165DL, LED-32272DL, LED-32665FHD

1. Introduction

This manual provides instructions for the ALLIMITY replacement remote control, designed for use with various NEO LED TV models. This remote control is a direct replacement and offers full functionality without the need for complex programming.

Compatible NEO LED TV Models:

- LED-19000DVBT
- LED-19965
- LED-23914
- LED-24165
- LED-24180
- LED-32165DL
- LED-32272DL
- LED-32665FHD

2. Setup

2.1 Battery Installation

The remote control requires two AAA alkaline batteries (not included). Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover off.
3. Insert two AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Note: *This remote control does not require any programming. Once batteries are installed, it is ready for immediate use*

with compatible NEO LED TV models.



Image 1: Angled view of the ALLIMITY replacement remote control. The battery compartment is located on the back of the device.

3. Operating Instructions

This remote control provides standard functions for your NEO LED TV. Point the remote control directly at the TV's infrared sensor for optimal performance.




SOURCE
PRESETS
1 ../@
2 abc
3 def
4 ghi
5 jkl
6 mno
7 pqrs
8 tuv
9 wxyz
TV
0
MENU
MENU
OK
BACK
EXIT
V+
P+
V−
i
P−
LANG
RC1912



Image 2: Front view of the ALLIMITY replacement remote control, showing the layout of all buttons.

3.1 Button Functions

- **Power (Red Button):** Turns the TV on or off.
- **Number Buttons (0-9):** Directly select channels.
- **PRESETS:** Access preset channels or settings.
- **TV:** Switches to TV input mode.
- **MENU:** Opens the TV's main menu.
- **Navigation Buttons (Up, Down, Left, Right Arrows):** Navigate through menus and options.
- **OK:** Confirms selections in menus.
- **BACK:** Returns to the previous screen or menu.
- **EXIT:** Exits the current menu or function.
- **V+** / **V-:** Increases or decreases the volume.
- **P+** / **P-:** Changes to the next or previous channel.
- **Mute (Speaker with X):** Mutes or unmutes the TV audio.
- **LANG:** Changes audio language or subtitle options.
- **Color Buttons (Red, Green, Yellow, Blue):** Access specific functions within certain TV menus or applications, as indicated on the TV screen.
- **Playback Controls (Play, Pause, Stop, Rewind, Fast Forward):** Control media playback if supported by the TV.

4. Maintenance

4.1 Cleaning

To clean the remote control, gently wipe it with a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote's surface or internal components.

4.2 Battery Replacement

Replace batteries when the remote control becomes unresponsive or its range decreases significantly. Always replace both batteries at the same time with new alkaline batteries of the same type (AAA). Do not mix old and new batteries or different types of batteries.

4.3 Storage

If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the device.

5. Troubleshooting

- **Remote control not working:**
  - Ensure batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new alkaline batteries.
  - Check for any obstructions between the remote control and the TV's infrared sensor.

- Ensure you are within the effective operating range (up to 10 meters) and pointing the remote directly at the TV.

- **Specific buttons not responding:**
  - This remote is designed to cover all functions of the original remote. If a specific button does not work, ensure your TV model supports that function.
  - Clean the remote control as described in the Maintenance section to ensure no debris is interfering with button contacts.

6. Specifications

Brand	ALLIMITY
Model Number	QYSY-LED24165-QYSY
Compatible Devices	NEO LED TVs (LED-19000DVBT, LED-19965, LED-23914, LED-24165, LED-24180, LED-32165DL, LED-32272DL, LED-32665FHD)
Connectivity Technology	Infrared (IR)
Maximum Range	10 Metres
Battery Type	2 x AAA Alkaline (not included)
Product Dimensions	4 x 12 x 0.3 cm
Item Weight	0.06 Kilograms

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C4YFXZBC

More documents and user manuals: **https://manuals.plus/**