Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LILOVE Pluxy Epil Pro 3.0

LILOVE Pluxy Epil Pro 3.0 7-in-1 Facial Epilator User Manual

Model: Pluxy Epil Pro 3.0

1. Introduction

1.1 Product Overview

The LILOVE Pluxy Epil Pro 3.0 is a versatile 7-in-1 facial epilator designed for effective and gentle hair removal. It features specialized discs capable of capturing fine and short facial hairs directly from the root, leading to slower, finer regrowth over time. This device is suitable for full body water washing, ensuring hygienic maintenance. It operates on USB power and includes multiple interchangeable heads for various grooming needs.

1.2 Intended Use

This device is intended for personal cosmetic use, specifically for hair removal on the face and body, facial cleansing, massage, and callus removal. It is designed for adult use only.

1.3 Package Contents

Please check the package for the following components:

- 1 x Main Unit (Host)
- 1 x Exfoliating/Grinding Cotton Head
- 1 x Nose Trimmer Head
- 1 x Massage Head
- 1 x Body Hair Trimmer Head
- 1 x Grinding Head (Callus Remover)
- 1 x Dead Skin Brush (Facial Cleansing Brush)
- 1 x Eyebrow Trimmer Head
- 1 x USB Charging Cable
- 1 x User Manual



Image 1.3.1: The Pluxy Epil Pro 3.0 main unit with its various interchangeable heads, highlighting its multi-purpose functionality.

2. Important Safety Instructions

Please read all instructions carefully before using the device and retain them for future reference. Failure to follow these instructions may result in injury or damage to the device.

- Keep the device out of reach of children.
- Do not use the device on irritated, infected, sunburned, or broken skin. Consult a doctor if you have any skin conditions.
- Avoid using the epilator on sensitive areas such as eyelids, eyelashes, or inside the nose/ears.
- Ensure the device is fully charged before use to maintain optimal performance.
- Do not immerse the charging cable or adapter in water.
- If the device shows any signs of damage, do not use it. Contact customer support.
- This device is water-resistant for cleaning purposes; however, avoid prolonged submersion.

- Only use the provided USB charging cable.

3. Getting Started

3.1 Charging the Device

1. Connect the USB charging cable to the charging port on the main unit.
2. Plug the other end of the USB cable into a compatible USB power adapter (not included) or a computer USB port.
3. The charging indicator light will illuminate to show that the device is charging.
4. A full charge typically takes approximately 2-3 hours. The indicator light may change or turn off when fully charged.



Image 3.1.1: Charging the Pluxy Epil Pro 3.0 via USB cable.

3.2 Attaching and Removing Heads

1. To attach a head, align the desired attachment with the main unit and gently push it down until it clicks into place.

2. To remove a head, hold the main unit firmly and pull the attachment upwards.
3. Ensure the device is turned off before changing any heads.

4. Operating Instructions

4.1 General Operation

- Press the power button to turn the device ON/OFF.
- Ensure your skin is clean and dry before epilating or trimming, unless using a wet application for specific heads.
- Hold the device at a 90-degree angle to the skin for optimal results.



Image 4.1.1: The Pluxy Epil Pro 3.0 designed for gentle and effective hair removal.

4.2 Using the Epilator Head (Facial Hair Removal)

1. Attach the epilator head to the main unit.

2. Ensure your skin is clean and dry. For sensitive skin, a warm shower beforehand can help open pores.
3. Hold the skin taut with one hand.
4. Gently glide the epilator against the direction of hair growth, maintaining a 90-degree angle.
5. Move slowly and steadily. Do not press too hard.

4.3 Using the Nose Trimmer Head

1. Attach the nose trimmer head.
2. Carefully insert the trimmer tip into the nostril or ear canal.
3. Move the device in a circular motion to trim unwanted hair.
4. Do not insert too deeply to avoid injury.

4.4 Using the Body Hair Trimmer Head

1. Attach the body hair trimmer head.
2. Hold the device flat against the skin and move it slowly against the direction of hair growth.
3. This head is suitable for larger areas of the body.

4.5 Using the Eyebrow Trimmer Head

1. Attach the eyebrow trimmer head.
2. Carefully shape and trim eyebrows by moving the trimmer in small, controlled strokes.
3. Use caution around the eyes.

4.6 Using the Massage Head

1. Attach the massage head.
2. Gently glide the massage head over your face or body in circular motions.
3. This head is designed to promote relaxation and improve skin circulation.

4.7 Using the Grinding Head (Callus Remover)

1. Attach the grinding head.
2. Use on dry, hardened skin areas, typically on feet.
3. Gently move the head over the callus until the desired smoothness is achieved.
4. Do not apply excessive pressure or use on broken skin.

4.8 Using the Dead Skin Brush (Facial Cleansing)

1. Attach the dead skin brush head.
2. Apply a small amount of facial cleanser to your face or directly to the brush.
3. Gently move the brush in circular motions across your face to cleanse and exfoliate.
4. Rinse your face and the brush thoroughly after use.



Image 4.8.1: Visual guide to the 7-in-1 functions of the Pluxy Epil Pro 3.0.

5. Care and Maintenance

5.1 Cleaning the Device

The Pluxy Epil Pro 3.0 is designed for full body water washing, making cleaning simple and hygienic.

1. Ensure the device is turned off and disconnected from the charging cable before cleaning.
2. Remove the attached head from the main unit.
3. Rinse the head under running water to remove hair and debris. For thorough cleaning, a small brush (not included) can be used.
4. The main unit can also be rinsed under running water. Avoid using harsh chemicals or abrasive cleaners.
5. Allow all parts to air dry completely before reassembling or storing.



Image 5.1.1: Cleaning the water-resistant Pluxy Epil Pro 3.0 under running water.

5.2 Storage

- Store the device and its accessories in a cool, dry place, away from direct sunlight and extreme temperatures.
- Keep the protective caps on the heads when not in use to prevent damage.

6. Troubleshooting

If you encounter any issues with your Pluxy Epil Pro 3.0, please refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Device does not turn on.	Low battery or no charge.	Charge the device fully using the provided USB cable.

Problem	Possible Cause	Solution
Poor hair removal performance.	Head is dirty or improperly attached. Incorrect usage angle.	Clean the head thoroughly. Ensure the head is securely attached. Hold the device at a 90-degree angle against the skin and move slowly against hair growth.
Device stops working during use.	Battery is depleted.	Recharge the device.
Skin irritation after use.	Sensitive skin. Device used on irritated skin.	Ensure skin is clean and dry before use. Apply a soothing lotion after use. Avoid using on irritated or broken skin.

7. Technical Specifications

Feature	Specification
Model Name	Pluxy Epil Pro 3.0
Brand	LILOVE
Color	White
Power Source	Battery Powered (USB Charging)
Voltage	5 Volts
Power	3 W
Cleaning Method	Full Body Water Washable
Package Dimensions	18.1 x 14.6 x 5.2 cm
Weight	270 grams
Manufacturer	KROXY

8. Warranty and Support

For warranty information, technical support, or any questions regarding your LILOVE Pluxy Epil Pro 3.0, please refer to the contact information provided with your purchase or visit the official LILOVE website. Please have your product model name and purchase details ready when contacting support.

© 2023 LILOVE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C4YS6XQ2

More documents and user manuals: **https://manuals.plus/**