KITCHMIX WT-340A

KITCHMIX 4-Slice Retro Toaster (Model WT-340A) User Manual

Brand: KITCHMIX | Model: WT-340A

Introduction

This manual provides essential information for the safe and efficient operation of your KITCHMIX 4-Slice Retro Toaster. Please read these instructions carefully before first use and keep them for future reference.

Important Safety Instructions

- Read all instructions before operating the toaster.
- Do not touch hot surfaces. Use handles or knobs.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- To protect against electrical shock, do not immerse cord, plugs, or toaster in water or other liquid.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Do not use the toaster for other than intended use.
- Oversize foods, metal foil packages, or utensils must not be inserted in a toaster as they may create a fire or risk of electric shock.
- A fire may occur if toasters are covered or touching flammable material, including curtains, draperies, walls, and the like, when in operation.
- Do not attempt to dislodge food when the toaster is plugged in.
- Do not operate unattended.

Product Features

- **1.5 Inch Extra-wide Slots:** Accommodates various items such as waffles, muffins, and bagels.
- **6 Shade Browning Levels:** Adjustable settings from light to dark to suit individual preferences.
- **1650W High Power & 360° Baking Mode:** Ensures even and fast toasting on both sides.
- **Dual Independent Control Panels:** Allows for different settings to be used simultaneously for each pair of slots.
- **Retro Design:** Features a classic aesthetic that complements various kitchen decors.
- **Easy to Use & Clean:** Equipped with removable crumb trays and integrated cord wrap storage.



Image of the KITCHMIX 4-Slice Retro Toaster in white, showcasing its four wide slots and retro design, suitable for various bread types.

Setup

1. Unpack the toaster and remove all packaging materials.
2. Place the toaster on a stable, heat-resistant, and dry surface. Ensure there is adequate clearance around the toaster for ventilation.
3. Ensure the removable crumb trays are properly inserted into their slots at the bottom of the toaster.

4. Plug the power cord into a grounded electrical outlet. The toaster is now ready for use.

Operating Instructions

Basic Toasting

1. Insert bread slices, bagels, or other items into the toaster slots. Ensure items are not too thick or too large to fit without force.
2. Select your desired browning level using the shade control knob (settings 1-6). Lower numbers result in lighter toast, higher numbers result in darker toast.
3. Press down the toast lever until it locks into place. The indicator light for the selected side will illuminate, and the toasting cycle will begin.
4. The toast will automatically pop up when the cycle is complete.



A visual guide showing the steps to use the toaster: inserting bread, pressing the lever, setting the shade knob, and automatic pop-up.

Special Functions

- **CANCEL:** Press the CANCEL button to stop the toasting cycle at any time. This will immediately eject the items from the slots.

- **BAGEL:** Press the BAGEL button after lowering the toast lever. This function is designed to toast the cut side of bagels while gently warming the other side.
- **DEFROST:** Press the DEFROST button after lowering the toast lever. This function thaws and toasts frozen bread, adjusting the toasting time accordingly.



Image illustrating the three function buttons: Cancel, Bagel, and Defrost, with their respective indicator lights.



Visual representation of the 6 browning levels, showing toast shades from light (Level 1, 70s) to dark (Level 6, 210s).

Your browser does not support the video tag.

Video demonstrating the KITCHMIX 4-Slice Retro Toaster's dual independent controls and wide slots, highlighting its suitability for family use.

Your browser does not support the video tag.

Video highlighting the aesthetic design of the KITCHMIX 4-Slice Retro Toaster and its various features in a kitchen setting.

Maintenance and Cleaning

1. Always unplug the toaster from the electrical outlet and allow it to cool completely before cleaning.
2. Pull out the removable crumb trays located at the bottom of the toaster.
3. Discard accumulated crumbs and wipe the trays with a damp cloth. Ensure the trays are thoroughly dry before reinserting them into the toaster.
4. Wipe the exterior of the toaster with a soft, damp cloth. Do not use abrasive cleaners, metal scouring pads, or harsh chemicals, as these can damage the finish.
5. Never immerse the toaster in water or any other liquid.
6. For storage, wrap the power cord around the cord wrap storage area located at the bottom of the toaster.



Image showing the slide-out crumb trays being removed from the KITCHMIX 4-Slice Retro Toaster for easy cleaning.

Troubleshooting

- **Toaster not working:** Ensure the power cord is securely plugged into a functional electrical outlet. Verify that the toast lever is fully pressed down and locked into place.
- **Uneven toasting:** Ensure bread slices are centered within the slots. Adjust the browning level as needed; some bread types may require different settings.
- **Bread stuck:** Unplug the toaster from the power outlet. Carefully remove the stuck bread using non-metallic utensils (e.g., wooden tongs). Never use metal objects or force the lever.
- **Smoke from toaster:** A small amount of smoke may occur during the first few uses as manufacturing residues burn off. This is normal. If excessive smoke occurs, it may be due to accumulated crumbs. Press the CANCEL button, unplug the toaster, and clean the crumb trays.

Specifications

Feature	Detail
Brand	KITCHMIX

Feature	Detail
Model Number	WT-340A
Color	White
Material	Stainless Steel
Product Dimensions (D x W x H)	12.2"D x 13.39"W x 7.28"H
Wattage	1650 watts
Voltage	110 Volts
Slot Count	4
Number of Settings	6
Special Features	Removable Crumb Trays
Item Weight	5.95 Pounds
UPC	614160288057, 614160288033

Warranty and Support

For detailed warranty information, product registration, or technical support, please refer to the documentation included with your product packaging. You may also visit the official KITCHMIX website for further assistance. Please retain your purchase receipt as proof of purchase for any warranty claims.

Additional Resources

For more information about KITCHMIX products and accessories, please visit theKITCHMIX Brand Store on Amazon.

© 2026 KITCHMIX. All rights reserved.