TAKARA TOMY BX-10

Takara Tomy Beyblade X BX-10 Extreme Stadium Instruction Manual

1. Product Overview

The Takara Tomy Beyblade X BX-10 Extreme Stadium is designed for dynamic Beyblade battles, featuring a unique X-Dash gimmick that enhances speed and impact. This stadium provides an exciting arena for Beyblade enthusiasts.



Image 1: Takara Tomy Beyblade X BX-10 Extreme Stadium in its retail packaging.

2. What's Included

The BX-10 Extreme Stadium set includes the following components:

- Cover (1)
- Main Unit (1)
- Fasteners (4)
- Bey Code Card (1)

3. Setup Instructions

The Takara Tomy Beyblade X BX-10 Extreme Stadium requires minimal assembly. Follow these steps to prepare your stadium for battle:

1. Carefully remove all components from the packaging.

2. Place the main unit of the stadium on a flat, stable surface.
3. Align the cover with the main unit and secure it using the four provided fasteners. Ensure all fasteners are securely attached to prevent movement during play.
4. Confirm that the stadium is stable and ready for use.

Note: No batteries are required for the operation of this stadium.

4. Operating Instructions

The BX-10 Extreme Stadium is designed to enhance Beyblade battles with its X-Dash gimmick. Follow these guidelines for optimal play:

- **Launching Beyblades:** Use your Beyblade launcher to launch your Beyblade tops into the stadium. Aim for the central area to initiate dynamic movement.
- **X-Dash Gimmick:** The stadium features a super accelerated X-Dash gimmick. When Beyblades interact with the stadium's specific design elements, they can achieve incredible speeds and generate powerful impacts, leading to intense clashes.
- **Battle Rules:** Standard Beyblade X battle rules apply. The last Beyblade spinning or the one that knocks its opponent out of the stadium wins the round.

5. Maintenance

To ensure the longevity and optimal performance of your Beyblade X BX-10 Extreme Stadium, follow these maintenance tips:

- **Cleaning:** Wipe the stadium surfaces with a soft, dry cloth after use to remove dust and debris. For stubborn marks, a slightly damp cloth can be used, followed by immediate drying.
- **Storage:** Store the stadium in a cool, dry place away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically inspect the stadium for any signs of wear or damage. Ensure all fasteners are secure.

6. Troubleshooting

If you encounter any issues with your Beyblade X BX-10 Extreme Stadium, consider the following:

- **Unstable Stadium:** Ensure all four fasteners are correctly and tightly secured. Place the stadium on a completely flat and stable surface.
- **Reduced Performance:** Ensure your Beyblades are in good condition and launched correctly. The X-Dash gimmick relies on the Beyblades' interaction with the stadium's design.
- **Missing Parts:** Refer to the 'What's Included' section. If any essential parts are missing upon unboxing, contact customer support.

7. Specifications

- **Model Number:** BX-10
- **Brand:** Takara Tomy
- **Material:** Plastic
- **Item Weight:** 500 Grams
- **Item Dimensions:** 16.14 x 17.72 x 6.3 inches
- **Assembly Required:** No
- **Batteries Required:** No

- **Recommended Age:** 6 years and up

8. Official Product Video

Watch the official product overview video to see the Takara Tomy Beyblade X BX-10 Extreme Stadium in action and learn more about its features.

Your browser does not support the video tag.

Video 1: Product Overview of the Takara Tomy Beyblade X BX-10 Extreme Stadium, demonstrating its features and the X-Dash gimmick.

9. Safety Information

Please observe the following safety precautions:

- This product contains small parts and is not suitable for children under 3 years of age due to choking hazards.
- Always play in a clear, open area to avoid injury to yourself or others.
- Do not modify the stadium or Beyblades, as this may affect performance and safety.
- Adult supervision is recommended during play.

10. Warranty and Support

For any questions, concerns, or support regarding your Takara Tomy Beyblade X BX-10 Extreme Stadium, please refer to the manufacturer's official website or contact their customer service. Specific warranty details may vary by region and retailer.

© 2023 Takara Tomy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question