Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Maxitoc B0C582MJJG

Maxitoc Universal Remote Control for Samsung Smart TVs

Model: B0C582MJJG

Instruction Manual

Introduction

This manual provides comprehensive instructions for the Maxitoc Universal Remote Control, designed for seamless operation with a wide range of Samsung Smart TVs and monitors. This remote offers out-of-the-box functionality, eliminating the need for complex programming or pairing. Please read this manual thoroughly to ensure proper use and to maximize your viewing experience.

Setup

Battery Installation

The remote requires two AAA batteries (not included). To install, slide open the battery compartment cover on the back of the remote. Insert the batteries, ensuring correct polarity (+/-), then close the cover. The remote is designed to work immediately without additional setup.



Figure 1: Battery installation in the remote control.

No Programming Needed

This remote control is pre-programmed for universal compatibility with Samsung Smart TVs and monitors. No manual programming or pairing is required. Simply insert the batteries, and the remote is ready for use.

Operating Instructions

Button Functions Overview

Refer to the diagram below for a detailed overview of the remote control's buttons and their respective functions.



Power	Press to turn the TV on or off. For The Frame model. When watching TV. press to switch to Art mode, In Art mode, press to switch to the Media Home Press and hold to turn off the TV completely
Menu	Rerer to guide
Settings Number -Color button	Each time you press this button, Settings menu/virtual numeric pad/Option pad with Color buttons are displayed alternately. • Use this button to access additional options that are specific to the feature in use. • Press to bring up the virtual numeric pad on the screen. Use the numeric keypad to enter numeric values. Select numbers and then select Done or Enter Number to enter a numeric value .Use to change the channel enter PIN enter ZIP code etc
Multi View	Press the button to directly enter the Multi View function.
❶ Directional button (up, down, left, right)	Use to navigate the menu or move the focus to highlight items on the Home Screen.
❷ Select	Selects or runs a focused item. When pressed while you are watching a broadcast programme, detailed programme information appears.
Return	Press to return to the previous menu. When pressed for 1 second or more, the running function is terminated. When pressed while you are watching a programme, the previous channel appears.
Smart Hub	Returns to the Home Screen.
Play/pause	When pressed, the playback controls appear. Using these controls, you can control the media content that is playing. To use Game Bar, press and hold the button in **Game Mode**. • Game Bar may not be supported depending on the model or geographical area.
+/— Volume	Move the button up or down to adjust the volume. To mute the sound, press the button.
∧/∨ Channel	Move the button up or down to change the channel. To see the Guide screen, press the button.When pressed for 1 second or more, the Channel List screen appears.Press and hold the button up or down to quickly change the channel. • Available apps may differ depending on the geographical area or contents provider
❸ Launch app button	Launch the app indicated by the button

Figure 2: Detailed button layout and functions.

- **Power Button:** Turns the TV on or off. For Frame models, press to switch to Art Mode; press and hold to turn off the TV completely.
- **Menu Button:** Accesses the TV's main menu.
- **Settings/Number Pad Button:** Displays settings menu or a virtual numeric pad for channel input.
- **Multi-View Button:** Activates the multi-window feature on compatible TV models.
- **Directional Buttons (Up, Down, Left, Right):** Navigates through menus and options.
- **Select Button:** Confirms a highlighted item or selection.
- **Return Button:** Returns to the previous screen or exits a menu.
- **Smart Hub Button:** Direct access to the Smart Hub home screen.
- **Play/Pause Button:** Controls media playback.
- **Volume Buttons (+/-):** Adjusts the TV volume.
- **Channel Buttons (Up/Down):** Changes TV channels.

Streaming Service Shortcut Buttons

The remote features dedicated shortcut buttons for popular streaming services: Netflix, Prime Video, Hulu, and Disney+.

Pressing these buttons provides one-key access to your favorite channels. Note: These streaming buttons are compatible with 2022 and 2023 Samsung TV models and most Samsung Smart TVs released since 2016 using the Tizen system. They do not work on models running Orsay OS or built-in web browsers.



Figure 3: Streaming service shortcut buttons.

Multi-View Function

The Multi-View feature allows for a multi-window display on compatible Samsung TV models (e.g., 2022-2023 models). Use the dedicated Multi-View button to activate this function.



Figure 4: Multi-View function in action.

Infrared Signal and Response

This remote utilizes a stable infrared signal, offering up to 40 feet of precise control and a quick 0.2-second response time for seamless operation.



Figure 5: Infrared signal and quick response.

Compatibility

Compatible TV and Monitor Models

This universal remote control is compatible with a wide range of Samsung Smart TVs, including models such as CU8000, Q60C, Q70C, Q80C, QN800C, QN850C, QN85C, QN900C, QN90C, S90C, S95C, LS03C, Q60B, QN800B, QN900B, S95B, LS01B, LS03B, and others. It also supports Samsung Smart Monitors like G65B, G7, G70B, G85SB, M70B, M8, S55BG97.



Figure 6: Compatible Samsung TV and Monitor models.

Compatible Remote Control Models

This remote is designed to replace various Samsung remote control models, including BN59-01312A, BN59-01312F, BN59-01312D, BN59-01312E, BN59-01312G, BN59-01312K, BN59-01312L, BN59-01312M, BN59-01312X, BN59-01312U, BN59-01312T, BN59-01329A, BN59-01329C, BN59-01329F, BN59-01330A, BN59-01330C, BN59-01330H, BN59-01330N, BN59-01330Q, BN59-01330M, BN59-01312Q, BN59-01391A, BN59-01289A, BN59-01388A, BN59-01388B, TM2360E, BN59-01432A, TM2361E, BN59-01439A, TM2261S, BP59-00149A, TM2280E, BN59-01385A, TM2281E, BN59-01391A, and others.



Figure 7: Examples of compatible original remote controls.

Limitations

This remote does not include voice control functionality. The multi-window feature is only available for TV models that natively support it (e.g., 2022-2023 models). Streaming buttons may not function on TVs running Orsay OS or those with built-in web browsers.

Maintenance

To ensure optimal performance and longevity of your remote control, keep it clean and dry. Avoid exposing it to extreme temperatures, humidity, or direct sunlight. Use a soft, dry cloth for cleaning. Do not use abrasive cleaners or solvents.

Troubleshooting

If the remote control is not responding, first check the batteries. Ensure they are inserted correctly with the proper polarity

and are not depleted. Replace batteries if necessary. If issues persist, ensure there are no obstructions between the remote and the TV's infrared receiver. For further assistance, please contact customer support.

Specifications

- **Product Dimensions:** 5.91 x 1.18 x 0.43 inches
- **Item Weight:** 1.44 ounces
- **Batteries:** 2 AAA batteries required (not included)
- **Special Feature:** Durable & Rapid Response, out-of-the-box functionality
- **Max Number of Supported Devices:** 1
- **Compatible Devices:** For Samsung Smart TVs

Warranty and Support

The manufacturer tests each remote before delivery to ensure functionality. If you encounter any problems while using the product, please contact Maxitoc customer support for assistance. We are committed to providing a satisfactory solution promptly.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C582MJJG

More documents and user manuals: **https://manuals.plus/**