Ariete Ariete 4625 220V

Ariete 4625 Dual Basket Air Fryer User Manual

Model: Ariete 4625 220V

1. Important Safety Instructions

Read all instructions carefully before using the appliance. Keep this manual for future reference.

- Do not immerse the appliance, cord, or plug in water or other liquid.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- This appliance is intended for household use only.

2. Product Overview

The Ariete 4625 Dual Basket Air Fryer is designed for healthy cooking with minimal oil. It features two independent cooking zones, a digital display, and pre-set programs for various dishes.



Front view of the Ariete 4625 Dual Basket Air Fryer, showcasing its sleek black and silver design with a digital control panel and two pull-out baskets.



The Ariete 4625 Air Fryer with callouts for its touchscreen panel, 11 preset programs, and 9-liter dual basket capacity.

Key Features:

- **Rapid Air Technology:** Ensures even and fast cooking for crispy results with less oil.
- **Adjustable Temperature:** Temperature range from 80°C to 200°C for precise cooking control.
- **Dual Basket Design:** Two independent 4.5-liter baskets (9 liters total capacity) allow cooking multiple dishes simultaneously.
- **SYNC Function:** Synchronizes cooking times for both baskets, ensuring meals are ready at the same time.
- **Digital Display:** Intuitive control panel with 11 pre-set programs.
- **Power:** 2100 Watts for efficient performance.

3. Setup and First Use

Unpacking:

- Remove all packaging materials, stickers, and labels from the appliance.
- Remove the baskets and crisper plates from the appliance.
- Wash the baskets and crisper plates thoroughly with hot water, dish soap, and a non-abrasive sponge.
- Wipe the inside and outside of the appliance with a damp cloth.

Placement:

- Place the appliance on a stable, horizontal, and heat-resistant surface.
- Ensure there is at least 10 cm of free space on the back and sides, and 10 cm above the appliance.
- Do not place anything on top of the appliance.

Before First Use:

- Plug the appliance into a grounded wall outlet.
- Run the air fryer empty for about 10-15 minutes at 180°C to burn off any manufacturing residues. A slight odor may be present, which is normal.
- Allow the appliance to cool down completely, then clean the baskets and crisper plates again.

4. Operating Instructions

General Operation:

1. Place the crisper plate into the basket.
2. Place ingredients into the basket. Do not exceed the MAX fill line.
3. Slide the basket back into the air fryer.
4. Plug the power cord into a wall outlet.
5. Press the power button to turn on the appliance.
6. Select a pre-set program or manually set the temperature and time for each basket using the digital controls.



Demonstration of adding a small amount of oil to french fries in one of the air fryer baskets before cooking, highlighting the minimal oil requirement.



A hand pressing a button on the digital control panel of the Ariete 4625, showing the clear display of temperature and time settings for both baskets.

7. Press the START button to begin cooking.
8. Some ingredients may require shaking halfway through the cooking time. Pull out the basket by the handle, shake it, and then slide it back into the appliance.
9. When cooking is complete, the timer will beep. Carefully pull out the baskets and remove the cooked food.

Using the SYNC Function:

The SYNC function allows you to cook two different foods with different settings, ensuring they finish cooking at the same time.

1. Place ingredients in both baskets.
2. Set the desired temperature and time for Basket 1.
3. Set the desired temperature and time for Basket 2.
4. Press the "SYNC FINISH" button. The appliance will automatically adjust the start times for each basket so they complete cooking simultaneously.
5. Press START.

Pre-set Programs:

The Ariete 4625 comes with 11 pre-set programs for common dishes. Refer to the icons on the digital display for specific programs (e.g., fries, chicken, fish, steak, cake, vegetables, shrimp, pizza, bacon, toast, reheat).
To use a pre-set program:

1. Place ingredients in the desired basket(s).
2. Select the basket (1 or 2).
3. Press the menu button repeatedly to cycle through the pre-set programs until the desired icon is highlighted.
4. The appliance will automatically set the recommended temperature and time. You can adjust these manually if needed.
5. Press START.

5. Cleaning and Maintenance

Regular cleaning ensures optimal performance and extends the lifespan of your air fryer.

Cleaning After Each Use:

- Unplug the air fryer and allow it to cool down completely before cleaning.
- Wipe the outside of the appliance with a damp cloth.

- The baskets and crisper plates are dishwasher safe. Alternatively, wash them with hot water, dish soap, and a non-abrasive sponge.



The two air fryer baskets pulled out, revealing the removable crisper plates inside, which are designed for easy cleaning.

- Clean the inside of the appliance with a non-abrasive sponge or cloth. Remove any food residue from the heating element using a cleaning brush.
- Ensure all parts are completely dry before storing.

Storage:

Store the appliance in a cool, dry place. Ensure all parts are clean and dry before storage.

6. Troubleshooting

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance is not plugged in.	Plug the power cord into a grounded wall outlet.
Food is not cooked evenly.	Too much food in the basket; food not shaken.	Reduce the amount of food; shake the basket halfway through cooking.
White smoke coming from the appliance.	Grease residue from previous use; fatty ingredients.	Clean the basket and crisper plate thoroughly; remove excess fat from ingredients.
Food is not crispy.	Not enough oil; temperature too low; cooking time too short.	Add a small amount of oil; increase temperature; extend cooking time.

7. Specifications

Feature	Detail
Brand	Ariete
Model Number	Ariete 4625 220V
Color	Silver

Feature	Detail
Product Dimensions	35.5 x 40.5 x 33 cm (13.98 x 15.94 x 12.99 inches)
Capacity	9 Liters (2 x 4.5 Liters baskets)
Power	2100 Watts
Voltage	220 Volts
Material	Plastic, Aluminum
Automatic Shut-off	Yes
Special Features	Temperature control, Programmable
Item Weight	3 Kilograms (6.61 lbs)



Diagram showing the dimensions of the Ariete 4625 Dual Basket Air Fryer: 35.5 cm depth, 40.5 cm width, and 33 cm height.

8. Warranty and Support

For warranty information and customer support, please refer to the warranty card included with your purchase or visit the official Ariete website. Keep your proof of purchase for any warranty claims.
Manufacturer: Ariete
Model: Ariete 4625 220V
For further assistance, please contact Ariete customer service.

© 2024 Ariete. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question