X-IMVNLEI X-IDRONE I9

X-IMVNLEI Drone User Manual

Model: X-IDRONE I9

Introduction

This manual provides comprehensive instructions for the safe operation, maintenance, and troubleshooting of your X-IMVNLEI Drone. Please read this manual thoroughly before operating the drone to ensure proper usage and to prevent damage or injury.

1. Setup

1.1 Unboxing and Components

Carefully unpack all items from the box. Verify that all components are present according to the list below:

- X-IMVNLEI Drone
- Remote Controller
- 2 x Lithium-ion Batteries
- 4 x Spare Propellers
- USB Charging Cable
- Screwdriver
- User Manual (this document)



Figure 1.1: Overview of the X-IMVNLEI Drone and included accessories, including the drone, remote controller, batteries, and spare propellers.



Figure 1.2: The drone and its accessories as they appear when unboxed, showing the compact packaging.

1.2 Battery Installation and Charging

The drone comes with two Lithium-ion batteries. Ensure both batteries are fully charged before first use.

1. Connect the USB charging cable to the battery and a compatible USB power source (e.g., computer USB port, USB wall adapter).
2. The indicator light on the battery will show charging status (refer to battery specific instructions for light indications).
3. Once fully charged, disconnect the battery.
4. To install the battery into the drone, slide it into the designated battery compartment until it clicks into place.



Figure 1.3: Illustration of the two included batteries and the drone's battery slot, highlighting the ease of battery insertion.



Figure 1.4: A close-up view of the battery being correctly inserted into the drone's battery compartment.

1.3 Propeller Installation

The drone's propellers are designed for easy installation. Ensure correct propeller orientation (A and B) as indicated on the drone arms and propellers.

1. Match the propeller type (A or B) to the corresponding motor shaft.
2. Press the propeller firmly onto the motor shaft until it is securely seated.
3. Verify that all propellers spin freely without obstruction.

1.4 Controller Setup and App Connection

The remote controller operates on Wi-Fi technology. For advanced features and live video feed, download the dedicated drone application on your smartphone.

1. Insert batteries into the remote controller (not included, typically AA or AAA).
2. Power on the drone, then power on the remote controller.
3. On your smartphone, connect to the drone's Wi-Fi network (usually named "X-IMVNLEI-XXXX").
4. Open the drone application. The app should automatically connect to the drone, displaying the live video feed.



Figure 1.5: The remote controller with a smartphone mounted, showing the live video feed from the drone's camera.

2. Operating Instructions

2.1 Basic Flight Controls

- **One-Button Takeoff/Landing:** Press the designated button on the controller for automatic takeoff or landing.
- **Altitude Hold:** The drone maintains a stable altitude, making it easier to control.
- **3 Speed Modes:** Adjust flight speed (low, medium, high) to suit your skill level and environment.
- **Headless Mode:** In this mode, the drone's orientation is relative to the pilot, simplifying control regardless of the drone's front direction.

2.2 Advanced Flight Features

- **360° Flip:** Execute impressive aerial stunts with a single button press.



Figure 2.1: The drone executing a 360-degree flip, demonstrating its acrobatic capabilities.

- **Optical Flow Positioning:** Utilizes a downward-facing camera to analyze ground patterns, providing stable hovering and precise positioning, especially indoors.



Figure 2.2: Visual representation of the drone's optical flow positioning system, showing how it uses ground data for stable flight.



Figure 2.3: The drone maintaining a stable hover, illustrating the effectiveness of optical positioning in keeping it in place.

- **Gesture Photo/Video:** Perform specific hand gestures in front of the camera to trigger photo or video recording.



Figure 2.4: Example of hand gestures used to control the drone's camera functions, allowing for hands-free photo and video capture.

- **Custom Flight Path (Trajectory Flight):** Draw a desired flight path on your smartphone screen, and the drone will automatically follow it.



Figure 2.5: A smartphone screen displaying a custom flight path drawn by the user, which the drone will then autonomously follow.

2.3 Camera Operation and FPV

The drone is equipped with dual cameras, providing versatile recording options and a live First Person View (FPV) experience.

- **Dual Cameras:** One camera is located at the front, and another at the bottom, allowing for diverse perspectives during flight.
- **720p Video Resolution:** Capture clear aerial footage and photos. The front camera is adjustable up to 90 degrees.
- **Live FPV Feed:** View real-time video from the drone's camera directly on your connected smartphone via the app.



Figure 2.6: The drone's 720p camera, highlighting its 90-degree adjustable angle for capturing various perspectives.



Figure 2.7: An illustration of the drone's dual camera system, showing both the front and bottom cameras for comprehensive aerial views.

3. Maintenance

Regular maintenance ensures the longevity and optimal performance of your drone.

3.1 Propeller Care

- Inspect propellers for cracks, bends, or damage before each flight.
- Replace damaged propellers immediately using the provided spare parts.
- Keep propellers clean from dust and debris.

3.2 Battery Care

- Do not overcharge or over-discharge batteries.
- Store batteries in a cool, dry place away from direct sunlight and extreme temperatures.
- If storing for extended periods, charge batteries to approximately 50% capacity.

3.3 Cleaning

- Use a soft, dry cloth to clean the drone's body.
- Avoid using liquid cleaners or solvents that may damage electronic components.
- Gently clean camera lenses with a microfiber cloth.

4. Troubleshooting

If you encounter issues with your drone, refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Drone does not respond to controller.	Batteries low in drone or controller. Not properly paired. Interference.	Charge/replace batteries. Re-pair drone and controller (refer to pairing instructions in app). Move to an open area away from other Wi-Fi devices.
Poor video quality/no FPV feed.	Weak Wi-Fi signal. App not connected. Camera lens dirty.	Ensure drone is within Wi-Fi range. Reconnect app to drone's Wi-Fi. Clean camera lens.
Drone drifts during flight.	Calibration needed. Damaged propeller.	Perform gyroscope calibration (refer to app instructions). Replace damaged propeller.

5. Specifications

Key technical specifications for the X-IMVNLEI Drone:

Feature	Detail
Brand	X-IMVNLEI
Model	X-IDRONE I9
Dimensions (L x W x H)	20 x 15 x 5 cm
Item Weight	68 Grams
Battery Type	Lithium-ion (2 included)
Video Recording Resolution	720p
Connectivity Technology	Wi-Fi
Remote Control Technology	Wi-Fi
Video Capture Format	MP4
Media Type	Micro SD (card not included)
Material	Plastic
Age Range (Description)	Adult

6. Warranty and Support

Specific warranty information for the X-IMVNLEI Drone is not provided in this manual. Please refer to the product packaging or the retailer's website for warranty details.
For technical support, troubleshooting assistance beyond this manual, or inquiries regarding parts and service, please contact the manufacturer or your point of purchase. Keep your purchase receipt as proof of purchase for any warranty claims.

© 2023 X-IMVNLEI. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question