ZOOAOXO M600-128GB

ZOOAOXO 128GB MP3 Player User Manual

Model: M600-128GB

1. Introduction

Thank you for choosing the ZOOAOXO 128GB MP3 Player. This manual provides detailed instructions on how to set up, operate, and maintain your device. Please read this manual carefully before use to ensure optimal performance and longevity of your MP3 player.

2. Product Overview

The ZOOAOXO 128GB MP3 Player is a versatile device designed for music enthusiasts. It features a large storage capacity, advanced Bluetooth connectivity, and a built-in HD speaker for a superior audio experience.

Key Features:

- **128GB Large Storage:** Easily store thousands of songs, creating a mobile music library.
- **Bluetooth 5.2:** Ensures stable and strong anti-interference transmission for wireless audio. Supports connection to Bluetooth headsets and speakers.
- **HiFi Lossless Sound:** Equipped with a powerful audio decoder chip for original, high-fidelity sound.
- **Built-in HD Speaker:** Play music directly without earphones, or connect headphones for private listening.
- **Multifunctional:** Includes music playback, FM radio, voice recorder, and e-book reader.
- **Compact Design:** Mini, lightweight (70 grams), with a durable metal shell and touch buttons.

Components:

Familiarize yourself with the device's layout and controls.





Figure 2.1: Front and back view of the ZOOAOXO 128GB MP3 Player, highlighting its compact design and controls.



Figure 2.2: Illustration of the ZOOAOXO MP3 Player's various functions including music, Bluetooth, picture, recorder, e-book, A-B repeat, and FM radio.

3. Setup

3.1 Charging the Device

Before first use, fully charge the MP3 player. Connect the provided USB cable to the device's charging port and the other end to a USB power adapter (not included) or a computer's USB port. The battery indicator on the screen will show charging status.

3.2 Transferring Music and Files

To transfer music, videos, or e-books to your MP3 player:

1. Connect the MP3 player to your computer using the provided USB cable.

2. The device will appear as a removable disk drive on your computer.
3. Drag and drop your desired audio, video, or text files into the appropriate folders on the MP3 player (e.g., 'Music', 'Videos', 'E-book').
4. Safely eject the device from your computer before disconnecting the USB cable.

Note: An included USB to micro SD converter can be used to transfer files directly to the memory card if your computer lacks a micro SD port.

3.3 Initial Power On

Press and hold the power button until the screen lights up. Follow any on-screen prompts for initial setup, such as language selection.

4. Operating Instructions

4.1 Music Playback

From the main menu, select 'Music'. You can browse by Artist, Album, Song, or Playlist. Use the navigation buttons to select and play your desired track. The device supports MP3, AAC, APE, FLAC, WMA, WAV, and OGG formats.



Figure 4.1: HiFi Sound Quality features, including DAC audio decoder chip and support for various audio formats.

4.2 Bluetooth Connectivity

To connect to Bluetooth headphones or speakers:

1. Ensure your Bluetooth audio device is in pairing mode.
2. On the MP3 player, navigate to 'Bluetooth' from the main menu.
3. Turn Bluetooth 'On' and select 'Search Device'.
4. Select your device from the list to pair. Once paired, audio will be routed wirelessly.



Figure 4.2: Bluetooth 5.2 connectivity to headphones and speakers.

4.3 FM Radio

To use the FM radio function, you must first plug in wired headphones, as they act as the antenna. From the main menu, select 'FM Radio'. You can then auto-scan for stations or manually tune to a frequency.

4.4 Voice Recorder

Select 'Recorder' from the main menu. Press the record button to start and stop recording. Recordings are saved as audio files on the device.



Figure 4.3: Simple Recording Function for interviews, learning, and conferences.

4.5 E-book Reader

Select 'E-book' to access text files. The device supports basic text file viewing.

4.6 Built-in Speaker

The MP3 player features a built-in HD speaker, allowing you to play music without connecting earphones. This is ideal for casual listening or sharing audio in a quiet environment. To switch between speaker and headphone output, ensure headphones are unplugged for speaker use.




Manufacturer:
Shenzhen Benjie Technology Co., Ltd.
Address:
8th Floor, Block B, Building 10, Huafeng Science and Technology Park, Fengtang Avenue, Fuyong Street, Baoan District, Shenzhen City, Guangdong Province, China
UK REP
Prolinx Global LTD
27 Old Gloucester Street
London, WCIN 3AX, UK
EC REP
Prolinx GmbH
Brehmstr. 56, 40239 Duesseldorf
Germany
RoHs
UK CA
Made in China



Figure 4.4: Close-up view of the ZOOAOXO MP3 Player's built-in HD speaker.

5. Maintenance

5.1 Cleaning

Wipe the device with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as they may damage the screen or casing.

5.2 Storage

Store the MP3 player in a cool, dry place away from direct sunlight and extreme temperatures. Avoid placing heavy objects on the device.

5.3 Battery Care

To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in use for extended periods.

6. Troubleshooting

Problem	Possible Cause	Solution
Device does not power on.	Low battery; device frozen.	Charge the device for at least 30 minutes. If still unresponsive, try a hard reset (refer to device manual for specific button combination, usually holding power button for 10-15 seconds).
Cannot transfer files to the device.	Loose USB connection; driver issue; device not recognized by computer.	Ensure USB cable is securely connected. Try a different USB port or cable. Restart your computer and the MP3 player. Check if the device appears in 'My Computer' or 'Disk Management'.
Bluetooth connection is unstable or fails.	Device too far from MP3 player; interference; pairing issue.	Ensure devices are within Bluetooth range (approx. 10 meters). Turn off other Bluetooth devices to reduce interference. Unpair and re-pair the device.
Touch buttons are overly sensitive.	Normal operation; accidental touches.	Be mindful of how you handle the device. Some models may have a button lock feature to prevent accidental presses; check settings.
Music playback skips or stops.	Corrupted file; low battery; software glitch.	Try playing a different file. Ensure the battery is sufficiently charged. Restart the device.

7. Specifications

Feature	Specification
Brand	ZOOAOXO
Model Name	M600-128GB
Special Feature	FM Radio
Connectivity Technology	Bluetooth 5.2
Memory Storage Capacity	128 GB
Screen Size	1.8 Inches
Compatible Devices	Headphone
Display Technology	LCD
Component Type	Memory
Supported Audio Standards	MP3, AAC, APE, FLAC, WMA, WAV, OGG

8. Warranty and Support

For any issues not covered in this manual, or for warranty inquiries, please contact ZOOAOXO customer support. Refer to the product packaging or the retailer's website for contact information.
Product Identification: X001S51MSN

© 2024 ZOOAOXO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question