Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Orbegozo CG 4061

Orbegozo CG 4061 Coffee Machine User Manual

Model: CG 4061

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions carefully before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or coffee machine in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- The carafe is designed for use with this appliance only. It must never be used on a range top.
- Do not place a hot carafe on a cold or wet surface.
- Do not use a cracked carafe or a carafe having a loose or weakened handle.
- Do not clean carafe with cleansers, steel wool pads, or other abrasive material.

Product Overview

Familiarize yourself with the components of your Orbegozo CG 4061 Coffee Machine.



The Orbegozo CG 4061 coffee machine, shown with a full carafe of freshly brewed coffee. This image highlights the sleek black design and the clear glass carafe.



A direct front view of the Orbegozo CG 4061 coffee machine, emphasizing its compact design and the visible coffee level in the glass carafe.



Side view of the coffee machine, showcasing the water level indicator on the side and the prominent red power button at the base.



A close-up shot of the illuminated red power button, indicating the machine's operational status.



Top view of the coffee machine with the lid open, revealing the water reservoir and the filter basket area, ready for filling.

Components:

- **Water Reservoir:** Located at the back, with clear markings for water levels.
- **Filter Basket:** Removable basket for holding ground coffee and the filter.
- **Glass Carafe:** Heat-resistant glass carafe with a handle and lid, designed to hold up to 12 cups of coffee.
- **Heating Plate:** Keeps the brewed coffee warm.
- **Power Button:** On/Off switch, often illuminated when the machine is operating.

Setup

1. **Unpacking:** Carefully remove the coffee machine and all its components from the packaging. Retain packaging for future storage or transport.
2. **Initial Cleaning:** Before first use, clean all removable parts (carafe, filter basket) with warm, soapy water. Rinse thoroughly and dry. Wipe the exterior of the machine with a damp cloth.
3. **First Brew Cycle (without coffee):**
    - Fill the water reservoir to the "MAX" level with fresh, cold water.

- Place the empty filter basket into its holder.
- Place the empty carafe on the heating plate.
- Plug the power cord into a suitable electrical outlet.
- Press the power button to start a brewing cycle. Allow the full cycle to complete.
- Discard the water from the carafe. This process cleans the internal components and removes any manufacturing residues.

4. **Placement:** Place the coffee machine on a flat, stable, heat-resistant surface, away from the edge of the counter and out of reach of children. Ensure adequate ventilation around the unit.

Operating Instructions

1. **Fill Water Reservoir:** Open the lid of the water reservoir and fill it with fresh, cold water up to the desired number of cups, indicated by the water level markings. Do not exceed the "MAX" level.
2. **Add Coffee Grounds:** Place a paper filter (or the reusable filter if included) into the filter basket. Add the desired amount of ground coffee. A general guideline is one tablespoon of coffee grounds per cup, but adjust to your taste.
3. **Close Lid and Place Carafe:** Close the lid of the coffee machine securely. Ensure the empty glass carafe is correctly positioned on the heating plate.
4. **Start Brewing:** Plug the coffee machine into a power outlet. Press the power button. The indicator light will illuminate, signifying that the brewing process has started.
5. **Brewing Process:** Water will heat up and drip through the coffee grounds into the carafe. The brewing process will take several minutes.
6. **Keep Warm Function:** Once brewing is complete, the machine will automatically switch to a "keep warm" function, maintaining the coffee's temperature on the heating plate. The indicator light will remain on.
7. **Serving:** Carefully remove the carafe from the heating plate to pour coffee. The drip-stop feature will temporarily prevent coffee from dripping onto the heating plate.
8. **Turn Off:** After serving or when the carafe is empty, press the power button again to turn off the machine. Unplug the machine from the power outlet when not in use.

Note: For best results, use fresh, cold water and high-quality coffee grounds. Do not open the lid or remove the carafe during the brewing cycle, as this may cause hot water or coffee to overflow.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the lifespan of your coffee machine.

Daily Cleaning:

- **Unplug:** Always unplug the coffee machine and allow it to cool completely before cleaning.
- **Carafe and Filter Basket:** Remove the carafe and filter basket. Discard used coffee grounds and filter. Wash the carafe and filter basket in warm, soapy water. Rinse thoroughly and dry. These parts are generally top-rack dishwasher safe, but hand washing is recommended for longevity.
- **Exterior:** Wipe the exterior surfaces of the coffee machine with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.
- **Heating Plate:** Wipe the heating plate with a damp cloth. Do not use abrasive materials that could scratch the surface.

Descaling (Every 2-4 Months, or as needed):

Mineral deposits (limescale) can build up in your coffee machine over time, affecting performance and taste. Descale regularly.

1. **Prepare Solution:** Mix 2-4 tablespoons of white vinegar with a full carafe of cold water. Alternatively, use a commercial descaling solution designed for coffee makers, following its instructions.
2. **Run Cycle:** Pour the descaling solution into the water reservoir. Place an empty filter (paper or reusable) in the filter basket. Place the empty carafe on the heating plate.
3. **Brew:** Turn on the coffee machine and allow half of the solution to brew through. Turn off the machine and let it sit for 15-20 minutes to allow the solution to work.
4. **Complete Cycle:** Turn the machine back on and allow the remaining solution to brew through.
5. **Rinse Cycles:** Discard the descaling solution. Fill the water reservoir with fresh, cold water and run at least two full brewing cycles with only water to rinse out any remaining descaling solution.

Caution: Never immerse the main body of the coffee machine, cord, or plug in water or any other liquid.

Troubleshooting

Problem	Possible Cause	Solution
Coffee does not brew.	Machine not plugged in; power button not pressed; water reservoir empty.	Ensure machine is plugged in and power button is on. Fill water reservoir.
Coffee is too weak or too strong.	Incorrect coffee-to-water ratio; coffee grind too coarse/fine.	Adjust amount of coffee grounds. Use appropriate grind for drip coffee.
Coffee overflows from filter basket.	Too much coffee grounds; filter clogged; carafe not properly placed.	Reduce coffee grounds. Clean filter basket. Ensure carafe is centered on heating plate.
Machine leaks.	Water reservoir overfilled; carafe not properly placed; internal blockage.	Do not overfill. Ensure carafe is correctly positioned. Descale the machine. If problem persists, contact support.
Coffee tastes bad.	Machine needs cleaning/descaling; stale coffee; poor water quality.	Clean and descale the machine. Use fresh coffee and filtered water.

Specifications

Brand: Orbegozo

Model Number: CG 4061

Type: Filter Coffee Machine

Power: 750 W

Capacity: 12 Cups

Voltage: 230 Volt

Color: Black

Product Dimensions: 20 x 15 x 25 cm (approx.)

Item Weight: 3 Kilograms (approx.)

Filter Type: Metal (or compatible paper filters)

Included Components: Carafe, Filter

Warranty and Support

This Orbegozo CG 4061 Coffee Machine is covered by a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including the warranty period and coverage details.
For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact Orbegozo customer service. Contact information can typically be found on the manufacturer's official website or on the product packaging.
Please have your model number (CG 4061) and purchase date available when contacting support.

© 2024 Orbegozo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C5G1TD8T

More documents and user manuals: **https://manuals.plus/**