Nokia TA-1543

Nokia 110 4G (2023) User Manual

Model: TA-1543

Introduction

This manual provides essential information for the safe and efficient use of your Nokia 110 4G (2023) mobile phone. Please read it carefully before using the device.





Figure 1: Nokia 110 4G (2023) Device Overview

The image displays the front of the Nokia 110 4G (2023) phone. The screen shows the current time (12:00), date (30.06.2023, Fri), network signal strength for two SIM cards (1 and 2), battery level, and an "Unlock" prompt. Below the screen, the "NOKIA" logo is visible. The physical keypad features standard numeric keys (0-9), function keys, navigation keys, and call/end call buttons. The phone has a dark blue finish.

Setup

1. Package Contents

- Nokia 110 4G (2023) Mobile Phone
- Battery
- Charger
- Quick Start Guide (this manual)

2. Inserting the SIM Card and Battery

1. Turn off the phone and remove the back cover by gently prying it open from the notch.

2. If the battery is inserted, remove it.
3. Slide the SIM card(s) into the SIM slot(s) with the gold contacts facing down. Ensure the card is correctly oriented as indicated by the diagram near the slot. This model supports Dual SIM (DS).
4. Insert the battery, aligning the gold contacts on the battery with those in the phone.
5. Replace the back cover, pressing firmly until it clicks into place.

3. Charging the Battery

1. Connect the charger to a power outlet.
2. Connect the charger cable to the microUSB port on your phone.
3. The battery indicator on the screen will show the charging status.
4. Once fully charged, disconnect the charger from the phone and then from the power outlet.

Operating Instructions

1. Power On/Off

- To power on: Press and hold the Power/End Call button until the phone vibrates and the screen lights up.
- To power off: Press and hold the Power/End Call button, then select "Power off" from the options.

2. Making Calls

1. From the home screen, enter the phone number using the keypad.
2. Press the Call button (green button) to initiate the call.
3. To end a call, press the End Call button (red button).

3. Sending Messages

1. Go to Menu > Messages.
2. Select "Create message" or "New message".
3. Enter your message using the keypad.
4. Enter the recipient's phone number or select from contacts.
5. Press "Send".

4. Contacts

- To add a new contact: Go to Menu > Contacts > Add new.
- To search for a contact: Go to Menu > Contacts > Search.

5. Radio and Music Player

- The phone includes an FM radio and a music player. Connect headphones to use the FM radio as they act as an antenna.
- Music files can be stored on a microSD card (sold separately) and played via the music player.

Maintenance

- Keep the device dry. Precipitation, humidity, and all types of liquids or moisture can contain minerals that will

corrode electronic circuits.

- Do not use or store the device in dusty or dirty areas.
- Do not store the device in high temperatures. High temperatures can shorten the life of electronic devices and damage batteries.
- Do not store the device in cold temperatures. When the device warms to its normal temperature, moisture can form inside the device and damage electronic circuit boards.
- Do not attempt to open the device other than as instructed in this manual.
- Do not drop, knock, or shake the device. Rough handling can break internal circuit boards and fine mechanics.
- Only use a soft, clean, dry cloth to clean the surface of the device.
- Recycle your used electronic products, batteries, and packaging materials in accordance with local regulations.

Troubleshooting

1. Phone does not power on

- Ensure the battery is correctly inserted and charged.
- Try charging the phone for at least 30 minutes.
- If the battery is removable, try removing and reinserting it.

2. Cannot make or receive calls

- Check if the SIM card is properly inserted.
- Ensure you have network coverage.
- Verify that your SIM card is active and has sufficient credit/plan.
- Restart the phone.

3. Poor audio quality during calls

- Check the volume settings during a call.
- Ensure nothing is blocking the earpiece or microphone.
- Move to an area with better network reception.

4. Battery drains quickly

- Reduce screen brightness.
- Close unused applications.
- Limit background data usage.
- Ensure the battery is not old or damaged.

Specifications

Feature	Detail
Model Name	TA-1543
Dimensions	5 x 1.44 x 12.15 cm
Weight	94.5 g

Operating System	S30+
RAM	24 MB
CPU Model	Snapdragon
Screen Size	1.8 Inches
Resolution	Approximately 320 x 240 pixels
Cellular Technology	4G
Wireless Carrier	Unlocked for All Carriers
Battery Type	1 Lithium Ion (included)

Warranty and Support

For warranty information and customer support, please refer to the official Nokia website or contact your local retailer. Keep your proof of purchase for warranty claims.

Manufacturer: Nokia

© 2023 Nokia. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How can I set up separate screens for each icon on the Nokia 110 4G (TA-1543)?

The Nokia 110 4G (2023) TA-1543 runs on the S30+ operating system, which has a simplified interface compared to smartphones. By default, it uses a grid or list view for the menu rather than...

Read full answer