Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Kinhank Super Console S2

Kinhank Super Console S2 Nostalgia Stick Game

User Manual

Introduction

The Kinhank Super Console S2 Nostalgia Stick Game is a compact, plug-and-play retro gaming system designed for ease of use and extensive game compatibility. It comes pre-loaded with over 12,000 classic games and supports 9 different emulators, offering a vast library of entertainment. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your game console.



Image: The Super Console S2 game stick, two wireless controllers, and a television screen highlighting the extensive game library and emulator support.



Image: A user playing a racing game on the Super Console S2, emphasizing the built-in game library and emulator support.

Product Components

Your Kinhank Super Console S2 package includes the following items:

- 1 x Game Stick
- 2 x Wireless Gamepads
- 2 x USB Receivers (for gamepads)
- 1 x HD Cable (HDMI extension)
- 1 x Power Line (USB power cable)
- 1 x 64GB TF Card (pre-installed with games)



Image: A visual representation of all items included in the product packaging, detailing each component.

Setup Guide

Follow these steps to set up your Super Console S2:

1. **Connect Power:** Connect the provided USB Power Line to the Game Stick and then to a suitable USB power source (e.g., TV USB port, USB wall adapter).
2. **Connect to Display:** Plug the Game Stick directly into an available HDMI port on your TV, monitor, or projector. If space is limited, use the included HD cable (HDMI extension).
3. **Select Input:** Using your display's remote control, change the input source to the HDMI port where the Game Stick is connected.
4. **Connect Controllers:** Insert the two USB Receivers into the USB ports on the Game Stick. Ensure the wireless gamepads have batteries installed (not included) and are powered on. The gamepads should automatically connect.

The console is compatible with various display devices that have an HDMI input.



Image: Illustration of the simple plug-and-play setup, showing the game stick connected to a TV.



Image: Demonstrates the wide compatibility of the game stick with various HDMI-enabled display devices.

Operating Instructions

Once set up, the Super Console S2 will display its main menu on your screen. Use the wireless controllers to navigate.

Controller Functions:

- **Directional Pad (D-Pad):** Navigate through menus and control in-game movement.
- **Action Buttons (A, B, X, Y):** Perform actions in games (e.g., jump, attack, confirm selections).
- **START Button:** Start games, pause games, or confirm selections.
- **SELECT Button:** Often used for in-game options, coin insertion, or specific game functions.
- **MODE Button:** Typically used to exit a game and return to the main menu. Press and hold for a few seconds.



Image: Demonstrates the use of the 2.4G wireless controllers for two-player gaming.

Playing Games:

1. From the main menu, use the D-Pad to browse through the list of emulators or game categories.
2. Select an emulator or category and press the A button to enter.
3. Browse the game list. Use the D-Pad to scroll and the A button to select a game.
4. Press the START button to launch the selected game.
5. To exit a game, press and hold the MODE button on the controller for a few seconds until you return to the main menu.

Maintenance

Proper care will extend the life of your Super Console S2:

- **Cleaning:** Use a soft, dry cloth to clean the game stick and controllers. Do not use liquid cleaners or abrasive materials.

- **Storage:** Store the console and accessories in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Avoid dropping the device or exposing it to strong impacts. Do not attempt to disassemble the game stick or controllers.
- **Power:** Always disconnect the power cable when not in use for extended periods.

Troubleshooting

If you encounter issues with your Super Console S2, refer to the following common problems and solutions:

Problem	Possible Cause / Solution
No display on TV / Console does not power on.	Ensure the USB power cable is securely connected to both the game stick and a working power source. Verify the HDMI cable is fully inserted into both the game stick and the TV. Check that your TV input is set to the correct HDMI channel. Try a different HDMI port or power source.
Controllers are not responding.	Ensure the USB receivers are firmly plugged into the game stick's USB ports. Check that the controllers have fresh batteries and are powered on. Re-pair the controllers by turning them off and on, or by re-inserting the USB receivers.
Difficulty navigating menus or games.	Familiarize yourself with the controller layout and button functions as described in the Operating Instructions. Some retro game interfaces may require specific button combinations; refer to on-screen prompts if available.
Games are slow, stuttering, or have poor graphics.	Ensure your TV's display settings are optimized for the console's output. While the console supports many games, performance can vary depending on the specific game and emulator. Some games may not run optimally due to hardware limitations.
Some games are repeated or in a foreign language.	The extensive game library may contain duplicates or region-specific versions. This is inherent to the pre-loaded game collection.

Specifications

Key technical specifications for the Kinhank Super Console S2:

- **Model:** Super Console S2
- **Controller Type:** Button Control
- **Power Source:** Battery Powered (for controllers), USB Powered (for game stick)
- **Hardware Interface:** HDMI
- **Battery Description:** Lithium-Ion or Lithium (for controllers, not included)
- **Display Type:** Digital
- **Material:** Plastic
- **Memory Storage Capacity:** 64 GB (TF Card)

- **Form Factor:** Mini
- **UPC:** 732124389012
- **Product Dimensions:** 6.7 x 4.6 x 3.5 inches
- **Item Weight:** 15.2 ounces
- **ASIN:** B0C5RG3KL3
- **Manufacturer:** Kinhank



Image: Dimensions of the compact game stick, highlighting its mini size and portability.

Warranty and Support

For information regarding product warranty, returns, or technical support, please refer to the documentation provided at the time of purchase or contact the manufacturer directly through their official website or customer service channels. Please have your product model (Super Console S2) and ASIN (B0C5RG3KL3) ready when contacting support.

© 2025 Kinhank. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C5RG3KL3

More documents and user manuals: **https://manuals.plus/**