innioasis G1

innioasis G1 MP3 Player User Manual

Model: G1 | Brand: innioasis

Introduction

Thank you for choosing the innioasis G1 MP3 Player. This device is designed to provide a versatile audio and visual experience, combining local music playback with access to popular streaming services via Wi-Fi. It also functions as an MP4 player and e-reader, making it suitable for various entertainment and educational needs. This manual will guide you through the setup, operation, and maintenance of your new device.

What's in the Box

- MP3 Player x 1
- 64GB SD Card x 1
- USB-C Cable x 1
- Wired Headphones x 1
- User Manual x 1

Setup Guide

1. Initial Charging

Before first use, fully charge your innioasis G1 MP3 Player using the provided USB-C cable and a compatible power adapter (not included). The battery indicator on the screen will show charging progress.

2. Inserting the SD Card

The device comes with a pre-installed 64GB SD card. If you wish to expand storage further (up to 1TB), gently insert a compatible Micro SD, SDHC, or SDXC card into the designated slot until it clicks into place.



Image: The innioasis G1 MP3 Player highlighting its 80GB internal storage (16GB ROM + 64GB TF card) and support for external storage expansion up to 1TB via an SD card slot.

3. Connecting to Wi-Fi

1. From the home screen, tap on 'Settings'.
2. Select 'Network & Internet' or 'Wi-Fi'.
3. Toggle Wi-Fi 'On'.
4. Select your desired Wi-Fi network from the list.
5. Enter the password if prompted and tap 'Connect'.

4. Setting Up Music and Streaming Apps

The device comes pre-installed with popular streaming applications such as Spotify, Pandora, Amazon Music, and Apple Music. To use these, ensure you are connected to Wi-Fi and log in with your existing account credentials. For local music, the powerful built-in music player supports various formats including MP3, WAV, FLAC, APE, OGG, M4A, AAC, WMA, MP2.



Image: The innioasis G1 MP3 Player's screen displaying icons for various pre-installed music streaming applications like Spotify, Pandora, Amazon Music, and Apple Music.

Operating Instructions

Basic Navigation

The innioasis G1 features a 4-inch full-touch LCD screen for intuitive navigation. Swipe left or right to browse through app pages. Tap on an icon to open an application. Use the physical buttons on the side for power and volume control.

Playing Music

- **Local Music:** Open the 'Music' app. You can browse by Title, Folder, Artist, Album, or Genre. Select a song to begin playback.
- **Streaming Music:** Open your preferred streaming app (e.g., Spotify, Pandora). Browse or search for music and select

to play.



Image: The innioasis G1 MP3 Player displaying its local music player interface, showing song information and playback controls.

Bluetooth Connectivity

The device is equipped with Bluetooth 4.2 for stable and fast connections to external audio devices.

1. Go to 'Settings' > 'Connected devices' > 'Bluetooth'.
2. Ensure Bluetooth is 'On'.
3. Put your Bluetooth headphones, speaker, or car stereo into pairing mode.
4. Select your device from the list of available devices to pair.



Image: The innioasis G1 MP3 Player demonstrating its wide Bluetooth compatibility, connecting to headphones, speakers, and car stereos.

Video Playback

The G1 MP3 Player also functions as an MP4 player, supporting 720p and 1080p HD video playback. Access your videos through the 'Videos' or 'Gallery' app.



Image: The innioasis G1 MP3 Player showcasing its video playback capabilities on its 4-inch full-touch LCD screen.

E-reader Functionality

Pre-installed apps like Audible and Kindle allow you to listen to audiobooks or read e-books directly on your device, providing a distraction-free experience.

Parental Controls

The G1 digital player does not allow the installation of additional apps, enhancing safety for younger users. You can also uninstall pre-installed apps that are not frequently used or deemed inappropriate. A reset lock feature is available to prevent unauthorized factory resets.



Image: The innioasis G1 MP3 Player's interface demonstrating the ability to uninstall built-in applications and the restriction on installing new apps, highlighting its 'purer music player' design.

Maintenance

Battery Life

The 1500mAh lithium battery provides approximately 15-25 hours of music playback (depending on earbud type) or 4-5 hours of video playback. To maximize battery life, close unused applications running in the background and reduce screen brightness when not needed.



Image: An internal view diagram of the innioasis G1 MP3 Player highlighting its 1500mAh battery and indicating up to 25 hours of music playback and 5 hours of video playback.

Storage Management

Regularly manage your files using the 'File Manager' app to optimize performance. You can transfer files to and from the device using the provided USB-C cable or the 'File Transfer' app.

Cleaning

Use a soft, lint-free cloth to clean the screen and exterior of the device. Avoid using harsh chemicals or abrasive materials.

Troubleshooting

Device Not Turning On/Charging

- Ensure the USB-C cable is securely connected to both the device and the power source.
- Try a different USB-C cable or power adapter.
- Perform a soft reset by holding the power button for 10-15 seconds.

Bluetooth Connection Issues

- Ensure both the MP3 player and the Bluetooth accessory are in pairing mode and within range.
- Forget the device in Bluetooth settings and attempt to re-pair.
- Restart both devices.

App Freezing or Crashing

- Close the problematic app and reopen it.
- Restart the MP3 player.
- Ensure sufficient storage space is available.

Specifications

Feature	Detail
Model	G1
Product Dimensions	0.39 x 4.33 x 2.36 inches
Item Weight	4.8 ounces
Manufacturer	INNIOASIS
ASIN	B0C619YRQ8
Batteries	1 Lithium Ion batteries required (included)
Date First Available	May 23, 2023
Brand	innioasis
Model Name	mp3 player with bluetooth
Special Feature	Video Playback, Voice Recorder, Equalizer, FM Radio
Connectivity Technology	Bluetooth
Memory Storage Capacity	64 GB (16GB ROM + 64GB TF card included, expandable up to 1TB)
Color	White
Screen Size	4 Inches
Compatible Devices	Laptop, Personal Computer, Headphone, Earphone
Media Type	SDHC, SD Card, Micro SDHC, Micro SDXC, Micro SD

Warranty and Support

The innioasis G1 MP3 Player comes with a**1-Year Warranty Service** from the manufacturer. For any product-related inquiries, technical support, or warranty claims, please contact innioasis customer service.
Customer Service Email: innioasis-csc@hotmail.com
Support is available 7 days a week, 24 hours a day.

© 2024 innioasis. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question