HHH Clash 200 EFI

HHH Clash 200 EFI Scooter User Manual

Model: Clash 200 EFI

1. Introduction

This manual provides essential information for the safe operation, assembly, maintenance, and care of your HHH Clash 200 EFI Scooter. Please read this manual thoroughly before operating the scooter to ensure proper usage and to prevent injury or damage. Keep this manual in a safe place for future reference.



Figure 1.1: HHH Clash 200 EFI Scooter (Blue)

2. Safety Information

Your safety and the safety of others are very important. This manual contains important safety messages. Always read and follow all safety messages.

- Always wear a helmet and appropriate safety gear when operating the scooter.
- Familiarize yourself with all controls before riding.
- Do not operate the scooter under the influence of alcohol or drugs.
- Observe all local traffic laws and regulations.
- Perform pre-ride inspections as outlined in the maintenance section.
- **Proposition 65 Warning:** This product may contain chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

3. What's in the Box

Upon receiving your HHH Clash 200 EFI Scooter, please verify that all components are present:

- HHH Clash 200 EFI Scooter (partially assembled)
- Matching trunk with keys
- Title and all documents for registration
- Owner's Manual
- Assembly tools (if applicable)

4. Assembly

The HHH Clash 200 EFI Scooter arrives approximately 70% assembled within a metal crate. Final assembly is required for components such as the tires, handlebars, and mirrors. Refer to the included assembly guide and available online videos for detailed instructions.



Figure 4.1: Scooter as received in shipping crate

Important: Ensure all bolts and fasteners are securely tightened after assembly and before the first ride. Professional assembly is recommended if you are unfamiliar with scooter mechanics.

5. Initial Setup

After assembly, perform the following initial setup steps:

1. **Fueling:** Fill the fuel tank with the recommended gasoline type (refer to the specifications section for details).
2. **Oil Check:** Verify engine oil levels are correct. Add oil if necessary.
3. **Tire Pressure:** Check and adjust tire pressure to the recommended PSI for both front and rear tires.
4. **Battery Connection:** Ensure the battery is properly connected and charged.
5. **Brake Check:** Test both front and rear brakes for proper function.
6. **Lights and Signals:** Confirm all lights (headlight, taillight, turn signals) and the horn are operational.

The Electronic Fuel Injection (EFI) system ensures reliable starting in various weather conditions.

6. Operating Instructions

The HHH Clash 200 EFI Scooter is designed for ease of use with its fully automatic CVT transmission. No manual gear

shifting is required.

6.1 Starting the Engine

1. Ensure the scooter is on its center stand or side stand.
2. Insert the key into the ignition and turn it to the 'ON' position.
3. Squeeze either the front or rear brake lever.
4. Press the electric starter button. The EFI system will facilitate a quick start.

6.2 Riding the Scooter

- Once the engine is running, release the brake lever.
- Gently twist the throttle grip to accelerate. The automatic transmission will manage gear ratios.
- Maintain a stable posture. The scooter's long 52-inch wheelbase contributes to stability.
- To slow down or stop, gradually release the throttle and apply the brake levers. The front hydraulic disc brake provides strong stopping power.
- Maximum speed is approximately 68 MPH. Always ride within safe limits and according to road conditions.



Figure 6.1: Side profile of the HHH Clash 200 EFI Scooter

7. Maintenance

Regular maintenance is crucial for the longevity and safe operation of your scooter. The EFI system helps keep maintenance low.

7.1 Daily Checks

- Check tire pressure and condition.
- Verify brake lever free play and effectiveness.

- Inspect all lights and turn signals.
- Check engine oil level.

7.2 Periodic Maintenance

Refer to the detailed maintenance schedule in your separate owner's manual for specific intervals. Key items include:

- Oil changes
- Spark plug inspection/replacement
- Air filter cleaning/replacement
- Brake fluid level and pad wear inspection
- Drive belt inspection



Figure 7.1: Front hydraulic disc brake system

8. Troubleshooting

This section provides solutions to common issues you might encounter. For more complex problems, consult a qualified technician.

8.1 Engine Does Not Start

- Check if the ignition key is in the 'ON' position.
- Ensure a brake lever is squeezed when pressing the starter button.
- Verify there is sufficient fuel in the tank.
- Check battery connections and charge level.

8.2 Poor Performance

- Inspect tire pressure.
- Check for proper fuel quality.
- Ensure air filter is clean.

8.3 Brake Issues

- Check brake fluid levels.
- Inspect brake pads for wear.

9. Specifications

Feature	Detail
Product Dimensions	81 x 28 x 44 inches
Item Weight	300 pounds
Engine Displacement	168cc (as per feature bullets, not 200cc)
Fuel System	Electronic Fuel Injection (EFI)
Transmission	Fully Automatic CVT
Max Speed	Up to 68 MPH
Wheelbase	52 inches
Brakes	Front Hydraulic Disc Brake
Manufacturer	HHH
Model Number	Clash 200 EFI Scooter

10. Warranty and Support

For warranty information, please refer to the documentation included with your scooter or contact HHH customer support directly. For technical assistance, parts, or service inquiries, please reach out to the manufacturer or your authorized dealer.

Customer Support: Please ensure a working phone number is provided for delivery appointments and any necessary support communication.

Your browser does not support the video tag.

Video 10.1: Overview of the HHH Clash 200 EFI Adult Gas Scooter Moped. This video provides a general visual tour of the scooter's features and design.

© 2024 HHH. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Where is the fuel pump relay located on the HHH Clash 200 EFI scooter?

The provided manual for the HHH Clash 200 EFI does not explicitly state the physical location of the fuel pump relay. However, on most EFI scooters of this design, electrical components like relays are...

Read full answer