Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Altec Lansing IMW34N-CB

Altec Lansing Furry Wireless Speaker

Model: IMW34N-CB

Introduction

Thank you for choosing the Altec Lansing Furry Wireless Speaker. This manual will guide you through the features, setup, and operation of your new portable speaker. Designed for ultra-portability and powerful sound, this speaker is an ideal companion for travel and outdoor activities. It features True Wireless Stereo (TWS) pairing, voice assistant integration, and wide compatibility with Bluetooth-enabled devices.



Image: Overview of the Altec Lansing Furry Wireless Speaker's key features, including Bluetooth connectivity, call management, 6-hour battery life, IPX5 water resistance, wide compatibility, hands-free speakerphone, included carabiner, and voice assistant support.

Safety Information

- Do not expose the speaker to extreme temperatures or direct sunlight for extended periods.
- Do not immerse the speaker in water. While it is water-resistant, it is not fully waterproof.
- Keep the speaker away from strong magnetic fields.
- Do not attempt to disassemble or modify the speaker. This will void the warranty.
- Use only the specified charging cable and power adapter.
- Keep out of reach of children.

Package Contents

Please check that all items are present in your package:

- Altec Lansing Furry Wireless Speaker
- USB Charging Cable
- Carabiner (for portability)
- Quick Start Guide (this manual)

Product Overview

Familiarize yourself with the various parts and controls of your Altec Lansing Furry Wireless Speaker.



Image: Detailed diagram illustrating the control buttons and ports on the Altec Lansing Furry Wireless Speaker, including Play/Pause, Volume Up/Next Track, Volume Down/Previous Track, Power/Play/Pause/Answer/Siri, LED Indicator, Mic, and Micro USB Port.

- **Power/Play/Pause/Answer/Siri Button:** Press and hold to power on/off. Short press to play/pause music or answer/end calls. Double press to activate voice assistant.
- **Volume Up/Next Track Button:** Short press to increase volume. Long press to skip to the next track.

- **Volume Down/Previous Track Button:** Short press to decrease volume. Long press to go to the previous track.
- **Play/Pause Button:** Short press to play or pause audio.
- **LED Indicator:** Shows power and Bluetooth status.
- **Mic:** For hands-free calling and voice assistant commands.
- **Micro USB Port:** For charging the speaker.

Setup

Charging the Speaker

Before first use, fully charge your speaker. Connect the supplied USB charging cable to the Micro USB port on the speaker and the other end to a USB power adapter (not included) or a computer's USB port. The LED indicator will show charging status.

Powering On/Off

- **To Power On:** Press and hold the Power button until you hear an audible prompt and the LED indicator lights up.
- **To Power Off:** Press and hold the Power button until you hear an audible prompt and the LED indicator turns off.

Bluetooth Pairing

The Altec Lansing Furry Wireless Speaker offers universal compatibility with any Bluetooth-enabled device up to a 30-foot range.



Image: The Altec Lansing Furry Wireless Speaker demonstrating its universal compatibility with various Bluetooth-enabled devices such as smartphones, tablets, laptops, and desktop computers, highlighting its 30-foot Bluetooth range.

1. Ensure the speaker is powered on and in pairing mode (the LED indicator will flash).
2. On your device (smartphone, tablet, laptop), go to the Bluetooth settings.
3. Search for available devices and select "Altec Furry" from the list.
4. Once paired, the LED indicator will turn solid, and you will hear a confirmation sound.

True Wireless Stereo (TWS) Pairing (Optional)

If you have two Altec Lansing Furry Wireless Speakers, you can pair them together for a stereo sound experience.

1. Ensure both speakers are powered on and not connected to any other Bluetooth device.
2. On one speaker, double-press the Power button. It will enter TWS pairing mode.
3. The speakers will automatically connect to each other. You will hear a confirmation sound.

4. Once TWS paired, connect your device to one of the speakers via Bluetooth as described above.

Operating the Speaker

Playing Audio

Once paired, audio from your device will play through the speaker. Use the controls on the speaker or your device to manage playback.

- **Play/Pause:** Short press the Play/Pause button.
- **Volume Control:** Short press the Volume Up (+) or Volume Down (-) buttons.
- **Next Track:** Long press the Volume Up (+) button.
- **Previous Track:** Long press the Volume Down (-) button.

Call Management

The speaker features a built-in microphone for hands-free calling.

- **Answer Call:** Short press the Power/Answer button when a call comes in.
- **End Call:** Short press the Power/Answer button during a call.
- **Reject Call:** Press and hold the Power/Answer button when a call comes in.

Voice Assistant Activation

Wake up your favorite voice assistants like Siri or Google Assistant with a simple voice command.



Image: The Altec Lansing Furry Wireless Speaker displayed alongside the logos for Google Assistant and Siri, emphasizing its capability to activate these voice assistants for various commands.

- **Activate Voice Assistant:** Double-press the Power/Siri button. The speaker will then be ready to receive your voice commands.

Water Resistance

The Altec Lansing Furry Wireless Speaker is IPX5 water-resistant, meaning it can withstand splashes and light rain. Do not submerge the speaker in water.

Maintenance

- **Cleaning:** Wipe the speaker with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the speaker in a cool, dry place when not in use for extended periods.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge it regularly, even if not in

use.

Troubleshooting

Problem	Solution
Speaker does not power on.	Ensure the speaker is fully charged. Press and hold the Power button for a few seconds.
Cannot pair with Bluetooth device.	Ensure the speaker is in pairing mode (flashing LED). Turn off and on Bluetooth on your device. Move speaker closer to device. Forget previous pairings on your device.
No sound or low volume.	Increase volume on both the speaker and your connected device. Ensure speaker is properly paired. Check if audio is paused.
Voice assistant not responding.	Ensure the speaker is connected to your device. Double-press the Power/Siri button to activate. Speak clearly into the microphone.
TWS pairing fails.	Ensure both speakers are not connected to any other Bluetooth device. Place them close to each other. Double-press the Power button on one speaker to initiate TWS pairing.

Specifications

Feature	Detail
Model Name	IMW34N-CB
Speaker Type	Wireless
Connectivity Technology	Bluetooth
Wireless Communication Technology	Bluetooth
Bluetooth Range	30 Feet (approx. 9 meters)
Power Source	Battery Powered (powerful built-in battery)
Water Resistance Level	Water Resistant (IPX5)
Audio Output Mode	Stereo
Controller Type	Voice Control
Compatible Devices	Laptop, MP3 Player, Smartphone, Tablet
Product Dimensions	2 x 8 x 2.5 inches
Item Weight	1.33 pounds
Color	Blue

Warranty and Support

The Altec Lansing Furry Wireless Speaker comes with a limited warranty. For detailed warranty information, please refer to the warranty card included in your product packaging or visit the official Altec Lansing website.
For technical support, troubleshooting assistance, or to inquire about warranty claims, please contact Altec Lansing customer service through their official website or the contact information provided in your product documentation.
Online Resources: For the latest updates, FAQs, and support, please visit the Altec Lansing official website.

© 2023 Altec Lansing. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C69ZTJQ5

More documents and user manuals: **https://manuals.plus/**