Dreo DR-HSH006

Dreo Space Heater User Manual

Model: DR-HSH006 | Brand: Dreo

Important Safety Information

Please read all instructions carefully before using this appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).
- This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces.
- Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.
- Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped or damaged in any manner.
- Do not use outdoors.
- To disconnect heater, turn controls to OFF, then remove plug from outlet.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable liquids are used or stored.
- Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
- The innovative tilt-detection sensor improves accuracy and reliability for better tip-over protection.
- Built with V0 flame retardant materials, overheat protection, and a safety plug, all certified by ETL.

Product Overview

The Dreo Space Heater (Model: DR-HSH006) is a portable electric heater designed for indoor use, providing efficient and safe heating for various spaces such as offices, bedrooms, and homes. It features advanced PTC ceramic heating

technology for fast warmth and a compact design for easy placement.

Key Features:

- **Hyperamics 1500W Advanced PTC System:** Delivers heat within seconds and enhances warm air circulation for up to 200% farther reach.
- **Unbreakable Safety:** Features tilt-detection sensor for tip-over protection, V0 flame retardant materials, overheat protection, and ETL certified safety plug.
- **Ultimate Temperature Control:** Enhanced NTC chipset for precise temperature setting from 41-95℉ with 1℉ increments.
- **Cozy Quietness:** Brushless DC motor and winglet fan design reduce noise to only 34dB.
- **Versatile Modes:** Includes Power heat, ECO, and Fan Only modes.
- **Convenient Extras:** Remote control, 12-hour timer, mute function, child lock, and memory function.

Product Components:



The Dreo Space Heater (Model DR-HSH006) shown with its accompanying remote control. The heater is gold and black, cylindrical with a digital display on top, emitting warm air.



A compact Dreo Space Heater placed on a small table in a living room, demonstrating its small size and ability to provide warmth in a home environment.



Diagram showing the dimensions of the Dreo Space Heater: 11.02 inches in height, 6.61 inches in width, and 6.61 inches in depth.

Setup

1. **Unpacking:** Carefully remove the heater and all accessories from the packaging. Retain packaging for future storage or transport.
2. **Placement:** Place the heater on a firm, level surface. Ensure there is at least 3 feet (0.9 meters) of clear space around the heater to allow for proper airflow and prevent fire hazards. Do not place it on soft surfaces like carpets or rugs that might block the air intake.
3. **Power Connection:** Ensure the heater is turned off before plugging it into a 120V AC, 60Hz wall outlet. Do not use extension cords, power strips, or surge protectors.
4. **Remote Control Batteries:** Insert the included CR2 battery into the remote control, observing correct polarity.

Operating Instructions

The Dreo Space Heater offers various modes and settings for optimal comfort and energy efficiency.

Control Panel and Remote:

The heater can be operated using the touch controls on the top panel or the included remote control. The digital display shows the current temperature and mode.



The control panel on top of the heater features touch buttons for power, mode, temperature adjustment, and timer. The remote control mirrors these functions for convenient operation.

Powering On/Off:

- Press the **Power button** ( ) on the control panel or remote to turn the heater on or off.
- The heater will remember the last used mode and temperature setting when powered back on.

Selecting Modes:

Press the **Mode button** ( ) to cycle through the available heating modes:

- **Power Heat (H1, H2, H3):** Provides continuous heat at different power levels (1000W, 1250W, 1500W). Use the +/- buttons to adjust the power level.
- **ECO Mode:** Energy-saving mode where the heater automatically adjusts power to maintain a set temperature (41-95℉). This mode utilizes the dedicated thermal sensor for precise temperature control.
- **Fan Only:** Circulates air without heating.

Setting Temperature (ECO Mode):

- In ECO mode, use the **Temperature Up (+)** and **Temperature Down (-)** buttons to set your desired temperature between 41℉ and 95℉ in 1℉ increments.
- The display will show the set temperature.



The heater's digital display shows the temperature setting, which can be adjusted between 41°F and 95°F for precise climate control.

Timer Function:

- Press the **Timer button** ( ) to set the auto-off timer from 1 to 12 hours. Each press adds one hour.
- The display will show the remaining time before the heater automatically turns off.

Child Lock:

- To activate the child lock, press and hold the **Child Lock button** ( ) for 3 seconds. The control panel will be locked to prevent accidental changes.
- To deactivate, press and hold the Child Lock button again for 3 seconds.

Mute/Unmute:

- To mute or unmute the button sounds, press and hold the **Mute button** ( ) for 3 seconds.

Official Product Videos:

Your browser does not support the video tag.

This video demonstrates the compact size and energy efficiency of the Dreo Space Heater, highlighting its ability to provide warmth while being mindful of energy consumption.

Maintenance

Regular maintenance ensures the longevity and efficient operation of your Dreo Space Heater.

- **Cleaning:** Always unplug the heater before cleaning. Use a soft cloth, brush, or vacuum cleaner to remove dust from the surfaces and air intake/exhaust vents.
- **Water Contact:** Never immerse the heater in water or allow water to drip into the interior of the heater.
- **Storage:** When not in use, store the heater in a cool, dry place. It is recommended to store it in its original packaging to protect it from dust and damage.

Troubleshooting

If you encounter issues with your Dreo Space Heater, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Heater does not turn on.	Not plugged in; power outlet malfunction; tip-over switch activated; overheat protection activated.	Ensure plug is fully inserted. Check circuit breaker. Place heater on a flat, stable surface. Allow heater to cool down for 30 minutes if it overheated.
Heater blows cold air.	Heater is in Fan Only mode; temperature setting is too low.	Switch to a heating mode (H1/H2/H3 or ECO). Increase the target temperature in ECO mode.
Heater makes unusual noise.	Dust accumulation; foreign object inside.	Unplug and clean the heater. If noise persists, contact customer support.
Remote control not working.	Batteries dead or incorrectly inserted; obstruction between remote and heater.	Replace batteries. Ensure correct polarity. Remove any obstructions.

For issues not listed here, or if the problem persists, please contact Dreo customer support.

Specifications

Brand	Dreo
Model Number	DR-HSH006
Color	Gold
Form Factor	Tower

Indoor/Outdoor Usage	Indoor
Product Dimensions	7.32"D x 7.32"W x 11.02"H
Item Weight	3.04 pounds
Heating Coverage	200 sq.ft
Burner Type	PTC Ceramic
Fuel Type	Electric
Number of Speeds	4
Voltage	120 Volts
Amperage	12.5 Amps
Min Temperature Setting	41 Degrees Fahrenheit
Max Temperature Setting	95 Degrees Fahrenheit
Batteries Required	1 CR2 batteries (included for remote)
Included Components	User Manual, Remote Control, Space Heater

Warranty and Support

Your Dreo Space Heater comes with a**12-month default warranty**. This warranty can be extended up to**30 months** by registering your product. Please refer to the product registration instructions provided with your purchase or visit the official Dreo website for details.
For any issues, questions, or technical support, please contact Dreo customer service. Our product experts are available to assist you.
It is recommended to carefully read the precautions in the user manual and Quick Start Guide (QSG) before use to ensure a pleasant and safe experience.

© 2024 Dreo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question