LavaTap DT40WT20

LavaTap Honeywell Home DT4 Digital Wired Room Thermostat User Manual

Model: DT40WT20

1. Introduction

The LavaTap Honeywell Home DT40WT20 is a modern, digital wired room thermostat designed to provide precise temperature control for your home. This thermostat is a direct replacement for older DT90, DT90E, and DT90E1012 models, offering enhanced features and ease of use. Its intuitive digital display and push-button controls allow for simple adjustment of your heating system, ensuring optimal comfort and energy efficiency.



Figure 1: Front view of the LavaTap Honeywell Home DT40WT20 Thermostat, displaying the current temperature and control buttons.

2. Product Features

- **Digital Display:** Clear and easy-to-read digital screen for temperature readings.
- **Push Button Control:** Simple and intuitive button interface for setting adjustments.
- **Wired Connectivity:** Reliable wired connection for consistent performance.
- **On/Off Functionality:** Direct control over your heating system's operation.
- **Wall Mount Design:** Designed for secure and discreet wall installation.
- **Rectangular Shape:** Modern and compact design.
- **Remote Access Capability:** Potential for remote control (requires compatible system/hub, not included).
- **Voltage:** Operates on 230 Volts (AC).

3. Package Contents

Please check the package contents carefully. If any items are missing or damaged, contact your retailer.

- LavaTap Honeywell Home DT40WT20 Digital Wired Room Thermostat
- Mounting Screws and Wall Plugs
- Installation Guide (this manual)

4. Safety Information

Read all safety information before installing or operating this device. Failure to follow these instructions may result in electric shock, fire, or other hazards.

- **Electrical Safety:** Installation must be carried out by a qualified electrician or competent person and in accordance with national wiring regulations. Always switch off the mains electricity supply before commencing any wiring work.
- **Voltage:** This device operates on 230 Volts (AC). Ensure the power supply matches this requirement.
- **Location:** Install the thermostat in a dry, indoor location, away from direct sunlight, drafts, or heat sources that could affect temperature readings.
- **Cleaning:** Do not use abrasive cleaners or solvents. Clean with a soft, damp cloth only.
- **Disposal:** Dispose of the device responsibly at the end of its life, following local regulations for electronic waste.

5. Installation Guide

5.1. Choosing a Location

Select a central location in the room that represents the average temperature. Avoid placing the thermostat near windows, doors, heat sources (radiators, lamps), or in direct sunlight, as these can lead to inaccurate temperature readings. The recommended mounting height is approximately 1.5 meters (5 feet) from the floor.

5.2. Mounting the Thermostat

1. **Switch off Power:** Before starting, ensure the mains electricity supply to your heating system is completely switched off at the consumer unit/fuse box.
2. **Separate Front Cover:** Gently detach the front cover of the thermostat from its backplate. Refer to the diagram for guidance.
3. **Mark Drilling Points:** Hold the backplate against the wall at your chosen location. Use a pencil to mark the drilling points through the screw holes.
4. **Drill Holes:** Drill holes at the marked points using an appropriate drill bit for your wall type. Insert wall plugs if necessary.
5. **Wire Connections:** Route the electrical wiring through the opening in the backplate. Connect the wires to the appropriate terminals as shown in the wiring diagram (refer to your heating system's specific wiring instructions and consult a qualified electrician if unsure).
6. **Secure Backplate:** Screw the backplate securely to the wall using the provided screws.
7. **Attach Front Cover:** Carefully reattach the front cover to the backplate, ensuring it clicks firmly into place.
8. **Restore Power:** Once installation is complete and all connections are secure, restore the mains electricity supply.



Figure 2: Rear view of the thermostat's backplate, illustrating mounting points and potential wiring access.

6. Operation

6.1. Understanding the Display

The digital display shows the current room temperature. When adjusting settings, it will temporarily show the target temperature.

6.2. Setting the Temperature

Use the **+** and **-** buttons to increase or decrease the desired room temperature (setpoint). The display will flash the new setpoint as you adjust it, then revert to showing the current room temperature after a few seconds. The thermostat will then work to maintain the set temperature.

6.3. On/Off Function

The central button typically acts as an On/Off toggle or mode selector. Press this button to switch the heating system connected to the thermostat On or Off. Consult the specific wiring and system configuration for exact behavior.

6.4. Remote Access (If Applicable)

While the DT40WT20 has "Remote Access" listed as a special feature, this typically refers to its compatibility with external smart home hubs or systems that provide remote control capabilities. The thermostat itself does not have built-in Wi-Fi for direct app control. For remote access, it must be integrated into a compatible smart home ecosystem. Refer to your smart home system's documentation for integration instructions.

7. Maintenance

7.1. Cleaning

To clean the thermostat, gently wipe the surface with a soft, slightly damp cloth. Do not use abrasive cleaners, solvents, or chemical sprays, as these can damage the plastic and electronic components.

7.2. Power Supply

The DT40WT20 is a wired, corded electric device and does not require battery replacement. Ensure the power supply remains stable and free from interruptions.

8. Troubleshooting

Problem	Possible Cause	Solution
Display is blank	No power supply.	Check mains electricity supply to the thermostat and heating system. Ensure circuit breaker is on.
Heating not turning on/off	Incorrect wiring; Thermostat setting too low/high; Heating system fault.	Verify wiring connections (consult electrician). Adjust setpoint. Check heating system boiler/furnace.
Inaccurate temperature reading	Thermostat located near heat source/draft; Sensor obstruction.	Relocate thermostat if possible. Ensure no objects are blocking the thermostat's sensor.
Buttons unresponsive	Temporary software glitch; Physical damage.	Try cycling power to the thermostat (switch off and on at mains). If problem persists, contact support.

9. Specifications

Attribute	Detail
Brand	LavaTap
Model Number	DT40WT20
Colour	White
Item Shape	Rectangular
Control Type	Button Control / Push Button
Mounting Type	Wall Mount
Voltage	230 Volts (AC)

Attribute	Detail
Power Source	Corded Electric
Special Features	Remote Access (via compatible systems)
Item Weight	250 g
Package Dimensions	16 x 11.5 x 5 cm
Display Type	Digital
Connectivity Technology	Wired (for heating system connection); Wi-Fi (for remote access via compatible smart home hubs)

10. Warranty and Support

For warranty information and technical support, please refer to the documentation provided with your purchase or contact your retailer. Keep your proof of purchase for warranty claims.
You may also visit the official LavaTap store on Amazon for more product information and support resourcesLavaTap Store

© 2024 LavaTap. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question