GYMAX Kids Trampoline with Slide & Ladder

GYMAX 7FT Kids Trampoline Instruction Manual

Model: Kids Trampoline with Slide & Ladder | Brand: GYMAX

List | Assembly | Operation | Introduction | Maintenance | Safety Information | Troubleshooting | Parts | Specifications | Warranty & Support

1. Introduction

Thank you for choosing the GYMAX 7FT Kids Trampoline. This product is designed to provide a fun and safe recreational experience for children aged 3 and above. Featuring a versatile 3-in-1 design, it includes a trampoline, a slide, a ladder, and ocean balls, offering multiple play options. Constructed with heavy-duty galvanized steel and an all-round enclosure net, this trampoline is built for durability and safety, supporting up to 600 lbs. Please read this manual thoroughly before assembly and use to ensure proper installation and safe operation.



Image: The GYMAX 7FT Kids Trampoline highlighting its 3-in-1 design with a slide, ladder, and ocean balls.

2. Safety Information

Your safety and the safety of others are paramount. This trampoline is ASTM approved, ensuring it meets rigorous safety standards. Adhere to the following guidelines to prevent injury:

- **Adult Supervision Required:** Always supervise children when they are using the trampoline.
- **Age and Weight Limits:** Suitable for ages 3+. Do not exceed the maximum weight capacity of 600 lbs.
- **One Jumper at a Time:** To prevent collisions, only one person should jump on the trampoline at a time.
- **Clearance Area:** Ensure adequate overhead and surrounding clearance. Keep the area around the trampoline free from obstacles.
- **Proper Entry/Exit:** Always use the ladder for entry and exit. Do not jump off the trampoline.
- **No Somersaults or Flips:** Avoid dangerous maneuvers that could lead to head or neck injuries.
- **Inspect Before Each Use:** Check all components, including the net, springs, and frame, for damage or wear before each use.

- **Weather Conditions:** Do not use the trampoline in wet, windy, or icy conditions.
- **Secure Enclosure:** Always ensure the enclosure net zipper is fully closed during use.



Image: Detailed view of the trampoline's safety features, emphasizing the protective net and padded poles.

3. Parts List

Before beginning assembly, ensure all parts are present and accounted for. Refer to the installation video for a visual guide to the parts. If any parts are missing or damaged, please contact customer support.

Trampoline Components

No.	Description	Quantity
1	Jumping Mat with Safety Pad & Enclosure Net	1
2	Upper Frame Tube	6

No.	Description	Quantity
3	Corner Connector	6
4	Leg Support Rod	6
5	Leg Base	6
6	Curved Base Tube	3
7	Enclosure Net Support Pole (Foam Padded)	6 (3x 10, 3x 10A)
8	Springs	36
9	Spring Pull Tool	1
10	Top Enclosure Pole (Foam Padded)	3
10A	Top Enclosure Pole (Foam Padded)	3
11	Curved Enclosure Pole (Foam Padded)	3
12	Slide	1
13	Ladder	1
A	Long Bolt	6
B	Washer	12
C	Spring Washer	6
D	Screw	10
E	Nut	6
F	Allen Wrench	1
G	Wrench	1
H	Slide Bracket	3

4. Assembly Instructions

Follow these steps carefully for proper assembly. An official installation video is provided below for visual guidance. It is recommended to have two adults for assembly.

Your browser does not support the video tag.

Video: Kids trampoline with slide installation video (3:13)
This video provides a complete visual guide for assembling your GYMAX trampoline.

Step-by-Step Assembly:

1. **Assemble Base Frame (Video: 0:07 - 0:19):**

   Insert the Leg Support Rods (4) into the Leg Bases (5). Then, connect the Curved Base Tubes (6) to the Leg Support Rods (4) to form the hexagonal base. Ensure all connections are secure.



Image: Assembling the sturdy U-shaped legs that form the base of the trampoline.

2. **Connect Frame Sections (Video: 0:19 - 0:35):**

   Attach the Upper Frame Tubes (2) to the Corner Connectors (3). Then, connect these assembled sections to the base frame, forming the upper hexagonal frame. Ensure all connections are firm.



Image: The hexagonal frame taking shape as sections are connected.

3. **Install Enclosure Net Support Poles (Video: 0:36 - 1:08):**

   Insert the Enclosure Net Support Poles (10 & 10A) into the designated holes on the frame. Secure them using the Long Bolts (A), Washers (B), Spring Washers (C), and Nuts (E). Tighten with the provided Allen Wrench (F) and Wrench (G).



Image: The yellow foam-padded poles being inserted into the frame.

4. **Attach Jumping Mat and Safety Pad (Video: 1:09 - 1:39):**

   Carefully place the Jumping Mat with Safety Pad & Enclosure Net (1) over the frame. Use the Spring Pull Tool (9) to attach the Springs (8) from the jumping mat to the frame. Ensure all 36 springs are securely attached. Then, tie the safety pad straps to the frame.



Image: The jumping mat and safety pad secured to the frame with springs.

5. **Install Enclosure Net (Video: 1:40 - 2:11):**

   Slide the Curved Enclosure Poles (11) through the top sleeve of the enclosure net (7). Connect these poles to the top of the Enclosure Net Support Poles (10 & 10A). Secure the bottom of the net to the frame using the provided ties.



Image: The enclosure net being pulled up and secured around the trampoline.

6. **Attach Slide and Ladder (Video: 2:12 - 3:08):**

   Position the Slide (12) against the trampoline frame. Secure it using the Slide Brackets (H) and Screws (D). Assemble the Ladder (13) by connecting its components and then hook it onto the trampoline frame for easy access.



Image: The completed trampoline with the slide and ladder in place.

5. Operating Instructions

Once assembled, the GYMAX Kids Trampoline offers various ways to play:

- **Trampoline Use:** Enter through the zippered opening. Ensure the zipper is closed before jumping. Jump in the center of the mat for optimal bounce and safety.
- **Slide Use:** The slide provides an alternative exit or entry point. Ensure the anti-collision mat is in place at the bottom of the slide for safe landing.
- **Ocean Ball Pit:** The trampoline can be used as a ball pit by adding the included ocean balls. This provides a soft

and fun play area.

Always remind children to follow safety rules and use the trampoline responsibly.

6. Maintenance

Regular maintenance will extend the life of your trampoline and ensure continued safety:

- **Cleaning:** Clean the jumping mat and safety pad with mild soap and water. Rinse thoroughly and allow to air dry. Do not use abrasive cleaners.
- **Frame Inspection:** Periodically check all nuts, bolts, and frame connections for tightness. Tighten as needed.
- **Spring Inspection:** Inspect springs for rust, stretching, or breakage. Replace any damaged springs immediately.
- **Net and Pad Inspection:** Check the enclosure net and safety pad for tears, holes, or excessive wear. Replace if damaged.
- **Weather Protection:** If used outdoors, consider covering the trampoline during harsh weather conditions (heavy rain, snow, strong winds) to protect it from elements.
- **Storage:** For long-term storage, disassemble the trampoline and store it in a dry, protected area to prevent rust and material degradation.

7. Troubleshooting

Here are some common issues and their solutions:

Problem	Possible Cause	Solution
Difficulty during assembly	Parts not aligning, incorrect orientation.	Refer to the installation video and ensure parts are oriented correctly before attempting to force them. Double-check part numbers.
Trampoline feels unstable	Loose frame connections, uneven ground.	Tighten all bolts and nuts. Ensure the trampoline is placed on a flat, level surface.
Enclosure net is loose or torn	Improper installation, wear and tear, damaged buckle.	Re-secure all net ties and ensure poles are correctly inserted. Inspect for damage and replace the net if necessary. Contact seller for replacement parts if a buckle is broken.
Springs are detached or stretched	Heavy use, improper installation.	Reattach springs using the spring pull tool. If springs are stretched or damaged, replace them.

8. Specifications

Feature	Detail
Brand	GYMAX
Model Name	Kids Trampoline with Slide & Ladder
Color	Blue

Feature	Detail
Material	Polyvinyl Chloride (PVC), Galvanized Steel, EPE, Polypropylene (PP), Polyethylene (PE)
Frame Material	Alloy Steel
Frame Size	84 Inches (7FT)
Shape	Hexagonal
Product Dimensions (L x W x H)	88"L x 88"W x 73"H
Item Weight	63 Pounds
Maximum Weight Recommendation	600 Pounds
Number Of Springs	36
Suggested Users	Boys, Girls
Included Components	User Guide, Floor Mat, Ocean Balls, Kids Trampoline with Slide & Ladder



Image: Detailed dimensions of the trampoline, including height, width, and slide measurements.

9. Warranty & Support

This GYMAX trampoline comes with a **90-day warranty**. For any questions, concerns, or assistance with missing/damaged parts, please do not hesitate to contact the seller directly through your purchase platform. Provide your order number and a detailed description of the issue for prompt support.

© 2024 GYMAX. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question