Famiworths 60317a5f-232b-4330-89e2-9406f0ac4200

Famiworths Iced & Hot Coffee Maker Instruction Manual

Model: 60317a5f-232b-4330-89e2-9406f0ac4200

1. Important Safety Information

Please read all instructions carefully before using your Famiworths Iced & Hot Coffee Maker. Retain this manual for future reference.

- **Electrical Safety:** Do not immerse the appliance, cord, or plug in water or other liquids. Ensure the power outlet matches the voltage specified on the appliance.
- **Hot Surfaces:** The brewing chamber and heating plate become hot during operation. Avoid contact with hot surfaces.
- **Water Usage:** Use only fresh, cold water in the reservoir. Do not fill with hot water, milk, or other liquids as this may damage the machine.
- **Brewing:** Do not open the brewing chamber during operation. Hot water and steam may escape and cause injury.
- **Cleaning:** Always unplug the coffee maker before cleaning. Follow descaling instructions to maintain performance and safety.
- **Children:** This appliance is not intended for use by children. Close supervision is necessary when any appliance is used near children.

2. Product Overview

The Famiworths Iced & Hot Coffee Maker is a versatile single-serve machine designed for both hot and iced coffee. It supports K-cups and ground coffee, features a compact design, and includes a descaling reminder for easy maintenance.



Image: Famiworths Iced & Hot Coffee Maker, showcasing its sleek design and compact footprint.

Included Components:

- Famiworths Iced & Hot Coffee Maker
- Reusable Ground Coffee Filter with Lid
- K-Cup Holder
- Recipe Book (for iced coffee)

3. Setup

3.1 Initial Cleaning

1. Before first use, wash the reusable ground coffee filter and K-cup holder with warm, soapy water. Rinse thoroughly.
2. Wipe the exterior of the coffee maker with a damp cloth.
3. Perform a cleansing brew cycle: Fill the water reservoir to the MAX line (14oz) with fresh, cold water. Place an empty mug on the drip tray. Close the lid and press the 'REGULAR' button. Discard the water after the cycle.

3.2 Placement

Place the coffee maker on a stable, flat, heat-resistant surface. Ensure adequate clearance around the unit for ventilation.



Image: The compact dimensions of the Famiworths coffee maker, measuring 8.2"D x 5.6"W x 12"H, suitable for small spaces and travel mugs up to 6.7 inches tall.

4. Operating Instructions

4.1 Water Filling

Open the water reservoir lid located at the top-right of the machine. Fill the reservoir with fresh, cold water according to your desired brew size (6oz, 8oz, 10oz, 12oz, 14oz). Do not exceed the MAX 14oz line.



Image: A hand pouring water into the open water reservoir of the coffee maker, showing the clear water level markings.

4.2 Inserting Coffee

Lift the brewing chamber lid. Choose your preferred coffee method:

- **For K-cups:** Place a K-cup into the K-cup holder.
- **For Ground Coffee:** Fill the reusable ground coffee filter with your desired amount of ground coffee (up to 0.88oz). Ensure the cap is securely attached to prevent grounds from entering your cup. Place the filled filter into the brewing chamber.



Image: Close-up of the coffee maker's brewing chamber, showing both the reusable ground basket with a lid and a K-pod holder, highlighting its 2-in-1 functionality.



Image: A hand placing ground coffee into the reusable filter, demonstrating the process for brewing with loose grounds.

4.3 Brewing Coffee

Place your mug or travel mug (up to 6.7 inches tall) on the drip tray.

- **For Hot Coffee:** Press the 'REGULAR' button. The machine will brew hot coffee at approximately 180°F in about 4 minutes.
- **For Iced Coffee:** Fill your mug with ice cubes. Press the 'OVER ICE' button. The machine will brew concentrated coffee over ice to prevent dilution.



Image: A finger pressing the 'OVER ICE' button on the coffee maker, with a glass of iced coffee brewing below.



Image: A glass of iced coffee with a straw, indicating a 4-minute brewing time.



Image: A red mug receiving hot coffee from the machine, with a temperature indicator of 180°F.

The coffee maker will automatically turn off after brewing is complete.

5. Maintenance

5.1 General Cleaning

- Unplug the appliance before cleaning.
- Wash the reusable filter and K-cup holder after each use.

- Wipe the exterior with a damp cloth. Do not use abrasive cleaners.

5.2 Descaling

The coffee maker features a built-in descaling reminder. When descaling is needed, the two brew buttons will blink red alternately.

1. Pour a maximum of 14oz of descaling solution (or a vinegar-water mixture) into the water reservoir.
2. Place an empty mug on the drip tray.
3. Press both brew buttons simultaneously for 2 seconds to start the descaling cycle.
4. The machine will run a cleaning cycle. Discard the solution after the cycle.
5. Run 2-3 cycles with fresh, cold water to rinse the machine thoroughly.



Image: An illustration showing the internal water flow during the descaling process, indicating the blinking red lights for the reminder and the steps to initiate cleaning.

6. Troubleshooting

- **Coffee not brewing:** Ensure the machine is plugged in, the water reservoir has sufficient water, and the brewing chamber lid is fully closed.
- **Weak coffee:** Check if enough ground coffee or a fresh K-cup is used. For ground coffee, ensure the grind size is appropriate for drip coffee makers.
- **Coffee overflowing:** Ensure the mug size is appropriate for the selected water amount. Do not overfill the water reservoir.
- **Descaling light blinking:** Follow the descaling instructions in Section 5.2.
- **Unusual noise:** This may indicate mineral buildup. Perform a descaling cycle. If the issue persists, contact customer support.

7. Specifications

Feature	Detail
Brand	Famiworths

Model Number	60317a5f-232b-4330-89e2-9406f0ac4200
Product Dimensions	8.2"D x 5.6"W x 12"H
Item Weight	3.29 pounds
Capacity	14 ounces
Coffee Input Type	K-Cups, Ground Coffee
Operation Mode	Fully Automatic
Special Feature	Auto Clean Function (Descaling Reminder)
Voltage	120V
Material	BPA-free materials

8. Warranty & Support

This Famiworths Iced & Hot Coffee Maker comes with a One Year Warranty.

For support or troubleshooting, please contact:

- **Phone:** 1-972-467-4438
- **Email:** support@myfamiworths.com

You can also scan the QR code on the product for additional support information.

9. Product Videos

Video: A detailed review of the Famiworths Single Serve Coffee Maker, demonstrating its hot and cold brewing capabilities for K-cups and ground coffee.

Video: Showcasing the Famiworths coffee maker's ability to make great iced coffee and its space-saving design.

Video: A helpful guide titled 'MUST WATCH before buying Famiworths Iced Coffee Maker', providing insights into the product's features and usage.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question