Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bellemave B0C6KHNTN5

Bellemave TV Stand (Model B0C6KHNTN5) Instruction Manual

Model: B0C6KHNTN5

Introduction

Thank you for purchasing the Bellemave TV Stand. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure safe and proper use of your new entertainment center. Please read this manual thoroughly before assembly and retain it for future reference.

Safety Information

Please observe the following safety precautions during assembly and use:

- Keep all packaging materials away from children.
- Assemble the unit on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not overload the TV stand. Refer to theSpecifications section for weight limits.
- Place the TV stand on a level surface to prevent tipping.
- Do not allow children to climb on or play with the TV stand.
- Use caution when moving the assembled unit. It is recommended to have two people for moving.

Parts List and Dimensions

Before beginning assembly, verify that all parts and hardware are present and undamaged. Refer to the included hardware pack for specific component identification.



Image: Detailed dimensions of the TV stand, including overall length (85.04 inches), depth (15.59 inches), and height (29.29 inches). Individual compartment measurements are also shown.

The TV stand consists of various wooden panels, shelves, doors, and support legs, along with an assortment of screws, dowels, hinges, and other fasteners. A complete list of parts and hardware is provided in the separate assembly guide included with your product.

Setup and Assembly

Assembly of the Bellemave TV Stand requires approximately 1 hour with two people. Please follow the step-by-step instructions provided in the separate assembly manual included in your package. Ensure you have a Phillips head screwdriver and a hammer (not included) for assembly.

General Assembly Guidelines:

1. **Unpack and Identify:** Carefully unpack all components and lay them out on a clean, soft surface. Identify each part using the provided diagrams in the assembly manual.

2. **Attach Legs:** Secure the support legs to the base of the TV stand as indicated in the instructions.
3. **Construct Frame:** Assemble the main frame of the TV stand by connecting the side panels, bottom, and top panels using the designated hardware.
4. **Install Shelves:** Insert the fixed and adjustable shelves into their respective positions.
5. **Attach Doors:** Mount the hinges to the doors and the main frame, then attach the doors. Adjust hinges as needed for proper alignment.
6. **Install Back Panels:** Secure the back panels to the rear of the unit. Ensure cord management openings are correctly positioned.
7. **Final Check:** Verify that all connections are tight and the stand is stable.



Image: The TV stand with all four cabinet doors open, revealing the interior storage compartments and open shelves. This view helps visualize the internal structure during assembly.

Operating Instructions

Once assembled, your Bellemave TV Stand is ready for use.

- **Placement:** Position the TV stand on a flat, stable surface in your desired living room or bedroom area.
- **TV Placement:** Carefully place your television on the top surface of the stand. This stand is designed to accommodate TVs up to 80 inches. Ensure the TV's base is fully supported and does not overhang the edges.
- **Storage:** Utilize the four cabinet doors and four open shelves for organizing media devices, remote controls, books, and other items.
- **Cable Management:** Route power cords and audio/video cables through the designated cord-management openings located on the back panel of the open shelves. This helps maintain a tidy and clutter-free appearance.



Image: The Bellemave TV Stand in a modern living room, showcasing a large television placed on top, media devices in the open shelves, and decorative items. This illustrates typical usage.

Maintenance and Care

Proper care will extend the life and appearance of your TV stand.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals, which can damage the melamine finish.
- **Spills:** Clean up spills immediately to prevent staining or damage to the wood finish.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten as needed to maintain stability.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading or discoloration of the wood finish.
- **Heat Protection:** Use coasters or protective pads under hot items to prevent heat damage to the surface.



Image: A close-up of the top corner and shelf of the TV stand, highlighting the wood grain and finish. This detail emphasizes the importance of proper cleaning and care.

Troubleshooting

If you encounter any issues with your Bellemave TV Stand, refer to the following common solutions:

- **Wobbly Stand:**
  - Ensure all screws and fasteners are fully tightened.
  - Verify the stand is on a level surface. Adjust floor glides on the legs if present.
- **Doors Not Aligning:**
  - Adjust the hinges. Most furniture hinges allow for minor adjustments in height, depth, and side-to-side movement. Refer to the hinge manufacturer's instructions if available.
  - Ensure the main frame is assembled squarely.

- **Missing Parts:**
  - Double-check all packaging materials.
  - Contact Bellemave customer support with your model number and a description of the missing part.

Specifications

Feature	Detail
Brand	Bellemave
Model Number	B0C6KHNTN5
Product Dimensions (D x W x H)	15.59"D x 85.04"W x 29.29"H
Weight Capacity	110 Pounds (Top Surface)
Material	Engineered Wood (MDF with Melamine Finish)
Number of Doors	4
Number of Open Shelves	4
Mounting Type	Floor Mount
Assembly Required	Yes (Full Assembly)
Recommended TV Size	Up to 80 inches

Warranty and Support

Specific warranty information for the Bellemave TV Stand is not provided in this document. Please refer to your purchase receipt or contact the retailer/manufacturer directly for warranty details.
For customer support, missing parts, or further assistance, please contact Bellemave customer service through their official website or the contact information provided with your purchase.
You can visit the Bellemave Store on Amazon for more information.

© 2023 Bellemave. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C6KHNTN5

More documents and user manuals: **https://manuals.plus/**